

# ProBell<sup>®</sup> Rotary Applicator

334452K

EN

***For finishing and coating applications in Class I, Div. I hazardous locations or Group II, Zone 1 explosive atmospheres, using the following materials:***

**Solventborne Models:**

- Group D materials.
- Group IIA materials.

**Waterborne Models:**

**Conductive waterborne fluids that meet at least one of the following conditions for non-flammability:**

- **Material does not sustain burning in accordance with the Standard Test Method for Sustained Burning of Liquid Mixtures, ASTM D4206.**
- **Material is classified as non-ignitable or hard to ignite as defined by EN 50176.**

**For professional use only.**

*100 psi (0.7 MPa, 7.0 bar) Maximum Air Inlet Pressure*


*150 psi (1.03 MPa, 10.3 bar) Maximum Fluid Working Pressure*



### **Important Safety Instructions**

This equipment could present hazards if not operated according to the information in this manual. Read all warnings and instructions in this manual and in all ProBell component manuals before using the equipment.

Save all instructions.



ti24617b

# Contents

<b>Related Manuals</b> .....	<b>3</b>	<b>Electrical Tests</b> .....	<b>52</b>
<b>Part Number Matrix</b> .....	<b>4</b>	Test Full Electrostatic Applicator with Power Supply .....	52
<b>Available Models</b> .....	<b>5</b>	Test Non-Electrostatic Applicator with Ground Plug .....	52
Electrostatic Models .....	5	Test Power Supply in Main Housing .....	54
Non-Electrostatic Models .....	6	Test Power Supply .....	56
<b>Approvals</b> .....	<b>7</b>	Test Front Housing .....	56
<b>Warnings</b> .....	<b>8</b>	Clean the Air Cap and Cup .....	57
<b>Introduction</b> .....	<b>11</b>	Clean the Fluid Nozzle .....	58
System Description .....	11	Clean the Outside of the Rotary Applicator .....	58
<b>Installation</b> .....	<b>13</b>	<b>Troubleshooting</b> .....	<b>59</b>
Basic Guidelines .....	13	Spray Pattern Troubleshooting .....	59
Typical System Installation .....	14	Applicator Operation Troubleshooting .....	59
Overview of Installation Steps .....	16	Electrical Troubleshooting .....	61
Step 1. Mount the Rotary Applicator .....	16	Waterborne System Voltage Loss Troubleshooting .....	62
Step 2. Connect All Lines at the Applicator .....	18	<b>Repair</b> .....	<b>64</b>
Connection Schematics .....	24	Prepare for Cup or Air Cap Service .....	64
Step 3. Mount Controllers and Accessories .....	26	Prepare for Applicator Service .....	64
Step 4. Connect Fluid Supply .....	28	Replace Cup or Air Cap .....	64
Step 5. Connect the Air Lines .....	33	Service the Cup and Air Cap .....	67
Step 6. Connect Power and Communication Cables .....	37	Replace Front Housing and Turbine Assembly .....	69
Step 7. Prepare the Spray Area .....	39	Repair or Replace the Solvent Stud .....	70
Step 8. Create Required System Interlocks .....	39	Repair Fluid Nozzle .....	70
Step 9. Ground the Equipment .....	40	Repair or Replace the Fluid Tube .....	71
Check Electrical Grounding .....	41	Replace Magnetic Pickup Sensor or Fiber Optic Extension Cable .....	72
System Logic Controller Setup .....	43	Repair Fluid Valves and Seats .....	74
Verification .....	43	Repair Fluid Tube Fittings or Coiled Fluid Tubes .....	75
<b>Operation</b> .....	<b>44</b>	Repair the Power Supply .....	76
Pre-Operation Checklist .....	44	Replace an Air Tube Fitting .....	76
Check Fluid Resistivity .....	45	<b>Parts</b> .....	<b>77</b>
Check Fluid Viscosity .....	45	Solventborne Models (R_A1_0) .....	77
Spray Procedures .....	45	Waterborne Models (R_A1_8) .....	80
Flushing Procedure .....	47	Non-Electrostatic Models (R_A1_1) .....	83
Pressure Relief Procedure .....	48	<b>Repair Kits</b> .....	<b>86</b>
Voltage Discharge and Grounding Procedure .....	49	Main Housing Repair Kits .....	86
Shutdown Procedure .....	50	O-Ring Kits .....	86
<b>Maintenance</b> .....	<b>51</b>	Fittings and Tools .....	86
Daily Care and Cleaning Checklist .....	51	Cup Selection Charts .....	87
Check for Fluid Leakage .....	51	<b>Accessories</b> .....	<b>88</b>
		Mounting Kits .....	88
		Fiber Optic Bulkhead Installation .....	89
		Miscellaneous Equipment .....	92

<b>Dimensions</b> .....	<b>93</b>	Shaping Air Consumption Charts .....	99
60° Robot Mount - shown as shipped .....	93	Fluid Flow Rate Charts .....	101
60° Robot Mount - shown with mounting Kit 24Z179 .....	94	Fluid Pressure Loss Charts .....	104
Reciprocator Mount - shown with reciprocator mounting kit 24Z178 .....	95	<b>Ignitability of Coating Materials</b> .....	<b>106</b>
<b>Performance Charts</b> .....	<b>96</b>	<b>Technical Specifications</b> .....	<b>107</b>
Turbine Air Consumption Charts .....	96	<b>California Proposition 65</b> .....	<b>107</b>
Turbine Inlet Air Pressure Charts .....	97	<b>Graco Standard Warranty</b> .....	<b>108</b>
		<b>Graco Information</b> .....	<b>108</b>

## Related Manuals

Manual in English	Description
334626	ProBell Rotary Applicator, Hollow Wrist
3A3657	ProBell Electrostatic Controller
3A3953	ProBell Speed Controller
3A3954	ProBell Air Controller
3A3955	ProBell System Logic Controller
3A4232	ProBell Cart Systems
3A4346	ProBell Hose Bundle
3A4384	ProBell System CGM Installation Kit
3A4738	ProBell Reflective Speed Sensor Kit
3A5223	ProBell Remote Fluid Ground Bracket Kit 25A878

# Part Number Matrix

Check the identification plate (ID) for the part number of your applicator. The following matrix defines the components of your applicator based on the 6-digit part number.

## Sample Part Number

<b>R1A</b>	<b>1</b>	<b>3</b>	<b>0</b>
15 mm Cup	ProBell Standard Applicator	0.75 mm nozzle	Solventborne

Cup Size		Description and Mounting Style		Nozzle Size		Applicator Type	
<b>R1A</b>	15 mm	<b>1</b>	ProBell Standard Rotary Applicator - Stationary, Reciprocator, or Solid-Wrist Robot.	<b>3</b>	0.75 mm	<b>0</b>	Solventborne
<b>R3A</b>	30 mm			<b>4</b>	1.0 mm	<b>8</b>	Waterborne
<b>R5A</b>	50 mm	<b>2</b>	ProBell Rotary Applicator - Hollow Wrist, 60° Robot Mount. See manual 334626.	<b>5</b>	1.25 mm	<b>1</b>	Non-Electrostatic
				<b>6</b>	1.5 mm		

# Available Models

Solventborne, Waterborne, and Non-Electrostatic applicator types.

## Electrostatic Models

Part No.	Cup Size*			Nozzle Size				Applicator Type		Maximum Output Voltage	Series
	50 mm	30 mm	15 mm	0.75 mm	1.0 mm	1.25 mm	1.5 mm	Solventborne	Waterborne		
R5A140	✓				✓			✓		100 kV	C
R5A150	✓					✓		✓		100 kV	C
R5A160	✓						✓	✓		100 kV	C
R5A148	✓				✓				✓	60 kV	C
R5A158	✓					✓			✓	60 kV	C
R5A168	✓						✓		✓	60 kV	C
R3A130		✓		✓				✓		100 kV	C
R3A140		✓			✓			✓		100 kV	C
R3A150		✓				✓		✓		100 kV	C
R3A160		✓					✓	✓		100 kV	C
R3A138		✓		✓					✓	60 kV	C
R3A148		✓			✓				✓	60 kV	C
R3A158		✓				✓			✓	60 kV	C
R3A168		✓					✓		✓	60 kV	C
R1A130			✓	✓				✓		100 kV	D
R1A140			✓		✓			✓		100 kV	D
R1A150			✓			✓		✓		100 kV	D
R1A138			✓	✓					✓	60 kV	D
R1A148			✓		✓				✓	60 kV	D
R1A158			✓			✓			✓	60 kV	D

\* All applicator models ship with a serrated aluminum cup. See the **Cup Selection Charts**, page 86, to see all available cups.





## Non-Electrostatic Models

Part No.	Cup Size*			Nozzle Size				Applicator Type	Maximum Output Voltage	Series
	50 mm	30 mm	15 mm	0.75 mm	1.0 mm	1.25 mm	1.5 mm	Non-Electrostatic		
R5A141	✓				✓			✓	-----	A
R5A151	✓					✓		✓	-----	A
R5A161	✓						✓	✓	-----	A
R3A131		✓		✓				✓	-----	A
R3A141		✓			✓			✓	-----	A
R3A151		✓				✓		✓	-----	A
R3A161		✓					✓	✓	-----	A
R1A131			✓	✓				✓	-----	A
R1A141			✓		✓			✓	-----	A
R1A151			✓			✓		✓	-----	A

\* All applicator models ship with a serrated aluminum cup. See the **Cup Selection Charts**, page 86, to see all available cups.

# Approvals

Specific controllers, rotary applicators, and power supply cables must be used together. Refer to the table below for compatible models.

Model	Electrostatic Controller	Power Supply Cables	Applicator Type	Applicator Approvals
RxAxx0	24Z098	17J586 17J588 17J589	Solventborne	 
RxAxx8	24Z099	17J586 17J588 17J589	Waterborne	
RxAxx1	NA	NA	Non-Electrostatic	 

# Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

## **WARNING**



### **FIRE AND EXPLOSION HAZARD**

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:

- Electrostatic equipment must be used only by trained, qualified personnel who understand the requirements of this manual.
- Ground all equipment, personnel, object being sprayed, and conductive objects in or close to the spray area. Resistance must not exceed 1 megohm. See **Grounding** instructions.
- Do not use pail liners unless they are conductive and grounded.
- Always use the required arc detection settings and maintain a safe distance of at least 6 inches (152 mm) between the applicator and the workpiece.
- **Stop operation immediately** if static sparking or repeated arc detection errors occur. Do not use equipment until you identify and correct the problem.
- Check applicator resistance and electrical grounding daily.
- Use and clean equipment only in well ventilated area.
- Always turn off and discharge the electrostatics when flushing, cleaning or servicing equipment.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking).
- Do not plug or unplug power cords or turn lights on or off when flammable fumes are present.
- Keep the spray area clean at all times. Use non-sparking tools to clean residue from the booth and hangers.
- Keep a working fire extinguisher in the work area.
- Interlock the applicator air and fluid supply to prevent operation unless ventilation air flow is above the minimum required value.
- Interlock the Electrostatic Controller and fluid supply with the booth ventilation system to disable operation if the air flow falls below minimum values. Follow your local codes.

#### **For solventborne systems only:**

Use only Group IIA or Group D materials.

- Use cleaning solvents with highest possible flash point when flushing or cleaning equipment.
- To clean the exterior of the equipment, cleaning solvents must have a flash point at least 15°C (59°F) above ambient temperature. Non-ignitable fluids are preferred.

#### **For waterborne systems only:**

Use conductive waterborne fluids that meet at least one of the following conditions for non-flammability:

- Material does not sustain burning in accordance with the Standard Test Method for Sustained Burning of Liquid Mixtures, ASTM D4206.
- Material is classified as non-ignitable or hard to ignite as defined by EN 50176.



# ⚠ WARNING



## ELECTRIC SHOCK HAZARD

This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.

- Turn off and disconnect power at main switch before disconnecting any cables and before servicing or installing equipment.
- Connect only to grounded power source.
- All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.
- Follow the **Voltage Discharge and Grounding Procedure** before entering the spray area for any cleaning or service operations.

### For waterborne systems:

- Connect the applicator to a voltage isolation system that will discharge the system voltage when not in use.
- All components of the voltage isolation system that are charged to high voltage must be contained within an isolation enclosure that prevents personnel from making contact with the high voltage components before the system voltage is discharged.
- Interlock the Electrostatic Controller with the voltage isolation system to shut off the electrostatics anytime the isolation system enclosure is opened.
- Do not splice fluid hoses together. Install only one continuous Graco Waterborne Fluid Hose between the isolated fluid supply and the applicator.











## PRESSURIZED EQUIPMENT HAZARD

Fluid from the equipment, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.

- Follow the **Pressure Relief Procedure** when you stop spraying/dispensing and before cleaning, checking, or servicing equipment.
- Tighten all fluid connections before operating the equipment.
- Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.

# ! WARNING

 	<p><b>EQUIPMENT MISUSE HAZARD</b></p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> <li>• Always operate in accordance with all information given in the instruction manuals.</li> <li>• Do not operate the unit when fatigued or under the influence of drugs or alcohol.</li> <li>• Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See <b>Technical Specifications</b> in all equipment manuals.</li> <li>• Use fluids and solvents that are compatible with equipment wetted parts. See <b>Technical Specifications</b> in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheet (SDS) from distributor or retailer.</li> <li>• Turn off all equipment and follow the <b>Pressure Relief Procedure</b> when equipment is not in use.</li> <li>• Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.</li> <li>• Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.</li> <li>• Make sure all equipment is rated and approved for the environment in which you are using it.</li> <li>• Use equipment only for its intended purpose. Call your distributor for information.</li> <li>• Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.</li> <li>• Do not kink or over bend hoses or use hoses to pull equipment.</li> <li>• Keep children and animals away from work area.</li> <li>• Comply with all applicable safety regulations.</li> </ul>
 	<p><b>PLASTIC PARTS CLEANING SOLVENT HAZARD</b></p> <p>Many solvents can degrade plastic parts and cause them to fail, which could cause serious injury or property damage.</p> <ul style="list-style-type: none"> <li>• Use only compatible water-based solvents to clean plastic structural or pressure-containing parts.</li> <li>• See <b>Technical Specifications</b> in this and all other equipment instruction manuals. Read fluid and solvent manufacturer's Safety Data Sheet (SDS) and recommendations about compatibility.</li> </ul>
 	<p><b>ENTANGLEMENT HAZARD</b></p> <p>Rotating parts can cause serious injury.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Do not wear loose clothing, jewelry or long hair while operating equipment.</li> <li>• Equipment can start without warning. Before checking, moving, or servicing equipment, follow the <b>Pressure Relief Procedure</b> and disconnect all power sources.</li> </ul>
	<p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read Safety Data Sheet (SDS) to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> </ul>
	<p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. Protective equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear, and hearing protection.</li> <li>• Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.</li> </ul>

# Introduction

## System Description

The ProBell Rotary Applicator is part of a spraying system designed for industrial painting applications. The following three components are needed in all ProBell spray systems that utilize electrostatics.

- Rotary Applicator
- Power Supply Cable
- Electrostatic Controller

**NOTE:** Non-electrostatic applicators do not require a power supply cable or Electrostatic Controller.

See **Typical System Installation**, page 14, for other available system components.

### Rotary Applicator

#### Applicator Style

**The ProBell Rotary Applicator, Standard style** is designed for use on a stationary mount, a reciprocator, or a solid wrist robot. It has a straight body with all connections on the rear of the applicator.

**The ProBell Rotary Applicator, Hollow Wrist style** is designed for use on a hollow wrist robot. The body has a 60° angle with all connections through a quick-disconnect plate. This design allows all connections to run inside the arm of the hollow wrist robot. See manual 334626.

#### Applicator Type

The **Solventborne Type** is designed for use in Class 1, Div. I Hazardous Locations using Group D spray materials, or for use in Group II, Zone 1 Explosive Atmosphere Locations using Group IIA spray materials.

The **Waterborne Type** is for use in Class 1, Div. I Hazardous Locations or in Group II, Zone 1 Explosive Atmosphere Locations with conductive waterborne fluids that meet at least one of the following conditions for non-flammability:

- Material does not sustain burning in accordance with the Standard Test Methods for Sustained Burning of Liquid Mixtures, ASTM D4206.
- Material is classified as non-ignitable or hard to ignite as defined by EN 50176. See **Ignitability of Coating Materials** on page 105 for definitions.

The **Non-Electrostatic Type** can be used with solventborne or waterborne materials.


**NOTE:** Non-electrostatic rotary applicators are used without a ProBell Electrostatic Controller and power supply cable. Instructions and steps related to the Electrostatic Controller do not apply to Non-Electrostatic systems.

#### Power Supply Cable

The Power Supply Cable connects the ProBell Electrostatic Controller to the Power Supply in the ProBell Rotary Applicator. The Power Supply Cable is available in three lengths: 11 meters (36 ft.), 20 meters (66 ft.), and 30 meters (98 ft.).

#### ProBell Electrostatic Controller

The ProBell Electrostatic Controller (manual 3A3657) provides the ability to display and set the voltage and current. It can operate remotely via discrete I/O or CAN communication.



li24618b

**FIG. 1. Rotary Atomizer Components**

Ref.	Component	Description
1, 4	Main Housing	The housings direct the air, fluid and electrical charge from the customer connections to the front of the ProBell Rotary Applicator. The main housing contains three fluid valves (4).
13	Front Housing	
5	Speed Sensor Assembly	The Speed Sensor Assembly detects the rotational speed of the magnets on the turbine assembly.
7, 9	Fluid Tube and Nozzle	The Fluid Nozzle contains the paint flow orifice. There are six sizes: 0.75 mm, 1.0 mm, 1.25 mm, 1.5 mm, 1.8 mm, and 2.0 mm.
10	Turbine Assembly	The turbine is driven by compressed air and provides rotating speeds up to 60,000 RPM.
15	Retaining Ring	Loosen and remove to access front-end components.
18, 19	Air Cap and Cover	The Air Cap and Cover direct the shaping air to the correct diameter for the cup. There are three sizes of air cap components, to match the three cup sizes.

Ref.	Component	Description
20	Cup	The Cup atomizes paint by rotating at speeds up to 60,000 RPM. There are three cup Sizes: 15 mm, 30 mm, and 50 mm.
27	Coiled Fluid Tube	Coiled Fluid Tubes are installed in each Rotary Applicator (3 for solvent-borne models and 1 for waterborne models). The coiled fluid tubes provide a more resistive path between the high voltage and ground for the paint, solvent, and dump lines (solvent only on waterborne).
28	Power Supply or Ground Plug	The Power Supply contains an electrostatic multiplier with 100 kV maximum output. It has a resistor built in to provide a path to discharge the Rotary Applicator.  The Ground Plug provides a ground path for the non-electrostatic applicator.
36	Mounting Bracket	The Mounting Bracket is used with the correct optional mounting kit for either a reciprocator or a robot.

# Installation



Installing and servicing this equipment requires access to parts that may cause electric shock or other serious injury if work is not performed properly.

- Do not install or service this equipment unless you are trained and qualified.
- Be sure your installation complies with National, State and Local codes for the installation of electrical apparatus in a Class I, Div. I, Group D Hazardous Location or a Group II, Zone 1 Explosive Atmosphere Location.
- For waterborne electrostatic applications, ensure that the applicator is connected to a voltage isolation system that will discharge the system voltage when required.
- Comply with all applicable local, state, and national fire, electrical, and other safety regulations.

## Basic Guidelines

### System Installation Requirements

- Several interlocks must be provided to allow safe and reliable operation. See **Step 8. Create Required System Interlocks**, page 38.
- Ventilation must be provided to prevent buildup of flammable or toxic vapors while spraying, flushing, or cleaning the applicator. See **Step 7. Prepare the Spray Area**, page 38.
- Earth grounds must be provided for all specified system components. See **Step 9. Ground the Equipment**, page 39.

### Additional Electrostatic Waterborne System Installation Requirements


- The applicator must be connected to a voltage isolation system that isolates the fluid supply from ground and allows voltage to be maintained at the front of the applicator.
- The applicator must be connected to a voltage isolation system with a bleed resistor that will discharge the system voltage when the applicator is not in use.
- All components of the voltage isolation system that are charged to high voltage must be contained within an isolation enclosure that prevents personnel from making contact with the high voltage components before the system voltage is discharged.
- The controller must be interlocked with the voltage isolation system to shut off and discharge the electrostatics anytime the isolation enclosure is opened or entered. See **Step 8. Create Required System Interlocks**, page 38.
- The voltage isolation system must be interlocked with the spray location entrance to automatically discharge the voltage and ground the fluid whenever someone opens the isolation enclosure or enters the spray location. See **Step 8. Create Required System Interlocks**, page 38.

#### NOTICE

The system should not have severe arcing occurring when the isolation mechanism opens and closes. Severe arcing will shorten the life of the system components.

# Typical System Installation

FIG. 2. shows a typical installation. It is not an actual system design. For assistance in designing a system to suit your particular needs, contact your Graco distributor.



**FIG. 2. Typical Installation, Electronic Air Controller, with Fluid Isolation Box for Waterborne Systems**

Typical Installation Components	
A	Rotary Applicator
B	Bearing Air Supply Line
BR	Bearing Air Return Line
BK	Braking Air Supply Line
C	Air Controller
D	Dump Return Line
DT	Dump Valve Trigger Air Line
F	Fiber Optic Cable for Speed Control
G	Speed Controller
H	Electrostatic Controller
J	System Logic Controller
L	PLC (connected to a gateway inside the Speed Controller)
N	CAN Communication Cables
P	Paint Supply Line
PT	Paint Valve Trigger Air Line
Q	I/O Cable (for electrostatic control and interlocks)
R	Power Supply Cable
S	Solvent Supply Line
SI	Shaping Air (Inner) Air Line
SO	Shaping Air (Outer) Air Line
ST	Solvent Valve Trigger Air Line (cup wash)
T	Fluid Supply Isolation Equipment (for water-borne applicators only)
TA	Turbine Air Line
U	Fluid Pressure Regulator





**NOTE:** See **Step 9. Ground the Equipment**, page 39, for required grounding information.

## Overview of Installation Steps

The following steps are needed to install and connect your system.

- Step 1. Mount the Rotary Applicator**, page 16.
- Step 2. Connect All Lines at the Applicator**, page 18.
- Step 3. Mount Controllers and Accessories**, page 26.
- Step 4. Connect Fluid Supply**, page 28.
- Step 5. Connect the Air Lines**, page 32.
- Step 6. Connect Power and Communication Cables**, page 36.
- Step 7. Prepare the Spray Area**, page 38.
- Step 8. Create Required System Interlocks**, page 38.
- Step 9. Ground the Equipment**, page 39.


## Step 1. Mount the Rotary Applicator

				
<p>To reduce the risk of fire and explosion due to sparking, all mounting hardware must be non-conductive or be properly grounded. Keep all grounded mounting hardware at least 10 in. (25.4 cm) away from the charged components.</p>				

### Reciprocator Mounting

Use Reciprocator Mounting Kit 24Z178 to mount the applicator to a stationary stand or to a reciprocator. See the Dimensions on page 94.

1. Install the nut (104) and the bolt (103), but do not tighten. Connect the mounting rod (102) to the reciprocator or stand. Use adapter (105) to adjust the diameter of the mounting rod if needed.
2. Thread the mounting post (101) into the mounting bracket (36) and tighten firmly. Use Loctite or other adhesive on the threads to prevent loosening.
3. Position the mounting post (101) in the mounting rod (102). Rotate to the desired angle.
4. Tighten the nut (104) and bolt (103) securely.



**FIG. 3. Reciprocator Mounting Kit**




## 60° Robot Mounting

Use 60° Robot Mounting Kit 24Z179 to mount the applicator to a solid wrist robot. See the Dimensions on page 92.

1. Remove screws (37) and bracket (36) from the applicator.
2. Install and tighten screws (108) to attach the adapter (105) to the mounting bracket (36).
3. Install and tighten screws (37) to reattach the mounting bracket (36) to the applicator.
4. Thread screw (107) through the robot mounting bracket (106) and into the bottom of the adapter (105) and tighten.
5. Thread screws (109) through the robot mounting bracket (106) and into the robot adapter plate (not shown).

**NOTE:** To find the adapter plate that will work with your robot, see **Accessories**, page 87.



**FIG. 4. 60° Robot Mount**

## Distance to Workpiece

To reduce the risk of fire and explosion, maintain a Safe Distance of at least 6 in. (15.2 cm) between the applicator and the workpiece at all times.				

Position the cup a minimum of 6 in. (15.2 cm) from the closest approach point of the workpiece. Take into account potential rotation or swaying of the part. The arc detection circuitry of the ProBell Electrostatic Controller helps minimize the risk of an arc should a workpiece approach too close to the charged cup. In addition, the Safe Distance of 6 in. (15.2 cm) must be maintained at all times.

A typical spraying distance is 9-14 in. (23-36 cm).


To reduce the risk of fire and explosion, the spray area must remain free of rusted steel. Frictional contact between aluminum components and rusted steel must be avoided.				

## Step 2. Connect All Lines at the Applicator


A total of 14 connections are needed for ProBell with electrostatic operation; 13 connections without electrostatics.

**NOTE:** All lines must run **through** the manifold retaining ring (35), the adapter cover (34), and the shroud (33).

1. Screw off the manifold retaining ring (35) by hand. The adapter cover (34) will come with it. (Electrostatic models only.)
2. Slide the shroud (33) off the back of the housing.



**FIG. 5. Electrostatic Bell Parts**







**FIG. 6. Non-Electrostatic Bell Parts**

3. Pass each line through these three pieces before connection at the applicator.

**TIP:** Connect the lines in the order shown in this section. **Label each line** and **bundle into groups**, to avoid confusion later when the lines are connected to the fluid supply, air supply, and other system components.

## Fluid Lines for Solventborne Type Applicators


			
<p>Fluid lines may contain high-voltage fluid. Sparking due to a hose leak could cause fire, explosion, or electrical shock. To reduce the risk of sparking:</p> <ul style="list-style-type: none"> <li>• Connect all fluid lines into the grounded fluid bracket.</li> <li>• Use only genuine Graco coiled fluid tubes.</li> </ul>			

All three fluid lines are connected at the fluid bracket at the back of the applicator. The fluid then flows through coiled fluid tubes and into the main housing.

1. Connect the paint supply line to port **P**.
2. Connect the solvent supply line to port **S**. This port is 6 mm (1/4 in.).
3. If needed, connect the fluid dump line to port **D**. If not needed, plug Kit 25C288 is available to plug the dump passage in the applicator.
4. Tighten all three connectors to secure the lines.

The paint and dump line ports are 8 mm (5/16 in.). Refer to the **Fluid Pressure Loss Charts**, page 102, to help determine the best tubing for your application.

An Alternate Fluid Bracket Kit 25A878 is available, for use in electrostatic applications with highly conductive materials. This kit includes a grounded fluid bracket that is mounted remotely. The fluid lines pass through the fluid bracket at the back of the applicator and connect directly into the main housing. The longer fluid lines create a more resistive fluid path. See manual 3A5223 Fluid Ground Bracket Kit.




ti28655a

**FIG. 7. Fluid Connections for Solventborne Type**

## Fluid Lines for Non-Electrostatic Type Applicators




1. Connect the paint supply line to port **P**.
2. Connect the solvent supply line to port **S**. This port is 6 mm (1/4 in.).
3. If needed, connect the fluid dump line to port **D**. If not needed, plug Kit 25C288 is available to plug the dump passage in the applicator.
4. Tighten all three connectors to secure the lines.



ti39571a

**FIG. 8. Fluid Connections for Non-Electrostatic Type**




## Fluid Lines for Waterborne Type Applicators

				
<p>The fluid between the applicator and fluid supply will be charged. To reduce the risk of electric shock, use only Graco-supplied waterborne fluid hoses. See also <b>Step 9. Ground the Equipment</b>, page 39.</p>				


**NOTE:** See **Accessories**, page 87, for a list of available waterborne hoses.

1. Connect the solvent supply line to fluid fitting **S** on the fluid bracket at the rear of the applicator. This port is 6 mm (1/4 in.). The solvent then flows through a coiled fluid tube and into the main housing.
2. Blow out the paint supply hose and fluid dump hose (if used) with air and flush with water before connecting.
3. Pass the paint supply hose through the strain relief fitting (32e) on the fluid bracket and connect to port P on the main housing. Make sure the ferrule (32f) is in place on the outer jacket of the hose and properly oriented. Tighten the strain relief nut (32g).
4. Pass the dump hose through the strain relief fitting on the fluid bracket and connect to port D on the main housing. Tighten the strain relief nut.
5. The applicator end of the waterborne hose comes stripped to the correct dimensions. The shield (W) should pass through the strain relief fitting to minimize electrical stress. The strain relief fitting must be located on the outer jacket (X) of the hose.

Ref.	Shielded		Unshielded	
U	5.75 in.	146 mm	1.5 in.	38 mm
V	1.25 in.	32 mm	N/A	




**Fig. 9. Fluid Connections at the Applicator**



### Air Lines—All Models

A total of nine air line connections are needed. Remember to label each line, and bundle into groups. Pass the air lines through the manifold retaining ring (35), the adapter cover (34), and the shroud (33), then through the center of the rear manifold (30).



ti24815a

**FIG. 10.**

1. Connect the three trigger air lines first – the paint valve trigger (**PT**), the solvent valve trigger (**ST**), and the dump valve trigger (**DT**). These lines are smaller because they provide only an air activation signal. Use 4 mm (5/32 in.) tubing.
2. Next, connect the bearing air return (**BR**), also a 4 mm (5/32 in.) tube.
3. Around the outer edge, connect the larger air supply lines, needed for bell operation. Use 8 mm (5/16 in.) OD tube with 1 mm (0.04 in.) wall to minimize pressure drop.
  - a. Connect the bearing air to port **B**.
  - b. Connect the inner shaping air to port **SI**.
  - c. Connect the outer shaping air to port **SO**.
  - d. Connect the turbine air to port **TA**.
  - e. Connect the braking air to port **BK**.

### Power Supply Cable (for Electrostatic Models)




To avoid potential arcing which could ignite flammable fumes, the power to the Electrostatic Controller must be turned off before disconnecting any cable connection.

Use a tool to tighten cable connections securely.

Connect the 4-pin end of the power supply cable to connector **R** on the applicator.

**NOTE:** An accessory 6 ft. extension power supply cable part number 19B884 can be installed at the applicator. The short cable is quicker to replace in demanding applications.




ti39500a

**FIG. 11. Extension Power Supply Cable**

### Fiber Optic Cable (for optional Speed Controller)

The applicator is equipped with a magnetic pickup sensor assembly that provides a signal used by the Speed Controller. On the applicator manifold, connect a fiber optic cable (**F**) to the F port that connects to the fiber optic extension cable (22). The amount of fiber extending past the nut should be 0.11 in. (2.8 mm). See **Accessories**, page 87, for available cables.

**NOTE:** An alternate reflective speed sensor assembly is available, Kit 24Z183.



**NOTICE**

To avoid equipment damage route all hoses and cables away from sharp edges. Avoid sharp bends and excessive strain on hoses or cables.

### Connect the Fiber Optic Cable on Non-Electrostatic Models

1. Remove the metal nut and ferrule from the main fiber optic cable if present.
2. Loosen the nut on the bulkhead fitting and insert the fiber optic cable until it bottoms out. The cable ends should meet in the middle of the fitting.
3. Tighten the bulkhead nuts to secure the cable.



ti39517a


**FIG. 12. Non-Electrostatic Fiber Optic Bulkhead Connection**

## Connect the Ground Wire

### Ground Wire on Electrostatic Models


See FIG. 13. Connect the ground wire (41) to the applicator manifold.

1. Remove the fluid bracket screw.
2. Pass the screw through the ground wire eyelet and reinstall. It is ok if the eyelet bends.



**FIG. 13. Ground Wire on Electrostatic Model**

**NOTE:** When all lines have been connected at the applicator, reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).




**Tip:** If you have a Graco hose bundle, pull the hose bundle cover over the back of the adapter cover (34). Secure with a cable tie.

### Ground Wire on Non-Electrostatic Models

See FIG. 14. Connect the ground wire (41) to the ground plug (28).

1. Remove the top nut from the ground plug (28).
2. Slide the ground wire eyelet onto the ground plug.
3. Reassemble and tighten the top nut to secure the ground wire.

**NOTE:** When all lines have been connected at the applicator, reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).




**FIG. 14. Ground Wire on Non-Electrostatic Model**


# Connection Schematics

## Main Housing

### Electrostatic Models




### Non-Electrostatic Models



## Fluid Bracket on Electrostatic Models

### Waterborne Models



### Solventborne Models




FIG. 15. Manifold Connections



B	<b>Bearing Air*</b> Provides air for proper air bearing support.
BK	<b>Braking Air*</b> Slows the turbine speed.
BR	<b>Bearing Air Return</b> - 4 mm (5/32 in.) tube fitting. Returns air to the controller for pressure check.
D	<b>Dump Line**</b> - 8 mm (5/16 in.) tube fitting. Waste line for flushing or color change.
DT	<b>Dump Valve Trigger</b> - 4 mm (5/32 in.) tube fitting. Air activation signal for the dump valve.
E	<b>Turbine Exhaust Ports</b>
F	<b>Fiber Optic Speed Sensor Port</b>
P	<b>Paint In**</b> - 8 mm (5/16 in.) tube fitting. Fluid supply inlet fitting

PT	<b>Paint Valve Trigger</b> - 4 mm (5/32 in.) tube fitting. Air activation signal for the paint valve.
R	<b>Power Supply Connection</b>
S	<b>Solvent In**</b> - 6 mm (1/4 in.) tube fitting. Cleaning solvent supply inlet fitting
SI	<b>Shaping Air (Inner)*</b>
SO	<b>Shaping Air (Outer)*</b>
ST	<b>Solvent Valve Trigger (Cup Wash)</b> - 4 mm (5/32 in.) tube fitting. Air activation signal for the solvent valve.
TA	<b>Turbine Air*†</b> Operates the turbine.
Z	<b>Weep Holes</b> Drainage points for any leakage into the air section.

- \* Use 8 mm (5/16 in.) OD tube with 1 mm (0.04 in.) wall to minimize pressure drop.
- \*\* For solventborne models, P, D, and S connections at the main housing are made at the factory.
- † The rotation speed or flow rate of a 50 mm cup may be limited due to pressure drop in the turbine air line. See **Turbine Inlet Air Pressure Charts**, page 96.

### Step 3. Mount Controllers and Accessories

The following components are available to create a complete ProBell Rotary Applicator System. The ProBell controllers have been designed and optimized for use with the ProBell Rotary Applicator. Your system may use all Graco components, or a combination of Graco equipment and other controls.

				
To reduce the risk of fire and explosion, do not install equipment approved only for a non-hazardous location in a hazardous location.				

#### ProBell Electrostatic Controller (Required for Electrostatic Models)

Mount the Electrostatic Controller in the non-hazardous area. See ProBell Electrostatic Controller manual 3A3657 for installation instructions.

#### ProBell System Logic Controller

The rotary applicator system can be controlled with a System Logic Controller or with an existing PLC. A System Logic Controller is required if your system includes a Speed Controller or an Air Controller. Mount the System Logic Controller in the non-hazardous area. See manual 3A3955 for installation instructions.

#### ProBell Speed Controller (Optional)

Mount the Speed Controller in the non-hazardous area, as close to the applicator as possible to minimize pressure loss in the air lines. See manual 3A3953 for installation instructions.

#### ProBell Air Controller (Optional)

Graco offers two Air Controller options: Electronic and Manual. Mount the Air Controller in the non-hazardous area, as close to the applicator as possible to minimize pressure loss in the air lines. See manual 3A3954 for installation instructions and to see features of each air controller.

### Air Filters

<b>NOTICE</b>
Air that is not filtered to specification can clog bearing air passages and cause bearing failure. The warranty does not cover a turbine damaged by contaminated air.

Three air filtration stages are required to prevent contamination of the paint finish and to prevent damage to the air bearing. Refer to Table 1 for the specifications of each filter. Use only these recommended filters, or filters that meet the same specifications. See manual 309919 for filter details, installation, and pipe size recommendations.

- The temperature of the air as it enters the Pre-Filter must be close to ambient.
- Air must be dehydrated to a dew point of 10°F (-12°C).
- Filters must remove 99% of all aerosols.
- Filters must remove particles of 0.5 microns and larger. Graco filter 234403 removes particles down to 0.01 microns.
- Standard piping may be used only up to the pre-filters. All piping after the pre-filters should be brass, stainless steel, or plastic hose.
- Do not use any type of thread sealant or PTFE tape downstream of the bearing air filter. Small particles may loosen and plug the air holes in the turbine air bearings.
- Air that is heated above 120°F (49°C) will damage filter elements.




FIG. 16. Air Filter

Table 1. Required Air Filters

Part Number	Description and Specification	Replacement Element Part Number	Air Inlet and Outlet npt(f)
234402	<b>Stage 1: Pre-Filter (A)</b> 100 SCFM (rated flow of 100 SCFM minimum is required), removes coarse amounts of oil, moisture, and dirt to 3 microns. Use upstream of 234403.	16W405	1/2 in.
234403	<b>Stage 2: Grade 6 Coalescing Filter (B)</b> 50 SCFM (rated flow of 50 SCFM minimum is required), removes oil and submicronic particles down to 0.01 microns. Use one filter for each ProBell Applicator.	16W407	1/2 in.
17M754	<b>In Control Box: Bearing Air Grade 6 Coalescing Filter (C)</b> 4 SCFM (rated flow of 4 SCFM minimum is required). One filter is included in ProBell Speed Controller 24X519 and in ProBell Manual Air Controller 24X520.	Not available. Replace with assembly 17M754	1/4 in. push-lock, (m)

**Air Heaters**

Air heaters may be needed in some applications. If the surface temperature of the applicator falls below the dew point of the paint booth, condensation may form on the inside or outside of the applicator. This condensation is caused by supply air that is too cool, or by the cooling of the shaping and turbine airs as they exit the applicator.

A heater may be required to ensure that the temperature of the turbine exhaust air is above the dew point of the spray booth. Install heaters into the air supply lines (turbine, shaping airs).

Set the heater as low as possible to maintain the applicator surface temperatures above the dew point in the booth.


**NOTE:** The maximum air temperature at the bell must not exceed 120°F (49°C).

## Step 4. Connect Fluid Supply


Connect fluid lines at the applicator first. See **Step 2. Connect All Lines at the Applicator**, page 18.

### Solventborne Electrostatic Systems or Non-Electrostatic Systems.

- a. **Paint Hose:** The fluid hose connected to port **P** on the applicator must be connected to a regulated, filtered paint supply, such as a circulation system or a supply pump. This hose also must be connected to a regulated solvent supply to flush the system and an air supply to empty the lines. This figure shows a common way to make these connections.



- b. **Dump Hose:** The fluid hose connected to port **D** on the applicator must go to a grounded waste container.




- c. **Solvent Hose:** The fluid hose connected to port **S** on the applicator must be connected to a regulated solvent supply that will be used to wash the cup.




This line must also be connected to a regulated air supply to purge the cup wash passages with air.

An air purge is recommended for use with conductive solvents to improve electrostatic performance

**NOTE:** Not purging the lines of conductive solvents may cause low electrostatic voltage or system errors.




## Waterborne Systems


				
<p>The fluid between the applicator and the fluid supply will be charged. To reduce the risk of electric shock, follow hose requirements and instructions carefully.</p>				

a. **General Requirements:** Waterborne isolation systems must meet these requirements:

- Fluid Supply
  - All conductive components of the fluid supply (pump, filter, regulator, container, etc.) that are charged to high voltage must be bonded together.
  - If non-conductive containers are used, a conductive element bonded to the fluid supply must be in contact with the fluid.
- Fluid Hose
  - Use only approved Graco Waterborne fluid hoses.
  - Unshielded waterborne fluid hoses must be routed such that a minimum distance of 0.25 cm/kV is maintained between the hose and grounded surfaces.
  - The conductive layer of shielded hoses must be grounded at the isolation system.
- Enclosure
  - All components of the isolated fluid supply system must be housed in a protective enclosure to prevent contact with the charged components during operation.
  - Access to the enclosure must be interlocked with the high voltage supply to shut off and discharge the high voltage before any live parts can be reached.



b. **Paint Hose:** The fluid hose connected to port **P** on the applicator must be connected to a regulated, filtered paint supply. This hose also must be connected to a regulated solvent supply to flush the system. Connect an air supply to empty the lines, if needed. The illustration below shows a common way to make these connections.




c. **Dump Hose (optional):** The most common system design for the dump line (connected to port **D**) is to connect a waterborne fluid hose to a grounded waste container. Flush and purge the dump line with air before turning on the electrostatics.

A second dump option is to place the waste container in the voltage isolation enclosure. Connect a Graco Waterborne Fluid Hose between the voltage isolation system fluid outlet and the applicator dump port (**D**).

d. **Solvent Hose:** The fluid hose connected to port **S** on the applicator must be connected to a regulated solvent supply that will be used to wash the cup. This line must also be connected to a regulated air supply to purge the cup wash passages with air. An air purge is required for very conductive waterborne fluids.

**NOTE:** Not purging the lines will cause low electrostatic voltage or system errors.


An isolated solvent kit 25N021 is also available for waterborne systems that have the solvent supply inside the isolation system.



e. **Hose-Stripping Requirements**

Hose-Stripping Requirements				
Ref.	Shielded		Unshielded	
U	14.5 in.	368 mm	14.5 in.	368 mm
V	0.75 in.	19 mm	NA	

- An unshielded hose consists of a PTFE tube (Y) with an outer covering (X).



**FIG. 17. Unshielded Hose**

Connect one end of the hose to the applicator.


Connect the other end to a fluid supply inside an isolation enclosure.

Route unshielded hoses away from grounded objects. Maintain a distance of 0.25cm/kV between the hose and grounded objects.

- A shielded hose consists of an inner PTFE tube (Y), a conductive layer covering the PTFE tube (W), and an outer cover (X).

If a hose failure occurs where high voltage arcs through the inner tube, voltage will be discharged to ground through the conductive hose layer. When properly installed, the conductive hose layer is grounded through its connection to the grounded enclosure.

The fluid supply end of the hose has been stripped at the factory for connection to a WB100 Isolation System, as shown below. If desired, the hose can be changed on this end, but the conductive layer (W) must be no closer than 8 in. (20.3 cm) to the end of the hose or any other high-voltage component.



ti29270a

**FIG. 18. Shielded Hose**

**NOTICE**

Be careful not to cut into the inner tube (Y) of the hose when stripping the hose. Nicks or cuts in the PTFE tube will cause premature hose failure.


**NOTE:** Blow out the fluid supply hose and circulation hose (if used) with air and flush with water before connecting.

- Connect the fluid hose(s) as follows:

<p>To reduce the risk of electric shock, the areas of the Graco Waterborne Fluid Hose that are accessible to personnel during normal operation must be covered by the outer hose jacket (X). The portion of the inner PTFE tube (Y) not covered by the outer jacket (X) must be inside the isolation enclosure (T). The conductive hose layer (W) must be grounded at the isolation enclosure (T).</p>				


1. Pass the Graco waterborne fluid hose through a strain relief fitting at the wall of the isolated enclosure and connect the inner tube (Y) to the fluid supply outlet. Tighten the strain relief fitting (Z). For a shielded hose, the conductive layer of the hose (W) must be grounded to the isolation system ground (strain relief fit-

tings must grab onto the outer jacket or conductive layer of the fluid hose).



ti28657a

2. Using an ohmmeter, verify continuity between the conductive layer closest to the applicator and the isolation enclosure ground.
3. Connect the dump hose (D) to a grounded or isolated waste container. Connect the waterborne hose as in step 1.



ti29272a

## Step 5. Connect the Air Lines

Connect all air lines to the applicator first (see **Step 2. Connect All Lines at the Applicator**, page 18). The air supply for each line can be regulated and actuated using the ProBell Speed Controller and/or one of the ProBell Air Controllers (see **Table 2: Air Line Connections Availability by Controller Type**, page 35). Spray parameters can be adjusted independently or saved as presets. ProBell controllers are labeled with the same reference letters as the applicator, for easier matching (see FIG. 20. or FIG. 21., page 34 for more detail). See the following sections for connection information.

If your system is not using all of the ProBell controllers, see the following sections for specifications and requirements for each air line.

### NOTICE

Take great care to connect the air lines to the correct ports on the control equipment. Incorrect air line connections will damage the applicator.

## Bearing Air


### NOTICE

To avoid equipment damage

- bearing air must be on while the turbine is spinning and must not be turned off until the cup comes to a complete stop.
- bearing air must be filtered to precise requirements. See **Air Filters**, page 26.

The bearing air provides proper bearing support. Connect the bearing air line to the port marked **B** on either the Speed Controller or the Manual Air Controller if only one controller is present in the system. If both Speed Controller and Manual Air Controller are present, the connection must be made to the Speed Controller.

To provide additional protection for the bearing if the bearing air is turned off before the bell cup comes to a complete stop, install an air accumulator tank (AT) and a check valve (CV) in the bearing air line. The accumulator tank (AT) should be 3 gallons (11 liters) or greater.



**FIG. 19. Bearing Air Line with Accumulator Tank and Check Valve**

Bearing air requires at least 70 psi (0.48 MPa, 4.8 bar) pressure at the applicator at all times. A flow volume of 3 scfm is required.

### NOTICE

For best performance, maintain 100 psi bearing air pressure. Bearing air pressure of less than 90 psi (0.62 MPa, 6.2 bar) increases the potential for turbine failure when running at speeds greater than 50 krpm.

## Bearing Air Return

### NOTICE

Use of a bearing air return line will help prevent equipment damage.

The bearing air return line is connected to a pressure monitoring device, to ensure that adequate bearing air pressure is maintained. Connect the bearing air return line to the port marked **BR** on either the ProBell Speed Controller or the ProBell Manual Air Controller if only one controller is present in the system. If both Speed Controller and Manual Air Controller are present, the connection must be made to the Speed Controller.

If your system does not use the ProBell System Logic Controller, bearing air return must be interlocked with the turbine air so that the turbine air will not flow if the bearing air return pressure is under 70 psi (0.48 MPa, 4.8 bar).

**NOTE:** While not advisable, if you choose not to use the bearing air return line, plug the bearing air return port (BR) on the applicator.



## Turbine Air

NOTICE
Turbine air supplies must be regulated and adjusted to the right pressure before use. Excess air flow will over speed the turbine and will result in equipment damage.



The turbine air rotates the cup. Connect the turbine air line to the port marked **TA** on either the Speed Controller or the Manual Air Controller if only one controller is present in the system. If both Speed Controller and Manual Air Controller are present, the connection must be made to the Speed Controller.

For speed adjustment using a pressure regulator, see the **Turbine Inlet Air Pressure Charts** on page 96 for typical air requirements for a given bell speed.

If your system does not use the ProBell System Logic Controller, interlock the turbine air with either the bearing air or the bearing return air, to ensure that the turbine air will flow only if the bearing air pressure is at least 70 psi (0.48 MPa, 4.8 bar).

If your system does not use the ProBell System Logic Controller, interlock the turbine air with the brake air so they cannot flow at the same time.

## Braking Air

				
To avoid injury, avoid excessive braking air. A cup that is not fully seated may disengage from the shaft.				

The braking air slows the turbine speed. Connect the braking air line to the port marked **BK** on the Speed Controller. The speed controller automatically engages the braking air as needed.

For manual air braking applications, apply 20 psi (0.14 MPa, 1.4 bar) air for approximately 5 seconds. This pressure will slow the bell speed rapidly. Adjust the air pressure and time as needed for your system to stop cup rotation.

NOTICE
To prevent equipment damage, do not leave braking air on long enough to rotate the turbine in reverse.

If your system does not use the ProBell System Logic Controller, interlock the turbine air with the brake air so they cannot flow at the same time.

## Shaping Airs

The inner and outer shaping airs provide pattern control and keep the material particles moving toward the object being sprayed. Connect the inner shaping air line to the port marked **SI** on the Air Controller. Connect the outer shaping air line to the port marked **SO** on the Air Controller.

See the **Shaping Air Consumption Charts**, page 98, for volume requirements. Use filtered, dry air for the best finish quality.

Maintain an inner and outer shaping air pressure of at least 10 psi (0.07 MPa, 0.7 bar) at all times to help keep the bell clean. Use both inner and outer shaping air for optimal air control. Adjust the pressures to achieve the best pattern size and velocity for your application.

## Paint Valve Trigger

The paint valve trigger provides an air activation signal for the paint valve. Actuate the paint trigger each time a part is sprayed. The acceptable pressure range is 70-100 psi (0.48-0.69 MPa, 4.8-6.9 bar). Connect the paint valve trigger air line to the port marked **PT** on the Air Controller.

Interlock the paint trigger with the turbine air so the paint valve will not open to spray unless at the turbine speed is at least 10,000 rpm. The rotation is required to prevent fluid from flooding the turbine area.

Interlock the paint trigger with the conveyor, so the paint valve will open to spray only when the conveyor is moving.

See ProBell Air Controller manual 3A3954 for options to create these interlocks.

## Paint Trigger Input


The paint trigger input is included on the ProBell Air Controller (both manual and electronic models). This isolated input can be used to trigger the paint valve on a ProBell system from a PLC or robot. See the System Logic Controller manual (3A3955) to configure how the paint is triggered in a ProBell system. See the ProBell Air Controller manual (3A3954) to connect the paint trigger input.

### Solvent Valve Trigger (Cup Wash)

The solvent valve trigger provides an air activation signal for the solvent valve and is used to perform a cup wash. Connect the solvent valve trigger air line to the port marked **ST** on the Air Controller.

Interlock the solvent trigger with the turbine air so that the solvent valve will not open to spray unless the turbine speed is at least 10,000 rpm. The rotation is required to prevent fluid from flooding the turbine area.

Interlock the solvent trigger with the electrostatics so that the solvent valve will open to flow only if the electrostatics are turned off and discharged.




### Dump Valve Trigger


The dump valve trigger provides an air activation signal for the dump valve. The dump valve is used to purge the paint line. Connect the dump valve trigger air line to the port marked **DT** on the Air Controller.

### Auxiliary Ports

Three auxiliary ports are provided on the Graco Air Controllers for other customized system needs. The user might use one to trigger a valve, for example, or to connect a shutoff signal to stop the conveyor system.












**FIG. 20. Air Connections, Electronic Air Controller with Speed Controller**



**FIG. 21. Air Connections, Manual Air Controller**

**Table 2: Air Line Connections Availability by Controller Type**

Air Line		Speed Controller Connections	Electronic Air Controller Connections	Manual Air Controller Connections
B (Bearing Air)		✓		✓
BK (Braking Air)		✓		
BR (Bearing Air Return)		✓		✓
DT (Dump Valve Trigger)			✓	✓
PT (Paint Valve Trigger)			✓	✓
SI (Shaping Air Inner)			✓	✓
SO (Shaping Air Outer)			✓	✓
ST (Solvent Trigger)			✓	✓
TA (Turbine Air)		✓		✓
Auxiliary Triggers	1, 2, 3,		✓	✓

## Step 6. Connect Power and Communication Cables


### Electrostatic Controller

1. Connect the 7-pin side of the power supply cable to connector R on the Electrostatic Controller.
2. Make Interlock connections. See Electrostatic Controller manual 3A3657 for details.
  - Solvent supply
  - Spray area doors and openings
  - Conveyor
  - Ventilation fans
  - Fire control system
  - Fluid supply
  - Waterborne isolation system
3. Integrate the electrostatics. Integration of the electrostatic enable function typically depends on a part detection system. Two options are common:
  - Use the electrostatic enable digital input on the Discrete I/O interface of the ProBell Electrostatic Controller. Connect per controller manual 3A3657.
  - Provide a command from an external controller to the ProBell System Logic Controller to set the electrostatic enable register via a communication network. See manual 3A3955.

### Speed Controller

Connect the fiber optic cable to port **F** on the applicator and to port **F** on your Speed Controller. The amount of fiber extending past the nut should be 0.440 in. (11.2 mm) on the Speed Controller side. On the applicator side, the amount of extended fiber is 0.11 in. (2.8 mm). If you need to cut or repair the cable, use the tool included with the cable to cut.

Speed Controller End  
0.440 in. (11.2 mm)



### Available Fiber Optic Cables

Part Number	Length
24Z190	36 ft. (11 m)
24Z191	66 ft. (20 m)
24Z192	99 ft. (30 m)

**NOTE:** An alternate reflective speed sensing kit is available, Kit 24Z183. The kit includes instructions for conversion and installation.


See **Fiber Optic Bulkhead Installation**, page 88 for more information.

### System CAN Communication Cables

System components communicate information via CAN cables. No CAN cables connect to the applicator. But, several are needed to interconnect other system components.

Use CAN cables to network the Electrostatic Controller, Air Controller, Speed Controller, and the System Logic Controller (if used) in series, as shown in FIG. 21. One power supply is required in the CAN network, typically mounted on the speed controller. See **Accessories**, page 87, for a list of available CAN cables.

To connect the ProBell system to an outside communication network, purchase and install a gateway (see 3A4384 CGM Installation Kit 24Z574) and configure per the System Logic Controller manual 3A3955.



**FIG. 22. Power and Communication Cable Connections**

**KEY**

- C Air Controller
- F Fiber Optic Port
- G Speed Controller
- H Electrostatic Controller
- J System Logic Controller
- N CAN Ports
- R Applicator Power Supply Connector Port

## Step 7. Prepare the Spray Area

### Mount Warning Signs

Mount warning signs in the spray area where they can easily be seen and read by all operators. An English Warning Sign is provided with the rotary applicator.

### Ventilate the Spray Booth



Do not operate the applicator unless ventilation fans are operating. Provide fresh air ventilation to avoid the buildup of flammable or toxic vapors when spraying, flushing, or cleaning the applicator. Interlock the Electrostatic Controller and fluid supply to prevent operation unless ventilating air flow is above the minimum required value.

Electrically interlock the Electrostatic Controller and fluid supply with the ventilators so that the electrostatics turn off any time that the ventilation air flow falls below minimum values. Check and follow all National, State, and Local codes regarding air exhaust velocity requirements. Verify the operation of the interlock at least once per year.

**NOTE:** High-velocity air exhaust will decrease the operating efficiency of the electrostatic system. The minimum allowable air exhaust velocity is 60 ft/minute (19 linear meters/minute).

## Step 8. Create Required System Interlocks



To help prevent fire, explosion, or electric shock, check and follow all National, State, and Local codes regarding properly interlocking your spray system.

### NOTICE

To avoid damage to the bearing it is recommended that the bearing air remain on at all times.

The following system interlocks are needed to prevent fire, explosion, electric shock, or equipment damage.

**Turbine air and bearing air:** Interlock so the turbine air will flow only if the air pressure on the bearing air return line is at 70 psi (483 kPa) or higher. This interlock is included in the ProBell System Logic Controller. Bearing air must be on when the turbine is operating. Bearing air should be turned off only at the main air source and only after the cup has stopped spinning.

4. **Paint trigger and turbine air:** Interlock so the rotary applicator will spray only when the turbine is spinning. A minimum of 10K rpm is recommended. This interlock is included in the ProBell System Logic Controller.
5. **Electrostatic Controller and solvent supply:** Interlock so that electrostatics can be enabled only when solvent is not flowing in the solvent or paint lines. See Electrostatic Controller manual 3A3657 for available interlocks.
6. **Fluid supply and arc detection:** Interlock the fluid supply to shut off in the event of an arc detection fault.
7. **Braking air and turbine air:** Interlock so the braking air flows only when the turbine air is off.
8. **Electrostatic Controller and all doors or openings in the spray area:** Interlock so the electrostatics turn off and are fully discharged before live parts can be reached. See Electrostatic Controller manual 3A3657. Check interlock function weekly.
9. **Conveyor and paint trigger/electrostatics:** Interlock so the rotary applicator stops spraying and the electrostatics turn off if the conveyor stops moving.

10. **Electrostatic Controller, fluid supply, and ventilation fans:** Interlock so the electrostatics and fluid supply turn off any time that the ventilation air flow falls below minimum required value. See Electrostatic Controller manual 3A3657.
11. **Electrostatic Controller, fluid supply, and fire control system:** Interlock so the electrostatics and fluid supply turn off any time the automatic fire extinguishing system is activated. See Electrostatic Controller manual 3A3657. Check interlock function every 6 months.
12. **Electrostatic Controller and waterborne isolation system (for waterborne systems):** Interlock so the electrostatics turn off and are fully discharged before live parts can be reached. See Electrostatic Controller manual 3A3657. Check interlock function weekly.


## System Status Output

A system status output is included in the ProBell Speed Controller. This output indicates when the ProBell system is in Off Mode, such as when an alarm occurs. The output can be used to interlock system functions with functions that are not controlled by the ProBell system. For example: If the paint trigger is outside the ProBell system, the paint trigger can be interlocked with the system status output to ensure that the paint flow is stopped in the event of a system alarm. See the ProBell Speed Controller manual 3A3953 to connect the system status output.

## Optional Interlock Input

An optional interlock input for the ProBell System Logic Controller can be installed in the ProBell Speed Controller or the ProBell Air Controller. When 24 VDC is applied to this input, the system goes to Off Mode. Install Kit 24Z226. See speed controller manual 3A3953 or air controller manual 3A3954.

## Step 9. Ground the Equipment






The equipment must be grounded to reduce the risk of static sparking and electric shock. Electric or static sparking can cause fumes to ignite or explode. Improper grounding can cause electric shock. Grounding provides an escape wire for the electric current.

When operating the rotary applicator, any ungrounded objects in the spray location (people, containers, tools, etc.) can become electrically charged. Your system may include other equipment or objects which must be grounded. Your system must be connected to a true earth ground. Check ground connections daily. Check your local electrical code for detailed grounding instructions. The following are minimum grounding requirements for a basic electrostatic system.

- **Rotary Applicator:** Ground the applicator by connecting a ground wire from the applicator to a true earth ground. Also ground electrostatic applicators by connecting the power supply cable to a properly grounded Electrostatic Controller. The ground wire may be connected to the grounding lug on the Electrostatic Controller or stand and then connected to a true earth ground.
- **Control Box Stand:** The stand is grounded by connection to the Electrostatic Controller bracket. For Non-Electrostatic systems, use the ground wire and clamp provided to connect the stand to a true earth ground.
- **Air Controller and Speed Controller:** If not mounted on the Control Box Stand, use a ground wire and clamp to ground to a true earth ground.
- **Electrostatic Controller:** Use the ground wire and clamp provided to connect the Electrostatic Controller to a true earth ground.
- **Pump:** Ground the pump by connecting a ground wire and clamp as described in your separate pump instruction manual.
- **Voltage Isolation System (for waterborne systems):** Follow the grounding procedure in the manufacturer's instructions.
- **Fluid Hose (for waterborne systems only):** The hose is grounded through the conductive layer. Install the hose as instructed, page 29.


- **Air compressors and hydraulic power supplies:** Ground the equipment according to the manufacturer's recommendations.
- **All air and fluid lines** must be properly grounded.
- **All electrical cables** must be properly grounded.
- **All persons entering the spray area** must wear shoes having conductive or dissipative soles, such as leather, or wear personal grounding straps. Do not wear shoes with non-conductive soles such as rubber or plastic. If gloves are necessary, wear the conductive gloves supplied with the gun. If non-Graco gloves are worn, cut off fingers or palm area of gloves to ensure your hand contacts the grounded gun handle. The measured insulation resistance of gloves and footwear must not exceed 100 megohm per EN ISO 20344, EN1149-5.
- **Object being sprayed:** Keep the workpiece hangers clean and grounded at all times. Resistance must not exceed 1 megohm.
- **The floor of the spray area:** must be electrically conductive and grounded. Do not cover the floor with cardboard or any non-conductive material which would interrupt grounding continuity.
- **Flammable liquids in the spray area:** must be kept in approved, grounded containers. Do not use plastic containers. Do not store more than the quantity needed for one shift.
- **All electrically conductive objects or devices in the spray area:** including fluid containers and wash cans, must be properly grounded.

## Check Electrical Grounding

				
<p>Megohm meter Part No. 241079 is not approved for use in a hazardous area. To reduce the risk of sparking, do not use the megohm meter to check electrical grounding unless:</p> <ul style="list-style-type: none"><li>• The rotary applicator has been removed from the hazardous area;</li><li>• Or all spraying devices in the hazardous area are turned off, ventilation fans in the hazardous area are operating, and there are no flammable vapors in the area (such as open solvent containers or fumes from spraying).</li></ul> <p>Failure to follow this warning could cause fire, explosion, and electric shock and result in serious injury and property damage.</p>				

Check ground connections daily.





ti28964b

**FIG. 23. Grounding the System**

## System Logic Controller Setup

After installation, the following setup steps are required before Operation.

1. Use the Setup Screens on the System Logic Controller to set the following operating parameters. Detailed instructions are in the System Logic Controller manual 3A3955.
  - Set the number of guns, type of guns, type of signal, idle timer and idle speed. See System Screen and Gun Screen 1.
  - Enable or disable and configure the Air Controller, See Gun Screen 2.
  - Set up the auxiliary solenoids on the Air Controller. See Gun Screen 3.
  - Enable or disable and configure Speed Controller gun screen. See Gun Screen 4.
  - Enable or disable and configure the Electrostatic Controller. See Gun Screen 5.
  - Configure spray parameters for all recipes using Presets 0 through 98. See Preset Screens.

- Provide all information needed for the Gateway to enable communication via DeviceNet, Ethernet IP, Modbus TCP or PROFINET. See Gateway screens.
  - Set language, date format, date, time, units, and other personal preferences. See Advanced Screens.
2. Use the Setup screens and the Configuration screens on the Electrostatic Controller to set up your system electrostatics. This setup is saved in the equipment memory, even when power is removed. All instructions are in the Electrostatic Controller manual 3A3657.

**NOTE:** If you are using a PLC with only the Electrostatic Controller, see the Discrete I/O section in the Electrostatic Controller manual 3A3657.

## Verification

After all installation steps are complete, and the System Logic Controller is configured, the system is ready for start up. Prior to running production, a knowledgeable person should check the functions shown in the table. This verification should be repeated on a regular basis.

Test	Requirement	Frequency
1. Proper Grounding	Verify proper grounding. See <b>Step 9. Ground the Equipment</b> , page 39.	Daily
2. Proper Clearance	Verify proper clearance is maintained between the cup and parts. See <b>Distance to Workpiece</b> , page 17.	Weekly
3. Arc Detection	Verify the function of the arc detection circuitry. See the arc detection information in the Electrostatic Controller manual 3A3657.	Every 6 months and any time system parameters are changed
4. Interlock with Ventilation	Verify proper operation of the interlock with the ventilation system. See <b>Step 8. Create Required System Interlocks</b> , page 38.	Every 6 months
5. Voltage Discharge	Follow the <b>Voltage Discharge and Grounding Procedure</b> , page 48. Verify that access to the applicator (and the isolation system for waterborne) is prohibited until the discharge timer has elapsed and no residual voltage remains.	Each cleaning
6. Waterborne System Requirements	Verify the fluid supply system meets the requirements on <b>Step 4. Connect Fluid Supply</b> , page 28, and verify the interlock between the enclosure access and the high voltage controller.	Weekly
7. Interlocks with Fluid	Verify the proper operation of the interlocks with the solvent supply and fluid supply. See <b>Step 8. Create Required System Interlocks</b> , page 38.	Weekly
8. Fire Suppression	Verify the proper operation of the interlock with the fire suppression system. See <b>Step 8. Create Required System Interlocks</b> , page 38.	Every 6 months

# Operation

## Pre-Operation Checklist

Go through the Pre-Operation Checklist daily, before each use.

### All System Types

- All operators are properly trained to safely operate an automatic electrostatic rotary applicator system as instructed in this manual.
- All operators are trained in the **Pressure Relief Procedure** on page 47.
- The warning sign provided with the rotary applicator is mounted in the spray area where it can be easily seen and read by all operators.
- The system is thoroughly grounded and the operator and all persons entering the spray area are properly grounded. See **Step 9. Ground the Equipment** on page 39.
- The rotary applicator's mechanical and electrical components are in good condition.
- Ventilation fans are operating properly.
- Workpiece hangers are clean and grounded.
- All debris is removed from the spray area, including flammable fluids and rags.
- All flammable fluids in the spray booth are in approved, grounded containers.
- All conductive objects in the spray area are electrically grounded, and the floor of the spray area is electrically conductive and grounded.
- Applicator and hose connections show no signs of fluid leakage.
- All Setup is complete.

- Electrostatics are off and voltage is discharged according to **Voltage Discharge and Grounding Procedure**, page 48, before entering the spray area for any cleaning or maintenance work.

### Waterborne Systems Only

- Electrostatics are off and voltage is discharged according to **Voltage Discharge and Grounding Procedure**, page 48, before any person enters the isolation enclosure, before cleaning, and before performing any maintenance or repair.
- The Graco Waterborne Fluid Hoses (shielded or unshielded) are in good condition with no cuts or abrasions of the PTFE tube. Replace fluid hose if damaged.
- All fluids used meet one of the following flammability requirements:
  - Material does not sustain burning in accordance with the Standard Test Method for Sustained Burning of Liquid Mixtures, ASTM D4206.
  - Material is classified as non-ignitable or hard to ignite as defined by EN 50176. See **Ignitability of Coating Materials** on page 105 for definitions.

## Check Fluid Resistivity

<p>Check the fluid resistivity in a non-hazardous area only. Resistance Meter 722886 and Probe 722860 are not approved for use in a hazardous area. Failure to follow this warning could cause fire, explosion, and electric shock and result in serious injury and property damage.</p>				

Graco Part Number 722886 Resistance Meter and 722860 Probe are available as accessories to check that the resistivity of the fluid being sprayed meets the requirements of an electrostatic air spray system.

Follow the instructions included with the meter and probe. Readings of 20 megohms-cm and above provide the best electrostatic results and are recommended.

Megohms-cm			
1-7	7-20	20-200	200-2000
Longer fluid hose may be needed*	Good	Best electrostatic results	Good electrostatic results

\* Included in Kit 25A878.

## Check Fluid Viscosity

To check fluid viscosity you will need a viscosity cup and stopwatch.

1. Completely submerge the viscosity cup in the fluid. Lift the cup out quickly. Start the stopwatch as soon as the cup is completely removed.
2. Watch the stream of fluid coming from the bottom of the cup. As soon as there is a break in the stream, shut off the stopwatch.
3. Record the fluid type, elapsed time, and size of the viscosity cup.
4. Compare to the chart supplied by viscosity cup manufacturer to determine your fluid viscosity.
5. If the viscosity is too high or too low, contact the material supplier. Adjust as necessary. See **Fluid Flow Rate Charts**, page 100 to select the appropriate nozzle size.

## Spray Procedures

<p>To reduce the risk of electric shock and to avoid injury due to contact with the spinning cup, do not enter the spray area during rotary applicator operation.</p>				

<p>If any fluid leakage from the rotary applicator is detected, stop spraying immediately. Fluid leakage into the shroud could cause fire or explosion and result in serious injury and property damage.</p>				

### Flush Before First Use

The equipment was tested in fluid at the factory. To avoid contaminating your fluid, flush the equipment with a compatible solvent before using the equipment. See **Flushing Procedure**, page 46.

### Load Material

1. Put the system in Purge mode. In this mode:
  - a. Ensure that electrostatics cannot be enabled.
  - b. The bell should be rotating at least 10k rpm.
  - c. The Inner Shaping Air should be a minimum of 10 psi (0.7 bar) to help keep the applicator clean.
2. Supply paint to the paint line P.
3. Actuate the dump valve trigger (DT) until paint reaches the applicator. Actuate the paint valve trigger (PT) to load the paint to the front of the applicator.

**NOTE:** With this method, paint is returned through the dump line, rather than exiting out the front of the applicator. Paint remains in the dump line until the system is flushed. If your material has a low pot life, actuate the paint valve trigger (PT) to load paint.

4. Follow the **Cup Wash** procedure, page 46.

## Check Flow Rate

These instructions begin with material loaded.

1. Follow the **Cup Wash** procedure, page 46.
2. Put the system in Maintenance Mode. In this mode:
  - The electrostatics are off.
  - The shaping air is off.
  - The turbine air is off (not rotating).
  - The bearing air may remain on.
3. Remove cup and air cap. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.
4. Actuate the paint valve trigger (PT).
5. Measure the flow into a container. Use a stop watch to measure the time. Calculate the flow rate.
6. To increase the flow rate:
  - Increase the regulated fluid pressure of the material.
  - Increase the size of the fluid nozzle.
  - Reduce the viscosity of the material.
  - Use a larger diameter fluid hose up to the bell.

To decrease the flow rate:

  - Reduce the regulated fluid pressure of the material.
  - Reduce the size of the fluid nozzle.
7. Reinstall the cup and air cap. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.

## Adjust the Spray Pattern

1. Put the system in Spray mode.
2. Select Preset 0 so the spray parameters can be independently adjusted.
3. Adjust the atomization:
  - a. Set the inner shaping air (SI) and outer shaping air (SO) to at least 10 psi (0.7 bar) at the bell to keep the bell clean.
  - b. Set the speed to 25K rpm.
  - c. If your system does not have a speed controller, start with the turbine air (TA) set at 0 and increase very slowly. Make sure not to over speed the turbine. See **Turbine Inlet Air Pres-**

**sure Charts**, page 96, for the required pressure to achieve a given speed.

- d. Actuate the paint valve trigger (PT).
  - e. Increase the speed (or increase the turbine air pressure slowly) for finer atomization.
  - f. Decrease the speed (or decrease the turbine air pressure slowly) for coarser atomization.
- NOTE:** Speed can be changed with the applicator triggered or not triggered.
4. Adjust the pattern size:
    - a. Start with 20 psi (1.4 bar) on both the inner and outer shaping airs (SI and SO).
    - b. Increasing the outer shaping air (SO) will reduce the pattern size and increase the pattern velocity.
    - c. Increasing the inner shaping air (SI) will increase the pattern size.
  5. Adjust the electrostatics (where applicable):
    - a. Start with the maximum settings (100 kV, 150  $\mu$ A for Solventborne models; 60kV, 150  $\mu$ A for Waterborne models).
    - b. Decrease the voltage if test parts show evidence of thick edges or poorly covered recess areas (the Faraday effect).
    - c. Increase the voltage for improved wrap.
  6. Follow the **Cup Wash** procedure, page 46.

## Spray a Part

1. Put the system in Spray mode. In this mode:
  - a. Inner and outer shaping airs (SI and SO) are on.
  - b. The turbine is spinning at the desired speed.
2. Position a part, or position the applicator, for material application.
3. Turn on the electrostatics if used. The Safe Position input and other required interlocks must be satisfied.
4. Actuate the paint valve trigger (PT) until desired coverage is achieved.

**NOTE:** Excessive paint may wrap back toward the applicator if the applicator is sprayed without a target present and electrostatics on.

5. When finished, turn off the paint valve trigger first.
6. Turn off the electrostatics if used.
7. **Short Breaks:** Leave the shaping airs on and the turbine at speed.

**Longer Breaks:** Follow the **Cup Wash** procedure, page 46. Put the system in Idle mode, which reduces the turbine speed and shaping airs to conserve energy.

## Cup Wash

Follow this cup wash procedure whenever you are done spraying parts, and as needed between parts depending on the material being sprayed and the rate of build-up. Some materials will require frequent cup washing.

1. Put the system in Purge mode. In this mode:
  - a. Ensure that electrostatics cannot be enabled.
  - b. The bell should be rotating at least 10k rpm.
  - c. The inner shaping air (SI) should be a minimum of 10 psi (0.7 bar) to help keep the applicator clean.
2. Activate the solvent valve trigger (ST).
3. Use air to purge the solvent.

- a. Provide air to the solvent line S.
- b. Actuate the solvent valve trigger (ST) to purge the cup wash solvent.

## Flushing Procedure



To avoid fire, explosion, and electric shock:

- Always turn off the electrostatics and discharge voltage when flushing, cleaning, or servicing equipment.
  - Always ground the equipment and waste container.
  - Flush the equipment only in a well-ventilated area.
  - Use only Group IIA materials. Non-ignitable fluids are preferred.
  - To avoid static sparking and injury from splashing, always flush at the lowest possible pressure.
- Flush before changing fluids, before fluid can dry in the equipment, at the end of the day, before storing, and before repairing equipment.
  - Flush at the lowest pressure possible. Check connectors for leaks and tighten as necessary.
  - Flush with a fluid that is compatible with the fluid being dispensed and the equipment's wetted parts.

### NOTICE

Use the lowest practical solvent pressure to perform flushing and cup wash procedures. Excessive solvent flow can cause fluid to flood the turbine and damage it.

1. Put the system in Purge mode. In this mode:
  - a. Ensure that electrostatics cannot be enabled.
  - b. The bell should be rotating at least 10k rpm.
  - c. The inner shaping air (SI) should be a minimum of 10 psi (0.7 bar) to help keep the applicator clean.

2. Provide solvent to the paint line P.
3. Actuate the dump valve trigger (DT) to flush the lines to the applicator. Close the dump valve when clear solvent exits the dump line. (Actuate the Paint trigger if the dump valve is not being used.)
4. Actuate the paint trigger (PT) to flush the fluid tube and nozzle.
5. Actuate the solvent valve trigger (ST) to wash the cup.

**NOTE:** If you need to **purge all solvent**, proceed with Step 6.

6. Use air to purge the solvent.
  - a. Provide air to the paint line P.
  - b. Actuate the dump valve trigger (DT) to purge the lines.
  - c. Actuate the paint valve trigger (PT) to purge the applicator.
  - d. Provide air to the solvent line S.
  - e. Actuate the solvent valve trigger (ST) to purge the cup wash solvent.

## Pressure Relief Procedure



Follow the Pressure Relief Procedure whenever you see this symbol.



This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as splashing fluid and moving parts, follow the **Pressure Relief Procedure** when you stop spraying and before cleaning, checking, or servicing the equipment.

Follow these basic steps in the order shown to relieve the system pressure. The exact procedure to accomplish each step may vary based on your system design. Be certain that all steps are completed.

**NOTE:** Turn off the main air supply (bearing air) only after the cup has stopped spinning.

### Electrostatic Systems




1. **Turn off the electrostatics.**  
Complete Step 1 of the **Voltage Discharge and Grounding Procedure**.
2. **Shut off the fluid and solvent supply.**
3. **Relieve the paint pressure.**  
Actuate the dump valve trigger (DT) to relieve pressure in the paint and dump lines. If your system does not have a dump valve, actuate the paint valve trigger (PT).
4. **Relieve solvent pressure.**  
Actuate the solvent valve trigger (ST) to relieve pressure in the solvent line.
5. **Turn off the turbine air and the shaping airs.**  
Put the system in Off mode.
6. **After the bell has stopped spinning, turn off the main air supply.**
7. **Disable the electrostatics and verify the voltage has been discharged.**  
Complete Steps 2-4 of the **Voltage Discharge and Grounding Procedure**.



## Non-Electrostatic Systems

1. **Shut off the fluid and solvent supply.**
2. **Relieve the paint pressure.**  
Actuate the dump valve trigger (DT) to relieve pressure in the paint and dump lines. If your system does not have a dump valve, actuate the paint valve trigger (PT).
3. **Relieve solvent pressure.**  
Actuate the solvent valve trigger (ST) to relieve pressure in the solvent line.
4. **Turn off the turbine air and the shaping airs.**  
Put the system in Off mode.
5. **After the bell has stopped spinning, turn off the main air supply.**


## Voltage Discharge and Grounding Procedure

**NOTE:** The Voltage Discharge and Grounding Procedure applies to all systems where electrostatics are used. It does not apply to Non-Electrostatic Systems.

			
<p>The system is charged with high voltage until the voltage is discharged. Contact with the charged components of the applicator will cause an electric shock. For Waterborne systems, contact with the charge fluid supply system also will cause an electric shock. To avoid an electric shock, follow this procedure</p> <ul style="list-style-type: none"> <li>• before entering the spray area</li> <li>• whenever you are instructed to discharge the voltage</li> <li>• before cleaning or servicing the system equipment</li> <li>• before opening the isolation enclosure for the isolated fluid supply.</li> </ul>			

			
<p>To avoid fire or explosion during the test, all spraying devices in the hazardous area must be turned off and ventilation fans in the hazardous area must be operating. Conduct the test only when no flammable vapors are present in the area (such as open solvent containers or fumes from spraying).</p>			

**NOTE:** An accessory grounding rod, part No. 210084, is available to discharge any voltage remaining on a system component.

1. Turn off the electrostatics by pressing  on the Electrostatic Controller, by using an Electrostatic Enable I/O signal, or by using CAN communication. Switching to Purge mode also will shut off the electrostatics. Wait the amount of time set for your system to discharge.





To avoid fire or explosion or electric shock, always wait for the full discharge time to elapse. Once the electrostatics are turned off, the display no longer tracks or displays the actual voltage. Do not use the controller display to determine if the system is discharged.

**NOTE:** The procedure to set the discharge timer is found in the directions for Setup Screen 10 in the Electrostatic Controller manual (3A3657).

2. Put the system in Off mode.
3. Disable the electrostatics by powering off the Electrostatic Controller (set  on  off to off). **NOTE:** Electrostatics also can be disabled by removing an interlock, if preferred. An error will occur. When the procedure is finished, clear error to restart.
4. Verify that the system has discharged.
  - a. **For solventborne systems:** Touch the air cap cover (19) with a grounded rod to make sure the voltage has been discharged. If you see an arc, verify that the electrostatics are turned off. Increase the discharge time, or see **Electrical Troubleshooting**, page 60. The default discharge time is 5 seconds. Resolve the problem before proceeding.
  - b. **For waterborne systems:** Discharge the voltage at the voltage isolation system by following the procedure specified in the voltage isolation system instruction manual. Touch the pump, supply pail, and applicator air cap cover with a grounded rod to make sure the voltage has been discharged. If you see an arc, verify that the electrostatics are turned off. Increase the discharge time, or see **Electrical Troubleshooting**, page 60, or the voltage isolation system manual for other possible problems. The default discharge time is 60 seconds. Resolve the problem before proceeding.
5. Test voltage discharge weekly.

## Shutdown Procedure

1. Flush if needed. See **Flushing Procedure**, page 46.
2. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
3. Clean the cup and exterior of the applicator. See **Clean the Air Cap and Cup**, page 56. See also, **Clean the Outside of the Rotary Applicator**, page 57.

# Maintenance

<p>Installing and servicing this equipment requires access to parts which may cause an electric shock or other serious injury if the work is not performed properly. Do not install or repair this equipment unless you are trained and qualified.</p> <p>Contact with the charged components of the rotary applicator will cause an electric shock. Contact with a rotating cup also may cause injury. Do not touch the bell or come within 3 ft. (0.9 m) of the front of the applicator during operation.</p> <p>To reduce the risk of an injury, follow the <b>Pressure Relief Procedure</b>, page 47, which includes <b>Voltage Discharge and Grounding Procedure</b>, before checking or servicing any part of the system, and whenever you are instructed to relieve the pressure.</p>				

## Daily Care and Cleaning Checklist




Check the following list daily when finished using the equipment.

- Flush the applicator. See **Flushing Procedure**, page 46.
- Check the fluid and air line filters.
- Clean the cup and the outside of the applicator. See pages 56-57.
- Inspect the rotary applicator and the cup for nicks, scratches, or excessive wear.
- Check for fluid leakage from the applicator and fluid hoses.

## Check for Fluid Leakage

<p>If any fluid leakage from the applicator is detected, stop spraying immediately. Fluid leakage could cause fire or explosion, and result in serious injury and property damage.</p>				

During operation, periodically remove the shroud to check for the presence of fluid. See FIG. 24. for location of potential leaks.



ti29447a




**FIG. 24. Check for Fluid Leakage**

Fluid in these locations indicates leakage, which could be caused by the fluid tube connectors, manifold o-rings, or fluid valve leakage.

If fluid is seen in any of these locations:

1. Stop spraying immediately.
2. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
3. Follow the **Shutdown Procedure**, page 49.
4. Remove the applicator for repair.

# Electrical Tests

			
<p>Megohm meter Part No. 241079 (AA-see FIG. 25.) is not approved for use in a hazardous location. To reduce the risk of sparking, do not use the megohm meter to check electrical grounding unless:</p> <ul style="list-style-type: none"> <li>• The applicator has been removed from the hazardous location;</li> <li>• Or all spraying devices in the hazardous location are turned off, ventilation fans in the hazardous location are operating, and there are no flammable vapors in the area (such as open solvent containers or fumes from spraying).</li> </ul> <p>Failure to follow this warning could cause fire, explosion, or electric shock, and result in serious injury and property damage.</p>			

Electrical components inside the applicator affect performance and safety. The following procedures test electrical continuity between applicator components.

Use megohm meter (AA) and an applied voltage of 500 V. Connect the leads as shown.

**NOTE:** Follow the **Flushing Procedure**, page 46, and dry the fluid passages prior to performing electrical tests.

## Test Full Electrostatic Applicator with Power Supply

See FIG. 25.

Measure resistance between the air cap cover and power supply connector pins P1 through P4.


Pin	Acceptable Range
P1	120-160 megohms
P2	120-160 megohms
P3	120-160 megohms
P4	9.0-11.0 gigohms

- If resistance is within this range, testing is complete.
- If resistance is outside this range, test the power supply and the front housing separately.

## Test Non-Electrostatic Applicator with Ground Plug

See FIG. 25.

Use an ohmmeter to measure the resistance between the edge of the air cap to a true earth ground. The reading should be less than 10 ohms.



ti28658c

**Fig. 25. Full Applicator and Power Supply**


## Test Power Supply in Main Housing

See FIG. 26. and FIG. 27.

1. Remove front housing and turbine assembly. See **Replace Front Housing and Turbine Assembly**, page 68 for removal instructions if needed.
2. Measure resistance between the main housing contact (1a) and the power supply connector pins P1 through P4.


Pin	Acceptable Range
P1	120-160 MΩ
P2	120-160 MΩ
P3	120-160 MΩ
P4	9.0-11.0 GΩ

- If resistance is within range, proceed with testing the front housing.
- If resistance is out of range, test the power supply resistance and inspect the threaded ball contact.




ti30548b

**Fig. 26. Rotary Applicator Electrical Path**



ti32310a

**NOTE:** The spring plunger housing must be flush or no more than .01 inch below the main housing surface.



ti30564a

**FIG. 27. Full Applicator and Power Supply**


## Test Power Supply

See FIG. 28.

1. Remove the power supply (28). See **Repair the Power Supply**, page 75.
2. Measure resistance from the power supply (P1-P4) to the spring (28a).

Pin	Acceptable Range
P1	120-160 megohms
P2	120-160 megohms
P3	120-160 megohms
P4	9.0-11.0 gigohms


- If resistance is outside this range, replace the power supply.
- If resistance is within this range, reassemble the power supply in the main housing and retest. Make sure the power supply spring is making contact in the housing.



**FIG. 28. Power Supply Resistance**

## Test Front Housing

1. Remove front housing. See **Replace Front Housing and Turbine Assembly**, page 68, for removal instructions, if needed.
2. Measure resistance from the brass plug to the ball contact.
3. If resistance is less than 0.1 megohm, reassemble and retest the full applicator. Make sure spring loaded contacts are clean and making contact with the mating surface. Refer to FIG. 29.
4. If resistance is 0.1 megohm or greater, replace the front housing.



**FIG. 29. Front Housing Resistance**


## Clean the Air Cap and Cup



### Equipment Needed

- Soft bristle brush
- Compatible solvent

1. Remove the cup. See **Replace Cup or Air Cap**, page 63.
2. Soak the cup in a compatible solvent until paint is loose. Remove **all** paint with a soft bristle brush dipped in solvent.
3. If necessary, clean the splash plate (20a) separately for easier access. Make sure the center holes of the splash plate are clean.
  - a. **15 mm cups:** Use tool (21). Turn counter clockwise to remove the splash plate.
  - b. **30 mm and 50 mm cups:** Place the cup face down on a soft and non-abrasive surface. Press out the splash plate with the post end of the fluid valve tool (45).



**Fig. 30. Remove Splash Plate**

### NOTICE

Use only tool 25C438 (Ref. 21, 15 mm), tool 25C200 (Ref. 45, 30 mm or 50 mm), or your thumb to remove the splash plate. Other tools could damage the surface finish, taper connection, or threads, making the cup inoperable.

4. Reinstall the splash plate (20a).
  - a. **15 mm cups:** Use tool (21) to turn the splash plate clockwise to 20-25 in-lbs (2.3-2.8 N•m).
  - b. **30 mm and 50 mm cups:** Use your thumb to press the splash plate (20a) back in.

### NOTICE

Do not use the fluid valve tool (45) to install the splash plate. It might slip and damage the cup.

5. If the press fit of the splash plate feels loose, service the split ring (20b). If the press fit is too tight, verify alignment. Remove and re-align if necessary.
6. Rinse the cup and dry it.
7. Clean the air cap with the soft bristle brush and solvent, or submerge the air cap in a suitable solvent and wipe it clean. Do not use metal tools.
8. To maximize pattern control, clean the shaping air holes and the air cap cover. Be sure they are not blocked. Soak the parts in solvent and use compressed air to clear any plugged holes.
9. Inspect the parts for damage or excessive wear. Replace if needed.
10. Reassemble. See **Replace Cup or Air Cap**, page 63.



## Clean the Fluid Nozzle

### Equipment Needed:

- Soft bristle brush
- Compatible solvent

**NOTE:** The nozzle is reverse threaded.

1. Follow all steps in **Repair Fluid Nozzle**, page 69.
2. Remove o-ring (8).
3. Soak the nozzle in a compatible solvent until paint is loose. Remove **all** paint with a soft bristle brush dipped in solvent.
4. Rinse the nozzle and dry it.


## Clean the Outside of the Rotary Applicator

### NOTICE

- Clean all parts with a non-conductive, compatible solvent. Conductive solvents can cause the applicator to malfunction.
- Fluid in the air passages could cause the applicator to malfunction and could draw current and reduce the electrostatic effect. Whenever possible, point the applicator down when cleaning it. Do not use any cleaning method which could allow fluid into the air passages.

1. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
2. Make sure the bell has stopped spinning. Then, clean the outside surfaces with a damp solvent rag. **Do not** allow solvent to get into the bell passages.
3. Dry the exterior surfaces.

# Troubleshooting



1. Follow **Prepare for Applicator Service**, page 63, before checking or repairing the applicator.
2. Check all possible problems and causes before disassembling the applicator.
3. See additional troubleshooting in the System Logic Controller manual 3A3955.

## Spray Pattern Troubleshooting

Problem	Cause	Solution
Poor spray pattern.	The cup (20) is damaged.	Replace.
	The air cap cover (19) is not tight.	Tighten.
	O-ring (16, 18c, or 18d) is missing.	Replace.
	Splash plate (20a) is dirty or damaged.	Clean or replace.
	Fluid flow rate is incorrect.	Check fluid pressure. Check nozzle size (9).
	Shaping air holes are clogged.	Disassemble and clean the air cap cover (19).
Fluttering or spitting spray.	The fluid supply is empty.	Refill supply.
	Air is in the fluid supply.	Check fluid source. Refill.
Poor wrap.	See <b>Electrical Troubleshooting</b> , page 60.	

## Applicator Operation Troubleshooting

Problem	Cause	Solution
Rotary applicator does not spray.	Turbine (10) is not rotating.	Be sure the bearing air pressure is at least 70 psig and the turbine air pressure is sufficient. Inspect the turbine bearing for damage. If still not rotating freely, reference Spindle Inspection and Cleaning Service Instructions, 3A4794.
	Fluid supply is low.	Add fluid if necessary. Increase fluid pressure if needed.
	Paint valve (4) is not opening.	Verify at least 70 psig air pressure to the paint trigger line. Clean or replace paint valve.
	The fluid tube (7) or nozzle (9) is clogged.	Remove and clean, replace if necessary.

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Rotary applicator will not stop spraying.	The paint (4) valve is stuck open.	Turn off the paint trigger air. If still spraying, turn off fluid supply and clean or replace paint valve.
	A valve seat (3) is damaged or worn.	Inspect, clean, or replace as needed.
Cannot reach desired fluid flow rate.	Fluid pressure is insufficient.	Increase.
	Fluid nozzle (9) orifice is too small.	Replace with the next larger size nozzle.
	Fluid tube (7) or nozzle (9) is partially clogged.	Remove and clean, replace if necessary.
Fluid leakage from the front of the rotary applicator.	Fluid valve (4) is loose.	Remove and clean. Tighten.
	Nozzle (9) is loose on fluid tube (7).	Remove and clean. Tighten.
	An o-ring (2, 8, or 60) is missing or damaged.	Inspect and clean. Replace as needed.
	The fluid valve seat (3) is damaged or worn.	Inspect, clean, or replace as needed.
Fluid leakage from the dump valve.	Dump valve (4) is loose.	Remove and clean. Tighten.
	The valve seat (3) is damaged or worn.	Inspect, clean, or replace as needed.
Excessive vibration.	The cup (20) is dirty.	Remove and clean any dried paint or other contaminant.
	Cup (20) is not fully secured on turbineshaft (10).	Inspect and clean the threads on the cup and shaft. Retorque.
	The cup (20) is damaged.	Remove, clean, and inspect. Replace as needed.
	Turbine (10) is rotating too fast (being supplied with too much air).	Decrease turbine air pressure.
Speed sensor error.	The fiber-optic cable between the applicator and the speed controller is damaged or has surpassed the bend radius.	Repair or replace fiber-optic cable.
	The fiber-optic cable is not properly adjusted.	Adjust the amount of fiber extending past the nut.
	The fiber-optic connector is loose.	Reinstall and tighten.
	The magnetic speed pick-up sensor is not generating light.	Replace

## Electrical Troubleshooting

Problem	Cause	Solution
Voltage is still present after following the <b>Voltage Discharge and Grounding Procedure</b> , page 48.	Bleed resistor is damaged.	Measure power supply resistance.
	An air pocket in the fluid line has isolated the fluid near the applicator (waterborne models).	Determine cause and correct. Purge air from fluid line.
	The voltage isolation system failed (waterborne models)	Service the voltage isolation system.
Excessive paint is wrapping back.	Poor part grounding.	See <b>Step 9. Ground the Equipment</b> , page 39.
	The distance from applicator to part is incorrect.	Should be 9-14 in. (23-36 cm)
	The shaping air is insufficient.	Verify that shaping air is on. Increase setpoint if necessary.
Operator gets mild shock.	Operator is not grounded or is near an ungrounded object.	See <b>Step 9. Ground the Equipment</b> , page 39.
	Applicator is not grounded.	See <b>Step 9. Ground the Equipment</b> , page 39.
	Operator got too close to the applicator before the discharge time had elapsed.	Wait for the full discharge time to elapse. Check power supply resistance - Pin 4. Increase discharge timer setting, if needed.
Paint wraps poorly on parts.	Electrostatics are missing or voltage is insufficient.	Turn ON at the Electrostatic Controller. Adjust and monitor as needed.
	Parts are insufficiently grounded.	Properly ground so the electrical resistance between the part and ground is 1 megohm or lower.
	Shaping air pressure is too high.	Decrease the shaping air (inner and outer) setpoints.
	Distance from applicator to part is incorrect.	Should be 9-14 in. (23-36 cm).
	Fluid resistivity is low.	See <b>Operation</b> , page 43.
Electrostatic Controller won't go over 60 kV.	The controller is designed for use with a waterborne system.	Purchase a controller designed for use with a solventborne system.
The electrostatics are on, but there is no electrostatic effect from the applicator.	There is an error in the system (indicated by an error code on the Electrostatic Controller).	Refer to the Electrostatic Controller manual (3A3657) to determine and address the cause.
	One or more parts have malfunctioned or need service.	Complete the <b>Electrical Tests</b> starting on page 51. Replace any out-of-specification parts. Retest.
	The power supply cable is damaged.	Test the power supply cable for continuity. See the Electrostatic Controller manual 3A3657.
	Waterborne Systems: See <b>Waterborne System Voltage Loss Troubleshooting</b> , page 61, for possible causes and solutions.	

## Waterborne System Voltage Loss Troubleshooting

Normal spraying voltage for a system using the waterborne applicator is 40-55 kV. The system voltage is lower due to spraying current demands and voltage isolation system losses.

A loss of spraying voltage can be caused by a problem with the applicator, fluid hoses, or voltage isolation system, since all of the system components are electrically connected through the conductive, waterborne fluid.

Before troubleshooting or servicing the voltage isolation system itself, you need to determine which component in the system is most likely causing a problem. Possible causes include the following:

### Applicator

- Fluid leakage
- Dielectric breakdown at the fluid hose connections.
- Faulty power supply
- Excessive over spray on applicator surfaces
- Fluid in the air passages

### Waterborne Fluid Hose

- Dielectric failure of the hose (pin-hole leak in the PTFE layer)

### Voltage Isolation System

- Fluid leakage
- Dielectric breakdown of hoses, seals, or connections
- Isolators not functioning properly

## Visual Checks

First, check the system for any visible faults or errors to help isolate whether the applicator, fluid hose or voltage isolation system has failed.

1. Check that all of the air and fluid tubes and hoses are properly connected. Make sure the waterborne hoses are secured at the proper height at the strain relief.
2. Check that the voltage isolation system valves and controls are properly set for operation.
3. Check that the interior of the isolated enclosure is clean.
4. Check that the voltage isolation system has sufficient air pressure.
5. Check that the electrostatics are turned on.
6. Check that the voltage isolation system's enclosure door is closed and that any safety interlocks are engaged and working properly.
7. Make sure the voltage isolation system is isolating the fluid voltage from ground.
8. To eliminate air gaps in the fluid column, spray enough fluid to purge the air out between the voltage isolation system and the applicator. An air gap in the fluid hose can break the electrical continuity between the applicator and the isolated fluid supply and cause a low voltage reading at the isolation system.
9. Check the outside of the applicator for accumulated overspray. Excessive overspray can create a conductive path back to a ground. Clean the exterior of the applicator.
10. Inspect the entire system for any visible fluid leakage and repair any fluid leaks that are found. Pay special attention to the following areas:
  - Applicator fluid valves
  - Fluid hose: check for leakage or any bulges in the outer cover, which may indicate an internal leak.
  - Internal voltage isolation system components

## Tests



If you still have no voltage, separate the applicator and fluid hoses from the voltage isolation system and check whether the applicator and hoses alone will hold voltage with the following test.

1. Flush the system with water and leave the lines filled with water.
2. Discharge the system voltage (see the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**).
3. Disconnect the fluid hoses from the voltage isolation system.

Avoid allowing any water to leak out of the fluid hose(s) as that could cause a significant air gap in the fluid column up to the cup, which can break the conductivity path and conceal a potential failure area.

4. Position the end of the hose(s) as far as possible away from any grounded surface. The end of the hose must be at least 1 ft. (0.3 m) from any ground. Make sure that no one is within 3 ft. (0.9 m) of the end of the hose.

**NOTE:** The conductive layer of the hose must remain grounded.

5. Using the controller, turn on the electrostatics to the applicator. Observe the voltage and current level on the controller.
  - If the voltage is 40 to 55 kV, the applicator and fluid hose are okay, and the problem is in the voltage isolation system.
  - If the spraying voltage is below 40 kV, the problem is in the applicator or fluid hoses.
6. Discharge the system voltage (see **Voltage Discharge and Grounding Procedure**, page 47).
7. Flush the fluid hoses and applicator with enough air to dry out the fluid passages.

8. Using the controller, turn on the electrostatics to the applicator. Observe the voltage and current level on the controller.
9. If the voltage is 40-55 kV, the applicator power supply is okay, and there is probably a dielectric breakdown somewhere in the fluid hoses or applicator. Continue with step 10.

If the voltage is below 40 kV, do the **Electrical Troubleshooting**, page 60, to check the applicator and power supply resistance. If those tests show the applicator and power supply are okay, continue with step 10.

10. A dielectric breakdown is most likely in one of the following three areas. Repair or replace the component that is failing.
  - a. Fluid hoses:
    - Check each hose for leakage or any bulges in the outer cover, which may indicate a pin-hole leak through the PTFE layer. Disconnect the fluid hoses from the applicator, and look for signs of fluid contamination on the outside of the PTFE portion of the fluid tube.
    - Inspect the end of each hose connected to the voltage isolation system. Look for cuts or nicks.
    - Make sure each hose is properly stripped (see **Waterborne Systems**, page 29). Re-strip or replace the hose.
  - b. Fluid hose connection to the applicator:
    - A breakdown at the fluid hose connection joint is caused by fluid leaking past the fitting on the end of the hose.
11. Clean and dry the fluid tubes, then reassemble the applicator.

12. Reconnect the fluid hoses.

Check the voltage before filling the applicator with fluid.

# Repair



Installing and servicing this equipment requires access to parts which may cause an electric shock or other serious injury if the work is not performed properly. Do not install or repair this equipment unless you are trained and qualified.

Contact with the charged components of the rotary applicator will cause an electric shock. Contact with a rotating cup also may cause injury. Do not touch the bell or come within 3 ft. (0.9 m) of the front of the applicator during operation.

To reduce the risk of an injury, follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**, before checking or servicing any part of the system, and whenever you are instructed to relieve the pressure.

## NOTES:

- Check all possible remedies in **Troubleshooting** before disassembling the applicator.
- Lightly lubricate o-rings and seals with non-silicone grease. Order Part No. 111265 Lubricant. Do not over-lubricate.
- Only use genuine Graco parts.

## Prepare for Cup or Air Cap Service

1. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
2. Clean the applicator. See **Daily Care and Cleaning Checklist**, page 50.

## Prepare for Applicator Service


1. Flush the fluid lines.
2. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
3. Screw off the manifold retaining ring (35) by hand. The adapter cover (34) will come with it.
4. Slide the shroud (33) off the back of the housing (1).
5. Disconnect all fluid, air, power, and communication lines.
6. Clean the applicator. See **Daily Care and Cleaning Checklist**, page 50.
7. Remove the bell applicator from the mounting. Perform service or repair at a work bench.

## Replace Cup or Air Cap

Use this section for a quick, on-line replacement of a damaged or worn cup. Cup replacement kits are available.


### 15 mm or 30 mm Cup

1. **Prepare for Cup or Air Cap Service**, page 63.
2. Use the small end of the spanner wrench tool (44) to remove the air cap cover (19).




ti25432b


3. Remove the air cap (18).
4. Use the spanner wrench tool (44) to hold the turbine shaft, then screw off the cup (20).



6. Use the small end of the spanner wrench tool (44) to install the air cap cover (19).




5. Hold the turbine shaft with the spanner wrench tool (44), and install the new cup (20) hand tight. Make sure that the mating tapers are fully seated. Install the air cap (18).






## 50 mm Cup


1. Prepare for Cup or Air Cap Service, page 63.
2. Use the small end of the spanner wrench tool (44) to remove the air cap cover (19).




3. To hold the shaft steady, insert the fluid valve tool (45) into the rectangular opening on the air cap (18). To lock rotation, slowly rotate the cup until the tool engages the hole in the shaft. Then, screw off the cup (20).




4. Remove air cap (18). Inspect parts for damage and replace as needed. Reinstall the air cap (18) or install a new one.



5. Start threading the new cup (20). Insert the fluid valve tool into the rectangular opening on the air cap (18). Slowly rotate the cup until the tool engages the hole in the shaft. Then, tighten the cup (20) until the mating tapers are fully seated.



6. Use the spanner wrench tool (44) to install the air cap cover (19).



## Service the Cup and Air Cap

Use this section to remove your cup and air cap and fully disassemble each piece for cleaning or to replace any worn or damaged parts.

### NOTICE



Use only tool 25C438 (Ref. 21, 15 mm), tool 25C200 (Ref. 45, 30 mm or 50 mm), or your thumb to remove the splash plate. Other tools could damage the surface finish, taper connection, or threads, making the cup inoperable.

### NOTICE

Do not use the fluid valve tool (45) to install the splash plate. It might slip and damage the cup.

### 15 mm Cup



1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19), cup (20) and air cap (18). See page 63.
3. Use tool (21). Turn counter-clockwise to remove the splash plate from the cup. Clean parts and inspect for damage. Replace parts as needed.



4. Use tool (21) to reinstall the splash plate (20a). Turn the splash plate clockwise to 20-25 in-lbs (2.3-2.8 N•m).
5. Grease the solvent stud o-ring (18c) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See page 63.

### 30 mm Cup


1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19), cup (20) and air cap (18). See page 63.
3. Use the fluid valve tool (45) to push the splash plate (20a) out of the cup. Remove the split ring (20b). Clean all parts and inspect for damage. Replace parts as needed.



4. Install split ring (20b) on the splash plate (20a). Place the splash plate into the cup. Push in with your thumb until it is fully seated.
5. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See page 63.

## 15 mm or 30 mm Air Cap



1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19), cup (20) and air cap (18). See page 63.
3. Remove the solvent stud o-ring (60). Remove the solvent stud (59) only if you are experiencing a problem and need to replace it.
4. Remove the outer air cap (18b). Remove the o-ring (18c) from the inner air cap (18a). Clean all parts and inspect for damage. Replace parts as needed.



5. Install the o-ring (60) on the solvent stud (59).
6. Install the o-ring (18c) on the inner air cap (18a), then fit the inner (18a) and outer (18b) air caps together.
7. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See page 63.

## 50 mm Cup


1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19), cup (20), and air cap (18). See page 65.
3. Use the fluid valve tool (45) to push the splash plate (20a) out of the cup. Remove split ring (20b). Clean all parts and inspect for damage. Replace parts as needed.



4. Install the split ring (20b) on the splash plate (20a). Place the splash plate into the cup. Push in with your finger until it is fully seated.
5. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See page 65.

## 50 mm Air Cap


1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19) and cup (20). See page 65.
3. Slide off the air cap (18). Remove the outer air cap (18b). Remove o-rings (18c, 18d). Remove the solvent stud o-ring (60). Remove the solvent stud (59) only if you are experiencing a problem and need to replace it. Clean all parts and inspect for damage. Replace parts as needed.



4. Install the o-ring (60) on the solvent stud (59).
5. Install o-rings (18c and 18d) on the inner air cap (18a), then fit the inner (18a) and outer (18b) air caps together.
6. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See page 65.

## Replace Front Housing and Turbine Assembly

1. **Prepare for Applicator Service**, page 63.
2. Remove the air cap cover (19), cup (20) and air cap (18). See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.
3. Use the larger end of the spanner wrench tool (44) to remove the retaining ring (15).




4. Remove the front housing (13), which includes the turbine assembly (10).
5. Place the threaded end of the turbine assembly (10) on a padded bench. Press down on the housing (13) to separate the housing and the turbine assembly.

### NOTICE


Be careful not to damage the threads when removing the turbine assembly from the front housing.

6. Remove the o-rings (11, 12, 14, 16, and 17) from the front housing.
7. Remove the o-rings (10a, 10b, and 10c) from the turbine assembly (10).

8. Clean all parts and inspect for damage. Replace parts as needed.



9. Install o-rings (11, 12, 14, and 17) on the front housing (13). Lubricate and install o-ring (16).
10. Install o-rings (10a, 10b, and 10c) on the turbine assembly (10).
11. Install the turbine assembly (10) into the front housing (13).
12. Grease the solvent stud o-ring (60). Use the solvent stud and the pins to align the front housing (13) with the main housing (1), then install the front housing.
13. Install the retaining ring (15). Use the larger end of the spanner wrench tool (44) to tighten it.



14. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.

## Repair or Replace the Solvent Stud

The applicator has two solvent studs (59). One is on the main housing (1) and the other is on the air cap (18).

1. **Prepare for Cup or Air Cap Service**, page 63.
2. Remove the air cap cover (19), cup (20), air cap (18), retaining ring (15), turbine (10) and front housing (13).
3. Use a 1/4 in. hex wrench to remove the solvent stud (59) from the main housing (1) or the air cap (18). Remove the o-rings (60). One of the solvent stud o-rings probably will remain in the opening when the solvent stud is removed.
4. Install the o-rings (60) on the solvent stud (59). Lubricate the o-rings and tighten the solvent stud into the main housing (1) or the air cap (18).

**Tip:** You may find it easier to lubricate the bottom o-ring and install it in the hole.


5. Install the front housing (13, including turbine assembly, 10) and retaining ring (15). See steps 12-13, page 69.
6. Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.

## Repair Fluid Nozzle


1. **Prepare for Cup or Air Cap Service**, page 63.
2. Flush the fluid lines.
3. Follow the **Pressure Relief Procedure**, page 47.
4. Remove the air cap cover (19), cup (20), air cap (18), retaining ring (15) and front housing (13).

- Use the middle hexagon on the spanner wrench tool (44) to remove the fluid nozzle (9).

**NOTE:** The nozzle is reverse threaded.




- Inspect o-ring (8) and remove if damaged.
- Install a new o-ring (8) on the nozzle (9).
- Hold the fluid tube with a wrench. Use the middle hexagon on the spanner wrench to tighten the fluid nozzle. Torque to 58-62 in-lb (6.5-7.0 N•m).



- Install the front housing (13, including turbine assembly, 10) and retaining ring (15). See steps 12-13, page 69.
- Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.


## Repair or Replace the Fluid Tube

- Prepare for Cup or Air Cap Service**, page 63.
- Flush the fluid lines.
- Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
- If not already disassembled, remove the air cap cover (19), cup (20), air cap (18), retaining ring (15) front housing (13), and fluid nozzle (9).
- Use a 12 mm wrench to remove the fluid tube (7).



- Inspect o-rings (7a, 7b) and remove if damaged.
- Lightly grease and install new o-rings (7a, 7b) on the fluid tube.


- Screw in a new fluid tube hand tight, then use a 12 mm wrench to tighten. Torque to 78-82 in-lb (8.8-9.3 N•m).



- Install the front housing (13, including turbine assembly, 10) and retaining ring (15). See steps 12-13, page 69.
- Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.


## Replace Magnetic Pickup Sensor or Fiber Optic Extension Cable

- Prepare for Applicator Service**, page 63.
- Remove the air cap cover (19), cup (20), air cap (18), retaining ring (15) and front housing (13).
- Screw off the manifold retaining ring (35) by hand. The adapter cover (34) will come with it. For non-electrostatic models, use a screw driver to pry the adapter cover back off of the retaining studs.
- Slide the shroud (33) off the back of the housing (1).



- Loosen the connector of the fiber optic extension cable (22) at the rear manifold.
- At the front of the main housing, use a 3/32 inch hex wrench to remove screw (6).
- Pull the sensor (5) out of the main housing (1). The fiber optic extension cable (22) comes with it.
- Install the new magnetic pickup sensor (5) and/or the new fiber optic extension cable (22). Line up the flat cut with the hole for the screw.

- Use a 3/32 inch hex wrench to tighten the screw (6). Torque to 18-22 in-lb (2.0-2.5 N•m).




- Install the front housing (13, including turbine assembly, 10) and retaining ring (15). See steps 12-13, page 69.


- Grease the solvent stud o-ring (60) and install the air cap (18), the cup (20), and the air cap cover (19) on the applicator. See **15 mm or 30 mm Cup**, page 63, or **50 mm Cup**, page 65.

- Verify the amount of fiber extending past the nut is 0.11 in. (2.8 mm).

**NOTE:** For non-electrostatic models, the fiber optic cable has the nut on only one end.



- At the front of the rear manifold, install the fiber optic extension cable (22) and tighten the connector. For non-electrostatic models, use the fiber optic bulkhead fitting to connect the extension cable to the main fiber optic cable.




**NOTE:** For non-electrostatic models, use the fiber optic bulkhead to connect the extension cable to the main fiber optic cable.




## Repair Fluid Valves and Seats

1. Prepare for **Applicator Service**, page 63.
2. Flush the fluid lines.
3. Follow the **Pressure Relief Procedure**, page 47, which includes **Voltage Discharge and Grounding Procedure**.
4. Remove the manifold retaining ring (35), the adapter cover (34), and the shroud (33).
5. Put the 4-prong end of the fluid valve tool (45) into the recessed holes on the fluid valve (4).




6. Use the large center hex of the spanner wrench tool (44) to remove the fluid valve (4). Remove the outer o-rings (4a and 4b) from the fluid valve. One o-ring (4b) may have remained in the housing. Inspect o-rings and replace if damaged.
7. Use a 5/16 hex wrench to remove the seat (3). Remove the o-ring (2).
8. Inspect o-ring (2) and replace if damaged.



9. Lubricate the o-ring (2).
10. Install the new seat (3), with the o-ring side down.
11. Use a 5/16 hex wrench to tighten the seat. Torque seat to 9-11 in-lb (1.0-1.2 N•m).
12. Install o-rings (4a and 4b) on the fluid valve.
13. Lubricate the outside surfaces of the fluid valve. Avoid getting lubricant in the fluid path. Screw in the fluid valve, hand tight.
14. Put the 4-prong end of the fluid valve tool (45) into the recessed holes on the fluid valve (4).
15. Use the large center hex of the spanner wrench tool (44) to tighten the fluid valve (4). Torque to 35-40 in-lb (4.0-4.5 N•m).
16. Reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).


For non-electrostatic models, firmly press the adapter cover over the retaining studs to secure the cover.



## Repair Fluid Tube Fittings or Coiled Fluid Tubes


1. Prepare for Applicator Service, page 63.
  2. Use a 3/16 in. hex wrench to remove the 2 screws (42), that hold the fluid bracket (32).
  3. Loosen the connector on the rear manifold and disconnect the fiber optic extension cable (22).
  4. Use a 1/4 in. hex wrench to remove 3 tie rod screws (31), then remove the rear manifold (30).
  5. Use a 1/2 in. wrench to remove the tie rods (29).
  6. Use a 9/16 or 1/2 in. wrench to loosen the nuts on the fluid fittings (25, 61). Disconnect the coiled fluid tubes (27, 62) from the fittings on the main housing (1).
- Note:** Be careful not to lose the ferrules.
7. Remove the coiled fluid tubes (27, 62) from the fittings on the fluid grounding bracket (32a), then remove the bracket.
  8. Use a 1/2 in. wrench to remove the fittings (32d, 32e) and a 7/16 in. wrench to remove fitting 32f from the fluid grounding bracket (32a), as needed. Install new fittings. Add thread sealant and torque to 18-22 in-lb. (2.0-2.5 N•m).

9. Insert the coiled fluid tubes into the fittings (32d, 32f, 25, 61) on the fluid bracket (32a) and main housing (1). Be sure both ferrules are in place as shown. Use a 9/16 or 1/2 in. wrench to tighten the nut on the new fitting.



10. Install the tie rods (29). Torque to 30-35 in-lb (3.4-4.0 N•m).
11. Use 3 screws (31) to reattach the rear manifold (30). Torque to 30-35 in-lb (3.4-4.0 N•m).
12. Use 2 screws (42) to reattach the fluid bracket (32). Torque to 30-35 in-lb (3.4-4.0 N•m).
13. Reattach the fiber optic extension cable (22) on the rear manifold (30).
14. Pass all hoses and cables through the shroud (33), the adapter cover (34) and the manifold retaining ring (35), then reconnect them to the applicator.
15. Reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).

- ⚠ 1 Torque to 18-22 in-lb (2.0-2.5 N•m).
- ⚠ 2 Torque to 30-35 in-lb (3.4-4.0 N•m).
- ⚠ 3 Lubricate o-rings.
- ⚠ 4 Apply dielectric grease to housing end.



## Repair the Power Supply

1. **Prepare for Applicator Service**, page 63.
2. Use a 1/4 in. hex wrench to remove the three screws (31).
3. Loosen the connector on the rear manifold and disconnect the fiber optic extension cable (22).
4. Pull the rear manifold (30) off of the tie rods.


**NOTE:** If the hose bundle is still attached, maneuver the manifold off to side, away from the power supply (28).

5. Unscrew the power supply (28) by hand and remove from the housing. Inspect the spring (28a) and o-ring (28b) on front of the power supply (28) for damage. Replace if needed.
6. **Test Power Supply**, page 55, resistance.
7. To reinstall, use dielectric grease to fill the concentric rings on the housing end of the new power supply (28). Lubricate the outer o-ring.
8. Tighten the power supply securely in place by hand. Be sure it is fully seated.
9. **Test Full Electrostatic Applicator with Power Supply**, page 51.
10. Align and reattach the rear manifold (30).
11. Use a 1/4 in. hex wrench to tighten the tie rod screws (31). **Do not overtighten.**
12. Reattach the fiber optic extension cable (22) on the rear manifold (30).
13. Pass all hoses and cables through the shroud (33), the adapter cover (34) and the manifold retaining ring (35), then reconnect them to the applicator.
14. Reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).

## Replace an Air Tube Fitting

1. **Prepare for Applicator Service**, page 63.
2. Remove the rear manifold (30).
 


**NOTE:** If the hose bundle is still attached, maneuver the manifold off to the side. Remove other parts as needed for access.
3. Inspect all air fittings (23, 24). Pry out to remove, if needed. Replace fittings and o-rings (38, 39) as required.
4. Align and reattach the rear manifold (30).
5. Use a 1/4 in. hex wrench to tighten the tie rod screws (31). **Do not overtighten.**



6. Pass all hoses and cables through the shroud (33), the adapter cover (34) and the manifold retaining ring (35), then reconnect them to the applicator.
7. Reinstall the shroud (33), the adapter cover (34) and the manifold retaining ring (35).

# Parts

## Solventborne Models (R\_A1\_0)



t128626d

## Parts for Solventborne Models (R\_A1\_0)

Ref.	Part	Description	Qty
1†	-----	HOUSING, main, assembly	1
1a	25D453	SPRING, plunger contact	1
2†	127316	O-RING, FX75	3
3†	25C242	SEAT, fluid valve; includes o-ring (Ref. 2)	3
4†	25C243	VALVE, fluid; includes o-rings (Refs. 4a, 4b) and seat (Ref. 3)	3
4a†	117610	O-RING, FX75	6
4b†	120775	O-RING, FX75	3
5	25C279	SENSOR, magnetic; includes screw (Ref. 6)	1
6	GC0612	SCREW, button head, #8-32 x 0.25	1
7	25C280	FLUID TUBE, assembly; includes o-rings (Refs. 7a and 7b)	1
7a	120776	O-RING, FX75	1
7b	111516	O-RING, FX75	1
8	17B390	O-RING, FX75	1
9		NOZZLE, fluid; includes o-ring (Ref. 8)	1
	25C206	0.75 mm. (0.03 in); for R_A13_ models	
	25C207	1 mm. (0.04 in); for R_A14_ models	
	25C208	1.25 mm (0.05 in); or R_A15_ models	
	25C209	1.5 mm (0.06 in); for R_A16_ models	
	26A524	1.8 mm (0.07 in)	
	26A525	2.0 mm (0.08 in)	
10	24W988	TURBINE, assembly; includes o-rings (10a-10c)	1
10a◆	17D878	O-RING, FX75	
10b◆	17B495	O-RING, FX75	
10c◆	17D877	O-RING, FX75	
11◆	GC1936	O-RING, FX75	1
12◆	17D879	O-RING, FX75	1
13	25C281	HOUSING, front; includes o-rings (Refs. 11, 12, 14,16, 17)	1
14†◆	111516	O-RING, FX75	6
15	25C218	RING, retaining	1
16◆	17B495	O-RING, FX75	1
17◆	125249	O-RING, FX75	1
18		AIR CAP, assembly; includes solvent stud (59) and o-ring (60)	1
	25T686	for R1A1__ models (15 mm); includes Refs. 18a-18c	
	25T687	for R3A1__ models (30 mm); includes Refs. 18a-18c	
	25T689	for R5A1__ models (50 mm); includes Refs. 18a-18d	
18a	-----	AIR CAP, inner	1
18b	-----	AIR CAP, outer	1

Ref.	Part	Description	Qty
18c◆	17D877	O-RING, FX75, 50 mm models only	1
18d◆	17D878	O-RING, FX75, all models	1
19		COVER, air cap	1
	25T685	for R1A1__ models (15 mm)	
	25T688	for R3A1__ models (30 mm)	
	25T690	for R5A1__ models (50 mm)	
20		CUP, aluminum, serrated, includes splash plate (Ref. 20a); see <b>Cup Selection Charts</b> , page 86, for available cups	1
	24Z088	for R1A1_0 models (15 mm); includes tool (Ref. 21)	
	24Z079	for R3A1_0 models (30 mm)	
	24Z084	for R5A1_0 models (50 mm)	
20a		PLATE, splash	1
	25D455	for R1A1_0 models (15 mm); includes o-ring (Ref. 20c)	
	25C214	for R3A1_0 and R5A1_0 models; (30 mm and 50 mm) includes split ring (Ref. 20b)	
20b	17A653	RING, split	1
20c	17B390	O-RING, FX75	1
21	25C438	TOOL, 15 mm splash plate, not shown	
22	25C315	CABLE, extension, fiber optic; includes nuts (22a) and fittings (22b)	1
22a	-----	NUT, fiber optic - see kit 24W872	2
22b	-----	FITTING, fiber optic - see kit 24W872	2
23†★	-----	RETAINER, tubing, 5/16 in.	5
24†★	-----	RETAINER, tubing, 5/32 in.	4
25†	111157	FITTING, tube, 1/4 in. with 1/8 in. npt threads	2
27	25C227	TUBE, coiled, 1/4 in. (Paint and Dump)	2
28	25A692	POWER SUPPLY; includes spring (Ref. 28a) and o-ring (Ref. 28b)	1
28a	24Y773	SPRING	1
28b	16D531	O-RING, FX75	1
29	25C229	ROD, TIE	3
30	25C282	MANIFOLD, rear; includes bracket (Ref. 32) and screws (Ref. 42)	1
31	104035	SCREW, cap, socket head, 5/16-18 x 1 in.	3
32	25M454	BRACKET ASSEMBLY, fluid, grounding, includes 32a-32f	1
32a	-----	BRACKET	1
32b	-----	FITTING, fluid, 5/8-18 UNF-2A	3
32c	-----	NUT, 5/8-18 UNF-2B	3
32d	111157	FITTING, tube, 1/4 in. with 1/8 in. npt threads; included in Kit 25C225, page 85	3

Parts

Ref.	Part	Description	Qty
32e	17K719	FITTING, tube, 5/16 in. with 1/8 in. npt threads; <i>included in Kit 25C225, page 85</i>	2
32f	18A999	FITTING, tube, 3/16 in. with 1/8 in. npt threads; <i>included in Kit 25C225, page 85</i>	1
33	25C216	COVER, shroud	1
34	17B385	COVER, adapter	1
35	17B386	RING, retaining, manifold	1
36	25C284	BRACKET, mounting; includes screws (Ref. 37)	1
37	17B496	SCREW, socket head, 3/8-16 x 0.5 in.	4
38†★	17L763	O-RING, FX75	4
39†★	17L764	O-RING, FX75	5
41	223547	WIRE ASSEMBLY, Ground, 25 ft.	1
42	101682	SCREW, cap, socket head, 1/4-20 x 0.625 in.	2
59†	25C283	STUD, solvent; includes o-rings (Ref. 60)	1
60†◆	112319	O-RING, FX75	2
61	18A999	FITTING, 3/16 in. with 1/8 in. npt threads; <i>included in Kit 25C225, page 85</i>	1
62	25P659	TUBE, coiled 3/16" (Solvent)	1
65	-----	COVER, gun, not shown, (Kit 24Z177, qty. 10)	1
66▲	17L835	SIGN, warning	1
67▲	179791	TAG, warning	1
68	25C199	TOOL, spanner wrench	
69‡	25C200	TOOL, fluid valve	1
70‡	-----	TOOL, Allen wrench, 5/16 in.	1
71‡	-----	TOOL, Allen wrench, 1/4 in.	1
72‡	-----	TOOL, Allen wrench, 3/16 in.	1
73‡*	-----	TOOL, Allen wrench, 3/32 in.	1
74‡*	-----	TOOL, Allen wrench 5/32"	1
75‡*	-----	TOOL, Allen wrench 5/64"	1
76‡*	-----	TOOL, Allen wrench 7/32"	1
77‡*	-----	TOOL, Allen wrench	1
78‡	116553	TUBE, grease, dielectric	1

† *Parts are included in Main Housing Kit 26A218.*

◆ *See also O-Ring Kits 25C210, 25C212, and 26B871.*

★ *Parts are included in Air Fitting Quick Connect Kit 25C226.*

▲ *Replacement safety labels, tags, and cards are available at no cost.*

‡ *Parts are included in Tool Kit 25C198. (Not shown.)*

\* *Only used on Hollow Wrist models.*



## Parts for Waterborne Models (R\_A1\_8)

Ref.	Part	Description	Qty
1†	-----	HOUSING, main, assembly	1
1a	25D453	SPRING, plunger contact	1
2†	127316	O-RING, FX75	3
3†	25C242	SEAT, fluid valve, includes o-ring (Ref. 2)	3
4†	25C243	VALVE, fluid, includes seat (Ref. 3)	3
4a†	117610	O-RING, FX75	6
4b†	120775	O-RING, FX75	3
5	25C279	SENSOR, magnetic; includes screw (Ref. 6)	1
6	GC0612	SCREW, button head, #8-32 x 0.25	1
7	25C280	FLUID TUBE, assembly; includes o-rings (Refs. 7a and 7b)	1
7a	120776	O-RING, FX75	1
7b	111516	O-RING, FX75	1
8	17B390	O-RING, FX75	1
9		NOZZLE, fluid; includes o-ring (Ref. 8)	1
	25C206	0.75 mm. (0.03 in.); for R_A13_ models	
	25C207	1 mm. (0.04 in.); for R_A14_ models	
	25C208	1.25 mm (0.05 in.); or R_A15_ models	
	25C209	1.5 mm (0.06 in.); for R_A16_ models	
	26A524	1.8 mm (0.07 in.)	
	26A525	2.0 mm (0.08 in.)	
10	24W988	TURBINE, assembly; includes o-rings (10a-10c)	1
10a◆	17D878	O-RING, FX75	
10b◆	17B495	O-RING, FX75	
10c◆	17D877	O-RING, FX75	
11◆	GC1936	O-RING, FX75	1
12◆	17D879	O-RING, FX75	1
13	25C281	HOUSING, front; includes o-rings (Refs. 11, 12, 14, 16, 17)	1
14†◆	111516	O-RING, FX75	6
15	25C218	RING, retaining	1
16◆	17B495	O-RING, FX75	1
17◆	125249	O-RING, FX75	1
18		AIR CAP, assembly; includes solvent stud (59) and o-ring (60)	1
	25T686	for R1A1__ models (15 mm); includes Refs. 18a-18c	
	25T687	for R3A1__ models (30 mm); includes Refs. 18a-18c	
	25T689	for R5A1__ models (50 mm); includes Refs. 18a-18d	
18a	-----	AIR CAP, inner	1
18b	-----	AIR CAP, outer	1
18c◆	17D877	O-RING, FX75, 50 mm models only	1
18d◆	17D878	O-RING, FX75, all models	1

Ref.	Part	Description	Qty
19		COVER, air cap	1
	25T685	for R1A1__ models (15 mm)	
	25T688	for R3A1__ models (30 mm)	
	25T690	for R5A1__ models (50 mm)	
20		CUP, balanced, standard, serrated, includes splash plate (Ref. 20a); see <b>Cup Selection Charts</b> , page 86, for available cups	1
	24Z088	for R1A1__ models (15 mm); includes tool (Ref. 21)	
	24Z079	for R3A1__ models (30 mm)	
	24Z084	for R5A1__ models (50 mm)	
20a		PLATE, splash	1
	25D455	for R1A1__ models (15 mm); includes o-ring (Ref. 20c)	
	25C214	for R3A1__ and R5A1__ models (30 mm and 50 mm); includes split ring (Ref. 20b)	
20b	17A653	RING, split	1
20c	17B390	O-RING, FX75	1
21	25C438	TOOL, 15 mm splash plate	1
22	25C315	CABLE, extension, fiber optic; includes nut (Ref. 22a) and fitting (Ref. 22b)	1
22a	-----	NUT, fiber optic	2
22b	-----	FITTING, fiber optic	2
23†★	-----	RETAINER, tubing, 5/16 in.	5
24†★	-----	RETAINER, tubing, 5/32 in.	4
25†	18A999	FITTING, tube, 3/16 in. with 1/8 in. npt threads	1
27	25P659	TUBE, coiled, 3/16 in.	1
28	25A692	POWER SUPPLY; includes 28a and 28b	1
28a	24Y773	SPRING	1
28b	16D531	O-RING, FX75	1
29	25C229	ROD, TIE	3
30	25M453	MANIFOLD, rear; includes screws (Ref. 31) and bracket (Ref. 32)	1
31	104035	SCREW, cap, socket head, 5/16 x 1 in.	3
32	25M455	BRACKET ASSEMBLY, fluid, grounding; includes 32a-32h, 42	1
32a	-----	BRACKET	1
32b	-----	FITTING, fluid, 5/8-18 UNF-2A	1
32c	-----	NUT, 5/8-18 UNF-2B	3
32d	111157	FITTING, tube, 1/4 in. with 1/8 in. npt threads; included in Kit 25C300, page 85	1
32e	-----	FITTING, strain relief; included in Kit 25C300, page 85	2
32f	17L670	FERRULE; included in Kit 25C300, page 85	2



Ref.	Part	Description	Qty
32g	17L671	NUT, 5/8-18 UNF-2B; <i>included in Kit 25C300, page 85</i>	2
32h	18A999	FITTING, tube 3/16 with 1/8 in. npt threads; <i>included in Kit 25C300, page 85</i>	1
33	25C216	COVER, shroud	1
34	17B385	COVER, adapter	1
35	17B386	RING, retaining, manifold	1
36	25C284	BRACKET, mounting; includes screws (Ref. 37)	1
37	17B496	SCREW, socket head, 3/8-16 x 0.5in.	4
38†★	17L763	O-RING, FX75	4
39†★	17L764	O-RING, FX75	5
40†	17L617	FITTING, tube, 3/8 in. with 1/8 in. npt threads	2
41	223547	WIRE ASSEMBLY, ground, 25 ft.	1
42	101682	SCREW, cap, socket head, 1/4-20 x 0.625 in.	2
	-----	COVER, gun, not shown, ( <i>Kit 24Z177, qty. 10</i> )	1
▲	17L836	SIGN, warning	1
‡	25C199	TOOL, spanner wrench	1
‡	25C200	TOOL, fluid valve	1
‡	-----	TOOL, Allen wrench, 5/16 in.	1
‡	-----	TOOL, Allen wrench, 1/4 in.	1
‡	-----	TOOL, Allen wrench, 3/16 in.	1
‡	-----	TOOL, Allen wrench, 3/32 in.	1
‡*	-----	TOOL, Allen wrench, 5/32 in.	
‡*	-----	TOOL, Allen wrench, 5/64 in.	
‡*	-----	TOOL, Allen wrench, 7/32 in.	
‡	116553	TUBE, grease, dielectric	1
▲	179791	TAG, warning	1
59†	25C283	STUD, solvent; includes o-rings (Ref. 60)	1
60†◆	112319	O-RING, FX75	2

† *Parts are included in Main Housing Kit 26A244.*

◆ *See also O-Ring Kits 25C210, 25C212, and 26B871.*


★ *Parts are included in Air Fitting Quick Connect Kit 25C226.*

▲ *Replacement safety labels, tags, and cards are available at no cost.*

‡ *Parts are included in Tool Kit 25C198. (Not shown.)*

\* *Only used on Hollow Wrist models.*

# Non-Electrostatic Models (R\_A1\_1)



t37656b

## Parts for Non-Electrostatic Models (R\_A1\_1)

Ref.	Part	Description	Qty
1†	-----	HOUSING, main, assembly	1
1a	25D453	SPRING, plunger contact	1
2†	127316	O-RING, FX75	3
3†	25C242	SEAT, fluid valve; includes o-ring (Ref. 2)	3
4†	25C243	VALVE, fluid; includes o-rings (Refs. 4a, 4b) and seat (Ref. 3)	3
4a†	117610	O-RING, FX75	6
4b†	120775	O-RING, FX75	3
5	25C279	SENSOR, magnetic; includes screw (Ref. 6)	1
6	GC0612	SCREW, button head, #8-32 x 0.25	1
7	25C280	FLUID TUBE, assembly; includes o-rings (Refs. 7a and 7b)	1
7a	120776	O-RING, FX75	1
7b	111516	O-RING, FX75	1
8	17B390	O-RING, FX75	1
9		NOZZLE, fluid; includes o-ring (Ref. 8)	1
	25C206	0.75 mm. (0.03 in.); for R_A13_ models	
	25C207	1 mm. (0.04 in.); for R_A14_ models	
	25C208	1.25 mm (0.05 in.); or R_A15_ models	
	25C209	1.5 mm (0.06 in.); for R_A16_ models	
	26A524	1.8 mm (0.07 in.)	
	26A525	2.0 mm (0.08 in.)	
10	24W988	TURBINE, assembly; includes o-rings (10a-10c)	1
10a◆	17D878	O-RING, FX75	
10b◆	17B495	O-RING, FX75	
10c◆	17D877	O-RING, FX75	
11◆	GC1936	O-RING, FX75	1
12◆	17D879	O-RING, FX75	1
13	25C281	HOUSING, front; includes o-rings (Refs. 11, 12, 14,16, 17)	1
14†◆	111516	O-RING, FX75	6
15	25C218	RING, retaining	1
16◆	17B495	O-RING, FX75	1
17◆	125249	O-RING, FX75	1
18		AIR CAP, assembly; includes solvent stud (59) and o-ring (60)	1
	25T686	for R1A1_ models (15 mm); includes Refs. 18a-18c	
	25T687	for R3A1_ models (30 mm); includes Refs. 18a-18c	
	25T689	for R5A1_ models (50 mm); includes Refs. 18a-18d	
18a	-----	AIR CAP, inner	1
18b	-----	AIR CAP, outer	1

Ref.	Part	Description	Qty
18c◆	17D877	O-RING, FX75, 50 mm models only	1
18d◆	17D878	O-RING, FX75, all models	1
19		COVER, air cap	1
	25T685	for R1A1_ models (15 mm)	
	25T688	for R3A1_ models (30 mm)	
	25T690	for R5A1_ models (50 mm)	
20		CUP, aluminum, serrated, includes splash plate (Ref. 20a); see <b>Cup Selection Charts</b> , page 86, for available cups	1
	24Z088	for R1A1_0 models (15 mm); includes tool (Ref. 21)	
	24Z079	for R3A1_0 models (30 mm)	
	24Z084	for R5A1_0 models (50 mm)	
20a		PLATE, splash	1
	25D455	for R1A1_0 models (15 mm); includes o-ring (Ref. 20c)	
	25C214	for R3A1_0 and R5A1_0 models; (30 mm and 50 mm) includes split ring (Ref. 20b)	
20b	17A653	RING, split	1
20c	17B390	O-RING, FX75	1
21	25C438	TOOL, 15 mm splash plate, not shown	1
22	26A008	CABLE, extension, fiber optic; includes nuts (22a), fittings (22b), and bulkhead (22c)	1
22a	-----	NUT, fiber optic - see kit 24W872	2
22b	-----	FITTING, fiber optic - see kit 24W872	2
22c	24W877	BULKHEAD, fiber optic; discard metal nut	1
23†★	-----	RETAINER, tubing, 5/16 in.	5
24†★	-----	RETAINER, tubing, 5/32 in.	4
25	17K719	FITTING, tube, 5/16 in. with 1/8 in. npt threads	2
28	25R010	PLUG, ground, bell non-ES	1
28a	16D531	O-RING, packing	1
29	19B906	STUD, non-ES	3
33	26A017	COVER, shroud	1
34	17B385	COVER, adapter	1
36	25C284	BRACKET, mounting; includes screws (Ref. 37)	1
37	17B496	SCREW, socket head, 3/8-16 x 0.5 in.	4
38†★	17L763	O-RING, FX75	4
39†★	17L764	O-RING, FX75	5
41	223547	WIRE ASSEMBLY, Ground, 25 ft.	1
53	16D531	O-RING, packing	1
59†	25C283	STUD, solvent; includes o-rings (Ref. 60)	1
60†◆	112319	O-RING, FX75	2
61	111157	FITTING, tube, 1/4 in. with 1/8 npt threads	1

Parts

Ref.	Part	Description	Qty
65	-----	COVER, gun, not shown, (Kit 24Z177, qty. 10)	1
66▲	17L835	SIGN, warning	1
67▲	179791	TAG, warning	1
68	25C199	TOOL, spanner wrench	
69‡	25C200	TOOL, fluid valve	1
70‡	-----	TOOL, Allen wrench, 5/16 in.	1
71‡	-----	TOOL, Allen wrench, 1/4 in.	1
72‡	-----	TOOL, Allen wrench, 3/16 in.	1
73‡*	-----	TOOL, Allen wrench, 3/32 in.	1
74‡*	-----	TOOL, Allen wrench 5/32 in.	1
75‡*	-----	TOOL, Allen wrench 5/64 in.	1
76‡*	-----	TOOL, Allen wrench 7/32 in.	1
77‡*	-----	TOOL, Allen wrench	1
78‡	116553	TUBE, grease, dielectric	1

† Parts are included in Main Housing Kit 26A218.

◆ See also O-Ring Kits 25C210, 25C212, and 26B871.

★ Parts are included in Air Fitting Quick Connect Kit 25C226.

▲ Replacement safety labels, tags, and cards are available at no cost.

‡ Parts are included in Tool Kit 25C198. (Not shown.)

\* Only used on Hollow Wrist models.

# Repair Kits

## Main Housing Repair Kits

Kits include the main housing with the valves, seals, and fittings installed. See the individual parts list for included items.

**Kit 25C257, Main Housing, Replacement, Solventborne**

**Kit 26A244, Main Housing, Replacement, Waterborne**

**Kit 26A218, Main Housing, Replacement, Non-Electrostatic**

## O-Ring Kits

**Kit 25C210, Front Housing O-Rings**

Ref.	Description	Qty.
11	O-RING, FX75	1
12	O-RING, FX75	1
14	O-RING, FX75	6
16	O-RING, FX75	1
17	O-RING, FX75	1

**Kit 25C212, Turbine O-Rings**

Ref.	Description	Qty.
10a	O-RING, FX75	1
10b	O-RING, FX75	1
10c	O-RING, FX75	1

**Kit 26B871, Air Cap O-Rings (15 mm, 30 mm, 50 mm)**

Ref.	Description	Qty.
18c	O-RING, FX75 (only used on 50 mm)	1
18d	O-RING, FX75	1
60	O-RING, FX75	2

## Fittings and Tools

**Kit 25C225, Fluid Fittings, Solventborne**

Ref.	Description	Qty.
32d	FITTING, tube, 1/4 in. with 1/8 in. npt threads	3
32e	FITTING, tube, 5/16 in. with 1/8 in. npt threads	2
32f	FITTING, tube, 3/16 in. with 1/8 in. npt threads	1

**Kit 25C300 Fluid Fittings, Waterborne**

Ref.	Description	Qty.
32d	FITTING, tube, 1/4 in. with 1/8 in. npt threads	1
32e	FITTING, strain relief	2
32f	FERRULE	2
32g	NUT	2
32h	FITTING, tube, 3/16 in. with 1/8 in. npt threads	1

**Kit 25C226, Air Fittings, Quick Connect**

Ref.	Description	Qty.
23	RETAINER, tubing, 5/16 in.	5
24	RETAINER, tubing, 5/32 in.	4
38	O-RING, FX75	4
39	O-RING, FX75	5

**Kit 25C198, Tool Box**

Ref.	Description	Qty.
44	TOOL, spanner wrench	1
45	TOOL, fluid valve	1
53	TOOL, Allen wrench, 5/16 in.	1
54	TOOL, Allen wrench, 1/4 in.	1
55	TOOL, Allen wrench, 3/16 in.	1
56	TOOL, Allen wrench, 3/32 in.	1
57	TOOL, Allen wrench, 5/32 in.	1
58	TOOL, Allen wrench, 5/64 in.	1
59	TOOL, Allen wrench, 7/32 in.	1
60	TUBE, grease, dielectric	1

## Cup Selection Charts

**NOTE:** Pattern shape and diameter are material dependent.

\* Indicates the cup that is installed on the applicators at the factory. Other kits must be purchased separately.

### 15 mm Cups

	<b>Kit 24Z086</b>	<b>Kit 24Z088*</b>	<b>24Z089</b>	<b>Kit 24Z087</b>
Edge Type	Smooth	Serrated	Serrated	Smooth
Material	Aluminum	Aluminum	Aluminum	Composite
Splash Plate (20a, included)	25D455	25D455	25D455	25D455
Finish	Standard	Standard	High-Wear	None
Air Cap and Cover Kit	25T682			
Recommended Fluid Nozzles	25C206 (0.75 mm), 25C207 (1 mm), 25C208 (1.25 mm)			
Recommended Production Flow Rates	25-100 cc/min.			
Pattern Diameter Range	< 4 in. (< 10 cm)			

### 30 mm Cups

	<b>Kit 24Z076</b>	<b>Kit 24Z079*</b>	<b>24Z080</b>	<b>Kit 24Z078</b>
Edge Type	Smooth	Serrated	Serrated	Smooth
Material	Aluminum	Aluminum	Aluminum	Composite
Splash Plate (20a, included)	25C214	25C214	25C214	25C214
Finish	Standard	Standard	High-wear	None
Air Cap and Cover Kit	25T683			
Recommended Fluid Nozzles	25C206 (0.75 mm), 25C207 (1 mm), 25C208 (1.25 mm), 25C209 (1.5 mm)			
Recommended Production Flow Rates	25-400 cc/min.			
Pattern Diameter Range	4-12 in. (10-31 cm)			

### 50 mm Cups

	<b>Kit 24Z081</b>	<b>Kit 24Z084*</b>	<b>24Z085</b>	<b>Kit 24Z083</b>
Edge Type	Smooth	Serrated	Serrated	Smooth
Material	Aluminum	Aluminum	Aluminum	Composite
Splash Plate (20a, included)	25C214	25C214	25C214	25C214
Finish	Standard	Standard	High-Wear	None
Air Cap and Cover Kit	25T684			
Recommended Fluid Nozzles	25C207 (1 mm), 25C208 (1.25 mm), 25C209 (1.5 mm)			
Recommended Production Flow Rates	50-500 cc/min.			
Pattern Diameter Range	4-18 in. (10-46 cm)			


# Accessories

## Robot Adapter Plates

Adapter Plate	Robot	Bolt Circle		Mounting Screws	Locating Pin Circle		Locating Pins
		mm	in.		mm	in.	
24Y128	MOTOMAN EPX1250	27.5 mm	1.08 in.	4 x M5 x 0.8	27.5 mm	1.08 in.	5 mm
24Y129	MOTOMAN PX1450	32 mm	1.3 in.	8 x M6 x 1.0	-----		-----
	MOTOMAN EPX2850						
24Y172	ABB IRB 540	36 mm	1.4 in.	3 x M5	-----		-----
24Y173	ABB IRB 1400	40 mm	1.6 in.	4 x M6	-----		-----
24Y768	FANUC PAINT MATE 200iA	31.5 mm	1.2 in.	4 x M5	31.5 mm	1.24 in.	1 x 5 mm
	FANUC PAINT MATE 200iA/5L						


## Mounting Kits

### Kit 24Z178, Reciprocator Mounting



Ref.	Part	Description	Qty
101	17C780	POST, mounting	1
102	----	ROD, mounting	1
103	17K966	SCREW, 1/2-13 x 1.5 in.	1
104	17K967	NUT, 1/2-13	1
105	25C580	ADAPTER, 1.75 to 2.00 in	1

### Kit 24Z179, 60° Robot Mounting



Ref.	Part	Description	Qty
105	----	ADAPTER, mounting	1
106	----	BRACKET, robot mounting	1
107	C19789	SCREW, cap, socket head, 5/8-11 x 1.5 in.	1
108	17E420	SCREW, cap, socket head, 5/16-18 x 1.0 in.	4
109	100644	SCREW, cap, socket head, 1/4-20 x 0.75 in.	4


## Fiber Optic Bulkhead Installation

### Stainless Steel Bulkhead

Accepts Graco fiber optic cable fittings. Fits 1/2 inch (13 mm) panel hole.

#### 24W876 Stainless Steel Bulkhead Installation

1. Drill a 1/2 in. to 9/16 in (12.7 mm to 14.2 mm) hole in booth wall or panel to allow bulkhead to pass through.
2. Fiber optic cable nut should be 0.31 in. (7.9 mm) from end of cable.
3. Insert bulkhead (6) into hole and attach nut (7) on either side. Thread in fiber optic cable fitting (2) until it bottoms out. Do not force cable further. Make sure cable marker numbers match to ensure proper communication.
4. Repeat for second side of communications.




### Plastic Bulkhead

Accepts bare fiber optic cable. Fits 5/16" (8 mm) panel hole.

#### 24W877 Plastic Bulkhead Installation

1. Drill a 5/16 in. to 3/8 in. (7.9 mm to 9.5 mm) hole in booth wall or panel to allow bulkhead to pass through.
2. Make a clean cut to the ends of the cable using fiber optic cutter tool. Ensure the ends of the cable are equal length.
3. Insert bulkhead (6) into hole and attach nut (7) on either side. Insert cable into bulkhead and tighten cinch nut down to a snug fit.
4. Repeat for second side of communications.





**Kit 25C288, Dump Valve Plug Kit**

Use to plug the dump passage in the applicator if a dump valve is not needed.

Part	Description	Qty
-----	PLUG	1
117610	O-RING, FX75	1
120775	O-RING, FX75	1
127316	O-RING, FX75	1

**Kit 24Z183, Reflective Speed Sensing Kit**

Replaces the magnetic speed sensor with a dual fiber, optical speed sensor (25A537) and fiber optic source. See manual 3A4738 for details.

**Kit 25A537, Reflective Fiber Optic Cable Kit**

Dual fiber optical speed sensor only. Includes reflective fiber optic cable with housing and hardware required to install in a ProBell applicator.

**Dual Strand Fiber Optic Cables**

End nut must be adjusted to proper length for the applicator being used.

Part	Description	Qty
24X003	CABLE, fiber optic, 25 ft. (7.6 m)	1
24X004	CABLE, fiber optic, 50 ft. (15.25 m)	1
24X005	CABLE, fiber optic, 100 ft. (30.5 m)	1

**Fiber Optic Cables, Reciprocator Models**

Standard single fiber.

Kit	Description	Qty
24Z190	CABLE, fiber optic, 36 ft. (11 m)	1
24Z191	CABLE, fiber optic, 66 ft. (20 m)	1
24Z192	CABLE, fiber optic, 99 ft. (30 m)	1

**Kit 24W875, Fiber Optic Cable Repair**

Includes hardware to repair/replace all fiber optic ends.

Part	Description	Qty
-----	FITTING, fiber optic	4
-----	NUT, fiber optic	4
-----	TOOL, cutter, fiber optic	1

**Kit 24W823, Fiber Optic Cable Cutting Tool**

Use to get clean cut ends.

Part	Description	Qty
-----	TOOL, cutter, fiber optic	3

**Kit 25N021, Waterborne Isolated Solvent Line**

Includes the hardware required to replace the grounded solvent line with an isolated waterborne fluid hose. Additional waterborne fluid hoses must be purchased separately.

Part	Description	Qty
17L617	FITTING, tube, 3/8 in. with 1/8 in. mpt threads	1
-----	FITTING, waterborne hose	1
17L670	FERRULE, waterborne hose	1
17L671	NUT, waterborne hose	1

**Applicator Power Cables**

Kit	Description	Qty
17J586	CABLE, low voltage, 36 ft. (11 m)	1
17J588	CABLE, low voltage, 66 ft. (20 m)	1
17J589	CABLE, low voltage, 99 ft. (30 m)	1
19B884	CABLE, extender, 6 ft. (1.8 m)	1
	Can be used at the applicator for easy replacement in demanding applications	

**Fiber Optic Bulkheads**

Used to run fiber through walls.

Kit	Description	Qty
24W876	STAINLESS STEEL BULKHEAD requires 24W875	2
24W877	PLASTIC BULKHEAD	2

**Kit 25A878, Remote Grounding Bracket and Hose**

High-conductivity hose kit includes fluid hoses (15 ft., 4.6 m).

Part	Description	Qty
111157	FITTING, tube, 1/4 in. with 1/8 in. npt threads	3
-----	BRACKET	1
-----	FITTING, fluid, 5/8-18 UNF-2A	3
-----	NUT, 5/8-18 UNF-2B	3
-----	GROUND WIRE, 25 ft. (7.6 m)	1
17K719	FITTING, tube, 5/16 in. with 1/8 in. npt threads	6
17L847	5/16 in. OD x 0.062 wall, PTFE fluid hose	15 ft.
054183	1/4 in. OD x 0.062 wall, FEP fluid hose	15 ft.

## Electrostatic Waterborne Fluid Hoses

### Waterborne Fluid Hose Kits (Shielded); For Models R\_A1\_8

100 psi (0.69 MPa, 6.9 bar) Maximum Working Pressure

Kit	Description	Qty
17L886	HOSE, fluid, shielded, 36 ft. (11 m)	1
17L887	HOSE, fluid, shielded, 66 ft. (20 m)	1

### Waterborne Fluid Hose Kits (Unshielded); For Models R\_A1\_8

100 psi (0.69 MPa, 6.9 bar) Maximum Working Pressure

Kit	Description	Qty
17L884	HOSE, fluid, unshielded, 36 ft. (11 m)	1
17L885	HOSE, fluid, unshielded, 66 ft. (20 m)	1

## Non-Electrostatic Hose Bundles; For Models R\_A\_\_1

100 psi (0.69 MPa, 6.9 bar) Maximum Working Pressure

The hose bundle includes a fiber optic cable, a ground wire, nylon air lines, and PFA fluid lines. See manual 3A4346 for details.

Kit	Description	Qty
25T743	HOSE BUNDLE, 36 ft. (11 m)	1
25T744	HOSE BUNDLE, 66 ft. (20 m)	1
25T745	HOSE BUNDLE, 99 ft. (30 m)	1

## Air Only Hose Bundles

The hose bundle includes a fiber optic cable, power cables, a ground wire, and nylon air lines.

Kit	Description	Qty
25T746	HOSE BUNDLE, 36 ft. (11 m)	1
25T747	HOSE BUNDLE, 66 ft. (20 m)	1
25T748	HOSE BUNDLE, 99 ft. (30 m)	1

## Solventborne Hose Bundles; For Models R\_A\_\_0

100 psi (0.69 MPa, 6.9 bar) Maximum Working Pressure

The hose bundle includes a fiber optic cable, power cables, a ground wire, nylon air lines, and PFA fluid lines. See manual 3A4346 for details.

Kit	Description	Qty
24Z168	HOSE BUNDLE, 36 ft. (11 m)	1
24Z169	HOSE BUNDLE, 66 ft. (20 m)	1
24Z170	HOSE BUNDLE, 99 ft. (30 m)	1

## Air Only Hose Bundles

The hose bundle includes a fiber optic cable, power cables, a ground wire, and nylon air lines.

Kit	Description	Qty
24Z711	HOSE BUNDLE, 36 ft. (11 m)	1
24Z712	HOSE BUNDLE, 66 ft. (20 m)	1
24Z713	HOSE BUNDLE, 99 ft. (30 m)	1

## Hose Bundle Accessories

Kit	Description	Qty
24Z662	WRAP, spiral, 7 in. (18 cm) section, bag of 10	10
17A490	WRAP, blue, sold per foot	up to 100 ft.

## Bulk Hose Tubing

Maximum continuous purchase length is 100 ft., 30 m. 150 psi (1.03 MPa, 10.3 bar) Maximum Working Pressure

Kit	Description
057233*	5/16 in. OD x 1/4 in. ID PFA fluid hose
057234*	1/4 in. OD x 3/16 in. ID, PFA fluid hose
057231	5/16 in. nylon tubing
054754	5/32 in. nylon tubing, red
598095	5/32 in. nylon tubing, natural
054753	5/32 in. nylon tubing, black
054757	5/32 in. nylon tubing, green

\* Not for use with high-voltage fluid.

## Kit 25C424, Grounding Plate

## Kit 249598, Unclogging Needle

Kit includes 12 picks for unclogging gun air covers or nozzles.

## Kit 24Z177, Gun Cover

Kit includes 10 gun covers for the standard applicator.

## Air Cap and Cover Sets

Purchase as a replacement or to convert one bell model to another size. Each Kit includes the Air Cap Assembly (Ref. 18) and the Air Cap Cover (Ref. 19).

**Kit 25T682, 15 mm, for R1A1\_\_ Models**

**Kit 25T683, 30 mm, for R3A1\_\_ Models**

**Kit 25T684, 50 mm, for R5A1\_\_ Models**

## Test Equipment

Part	Description
241079	Megohmmeter. 500 V output, 0.01–2000 megohms. Use for ground continuity and gun resistance tests. <b>Not for use in hazardous locations.</b>
722886	Paint Resistance Meter. Use for fluid resistivity test. See manual 307263. <b>Not for use in hazardous locations.</b>
722860	Paint Probe. Use for fluid resistivity test. See manual 307263. <b>Not for use in hazardous locations.</b>
245277	Test Fixture, High Voltage Probe, and kV Meter. Use to test the electrostatic voltage of the gun, and the condition of the power supply when being serviced. See manual 309455.



## Miscellaneous Equipment

### Gun Accessories

Part	Description
111265	Non-silicone Lubricant, 4 oz (113 g)
116553	Dielectric Grease. 1 oz (30 ml)

# Dimensions


## 60° Robot Mount - shown as shipped



ti30442b

Ref.	Dimension					
	15 mm Cup		30 mm Cup		50 mm Cup	
	Inches	Centimeters	Inches	Centimeters	Inches	Centimeters
A	4.3	10.9	4.3	10.9	4.3	10.9
B	3.0	7.6	3.0	7.6	3.0	7.6
C	5.1	13.0	5.1	13.0	5.1	13.0
D*	17.9	45.5	17.9	45.5	17.9	45.5
E*	10.9	27.7	10.9	27.7	10.9	27.7
F	6.9	17.5	6.9	17.5	6.9	17.5
G	All models: 2.9 in. (7.4 cm)					
H	Electrostatic models: .5 in. (1.2 cm) Non-Electrostatic models: 1.9 in. (4.8 cm)					
* For non-electrostatic models, subtract 5.6 in (14.2 cm) from dimension shown.						


### 60° Robot Mount - shown with mounting Kit 24Z179



ti25779b

Ref.	Dimension					
	15 mm Cup		30 mm Cup		50 mm Cup	
	Inches	Centimeters	Inches	Centimeters	Inches	Centimeters
A	4.3	10.9	4.3	10.9	4.3	10.9
B	8.1	20.6	8.1	20.6	8.1	20.6
C	10.9	27.7	10.9	27.7	10.9	27.7
D	3.8	9.7	3.9	9.9	4.6	11.7
E	3.6	9.1	3.6	9.1	4.1	10.4
F	1.7	4.3	1.7	4.3	1.7	4.3
G	11.4	29.0	11.4	29.0	11.7	29.7
H*	17.3	43.9	17.3	43.9	17.9	45.5
J	Electrostatic models: 1.8 in. (4.6 cm) Non-Electrostatic models: 1.8 in. (4.6 cm)					
K	Electrostatic models: 7.2 in. (18.3 cm) Non-Electrostatic models: 7 in. (17.8 cm)					
* For non-electrostatic models, subtract 5.6 in (14.2 cm) from dimension shown.						

## Reciprocator Mount - shown with reciprocator mounting kit 24Z178



Ref.	Dimension					
	15 mm Cup		30 mm Cup		50 mm Cup	
	Inches	Centimeters	Inches	Centimeters	Inches	Centimeters
A	4.2	10.7	4.2	10.7	4.2	10.7
B	3.0	7.6	3.0	7.6	3.0	7.6
C	2.4	6.1	2.4	6.1	2.4	6.1
D*	1.75	4.3	1.75	4.3	1.75	4.3
E**	17.3	43.9	17.3	43.9	17.9	45.5
F	5.1	12.9	5.1	12.9	5.7	14.5
G	6.4	16.3	6.4	16.3	6.9	17.5
H	29.1	73.9	29.1	73.9	29.7	75.4

\* A sleeve adapter to convert dimension D from 1.75 inch to 2.0 inch is included with mounting kit 24Z178.  
 \*\* For non-electrostatic models, subtract 5.6 inc (14.2 cm) from dimension shown.


# Performance Charts

## Turbine Air Consumption Charts

These charts show the air consumption in scfm (l/min.) by rotation speed for the three cup sizes. See the key for the flow rate represented by each line.

### 15 mm KEY:


———— 50-100 cc/min.



### 30 mm KEY:

———— 300 cc/min.


- - - - - 100 cc/min.



### Turbine Air Consumption Charts (continued)

**50 mm KEY:**

- 500 cc/min.
- - - - - 300 cc/min.
- ..... 100 cc/min.




### Turbine Inlet Air Pressure Charts

These charts show the turbine inlet air pressure by rotation speed for the three cup sizes. See the key for the flow rate represented by each line. Pressure is measured within 1 ft. (0.3 m) of the rotary applicator.

**15 mm KEY:**

- 100 cc/min.






### Turbine Inlet Air Pressure Charts (continued)


#### 30 mm KEY:

- 300 cc/min.
- - - - - 100 cc/min.



#### 50 mm KEY:

- 500 cc/min.
- - - - - 300 cc/min.
- · - · - 100 cc/min.
- Limit for 20 m tube length. See note.
- Limit for 30 m tube length. See note.



**NOTE:** The rotation speed or flow rate of a 50 mm cup may be limited due to pressure drop in the turbine air line. The limits for the 8 mm OD tube are shown in the chart above. 100 PSI (0.69 MPa, 7.0 bar) system inlet pressure is assumed. For the full range of performance, use one of the following options:


- a maximum of 11 m (35 ft.) length of 8 mm OD tube with a 1 mm wall (0.3125 in. OD tube with 0.04 in. wall).
- a maximum of 30 m (100 ft.) length of 10 mm OD tube with a 1 mm wall.
- a maximum of 30 m (100 ft.) length of 0.375 in. OD tube with a 0.05 in. wall.

## Shaping Air Consumption Charts

These charts show shaping air consumption in scfm (liters per minute) for the three cup sizes. See the key for the type of shaping air (inner or outer) represented by each line. Pressure is measured within 1 ft. (0.3 m) of the rotary applicator.


### 15 mm KEY:

- Inner Shaping Air
- Outer Shaping Air



### 30 mm KEY:


- Inner Shaping Air
- Outer Shaping Air



### Shaping Air Consumption Charts (continued)


**50 mm KEY:**

- Inner Shaping Air
- - - - Outer Shaping Air




## Fluid Flow Rate Charts

These charts show fluid flow rates in cc/minute by inlet pressure for four nozzle sizes. See the key for the viscosity represented by each line. Pressure is measured within 1 foot (0.3 m) of the rotary applicator.




**KEY:**

- 50 cps
- - - - - 100 cps
- ..... 150 cps




Fluid Flow Rate Charts (Continued)





**KEY:**

- 50 cps
- - - - - 100 cps
- ..... 150 cps



Fluid Flow Rate Charts (Continued)





## Fluid Pressure Loss Charts

These charts show the pressure loss per foot of hose in psi (MPa, bar) for three hose sizes. See the key for the viscosity represented by each line.

**NOTE:** Tables use hose ID, while connection sizes refer to hose ODs.

**KEY:**


- 150 cps
- - - - - 100 cps
- · · · · 50 cps



### Pressure Loss Charts (Continued)

**KEY:**

- 150 cps
- - - 100 cps
- · - · - 50 cps





# Ignitability of Coating Materials

Per EN 50176

*From the Physikalisch-Technische Bundesanstalt, Braunschweig, Germany, June 26, 2019.*

## General

The fire and explosion protection of spraying systems can be facilitated considerably when processing coating materials with a low portion of solvents and a high flash point (generally water-based paints), provided that the spray cloud of the coating materials are considered to be non-ignitable. Substantial research has shown that the ignitability of spray clouds depends on the composition of the coating materials made mainly of water, solvents, and solids. The following classification has been established:

## Non-ignitable coating materials

Coating materials of this group have the following composition:

$$[\% \text{H}_2\text{O}] > 1,70 + [\% \text{LM}] + 0,96 \times [\% \text{ORG}], \text{ (all in \% by weight)}$$

where

H<sub>2</sub>O: water;

LM: the entire liquid phase, including liquids with flash points above 60°C and those liquids **not** listed in the safety data sheet, in which case the entire liquid phase is ignitable in the sprayed state;

ORG: solid phase which is ignitable in the sprayed state (ignitable inorganic or ignitable organic solids) including the solids which have an ignitable inorganic or ignitable organic coating.

Non-ignitable coating materials act like water in the liquid phase and in the sprayed state. If the rinsing and thinner liquids correspond to this category, too, no explosion protection is necessary. Coating materials of this group are classified as being non-ignitable liquid coating material.

A fire extinguishing equipment is not required for spraying systems processing coating materials which are classified to be non-ignitable. However, this does not affect the fire protection as a whole. Even these coating materials may resume ignitability after being partially dried. Moreover, water-based coating materials will burn when strongly exposed to a fire which had been initiated by other sources, and thus present a certain fire load.

# Technical Specifications

ProBell Rotary Applicator		
	US	Metric
Maximum air working pressure	100 psi	0.69 MPa, 7.0 bar
Maximum air consumption	50 scfm (25 scfm is typical)	
Bearing air minimum required	70 psi	0.5 MPa, 5.0 bar
Turbine and bearing air conditions		
Maximum dew point	10° F	- 12° C
Aerosol limit	99% aerosol free	
Maximum particle size	.00002 inches	0.5 microns
Maximum air and fluid temperature	120°F	49°C
Maximum fluid working pressure	150 psi	1.03 MPa, 10.3 bar
Turbine speed - maximum operating	60,000 rpm	
Viscosity Range	30 - 150 centistokes	
Maximum flow rate, 50 mm cup	500 cc/min	
Maximum flow rate, 30 mm cup	400 cc/min	
Maximum flow rate, 15 mm cup	100 cc/min	
Paint resistivity range	Solventborne systems: 1 megohm-cm to infinity Waterborne systems: Conductive waterborne fluids	
Weight	Electrostatic models: 9 lbs (4 kg) Non-Electrostatic models: 6.9 lbs (3.1 kg)	
Maximum output voltage	Solventborne systems: 100 kV Waterborne systems: 60 kV	
Maximum current draw	150 micro-amperes	
Ambient temperature range	41° F to 104 °F	5° C to 40° C
Sound pressure level at 60 rpm, 70 psi (0.48 MPa, 4.8 bar); measured per ISO 9614-2, 1 m from applicator	77 dB(A)	
Wetted parts	acetal, 300 series stainless steel, fluoroelastomer, nylon, coated aluminum, FEP, PTFE, PEEK	

## California Proposition 65

### CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm. – [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov).



# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

**TO PLACE AN ORDER**, contact your Graco distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-350

*All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 334452

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**  
**Copyright 2016, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)

Revision K, May 2021