

# HFR™ for NVH Foam - Cart

3A2797ZAC

EN

**Hydraulic, Plural-Component, Fixed-Ratio Proportioner.  
For dispensing NVH foam.**


**For professional use only. Not approved for use in explosive atmospheres or hazardous locations.**



**Important Safety Instructions**

Read all warnings and instructions in this manual. Save these instructions.

See page 4 for model information and maximum working pressure.



ti19507a

Patents Pending

# Contents

|  |           |   |            |
|--|-----------|---|------------|
| <b>Related Manuals</b> .....                         | <b>3</b>  | <b>Appendix D - ADM Error Codes</b> .....         | <b>77</b>  |
| <b>Models</b> .....                                  | <b>4</b>  | <b>Appendix E - System Events</b> .....           | <b>90</b>  |
| <b>Accessories</b> .....                             | <b>6</b>  | <b>Appendix F - USB Operation</b> .....           | <b>92</b>  |
| Applicator .....                                     | 6         | Overview .....                                    | 92         |
| GX-16 Orifices .....                                 | 6         | USB Options .....                                 | 92         |
| B (Blue) and A (Red) Feed Tanks .....                | 6         | Download Log Files .....                          | 92         |
| AC Power Pack .....                                  | 6         | Log Files, Folder Structure .....                 | 93         |
| Refill Kits .....                                    | 6         | Transfer System Settings .....                    | 95         |
| GX-16 Shutoff Valve Kit .....                        | 6         | Update Custom Language .....                      | 96         |
| Additional Accessories .....                         | 7         | <b>Appendix G - Communications Gateway Module</b> |            |
| Communications Gateway Module (CGM) .....            | 7         | <b>Installation Kit</b> .....                     | <b>98</b>  |
| Bag Filter Kits .....                                | 7         | Overview .....                                    | 98         |
| GX-16 Fitting Kits .....                             | 7         | Installation .....                                | 98         |
| <b>Warnings</b> .....                                | <b>8</b>  | Setup - Gateway Screens .....                     | 99         |
| <b>Important Two-Component Material Information</b>  | <b>11</b> | Available Internal Data .....                     | 102        |
| Isocyanate Conditions .....                          | 11        | Run Screens Available Data .....                  | 104        |
| Material Self-ignition .....                         | 11        | I/O Signal Descriptions .....                     | 105        |
| Keep Components A (Red) and B (Blue) Separate        | 11        | Data Exchange Interface .....                     | 106        |
| .....  | 11        | Data Exchange Interface Pointer Designation Table | 108        |
| Moisture Sensitivity of Isocyanates .....            | 11        | .....   | 108        |
| Foam Resins with 245 fa Blowing Agents .....         | 11        | Error Number Tables: .....                        | 113        |
| Changing Materials .....                             | 12        | <b>Technical Data</b> .....                       | <b>118</b> |
| <b>A (Red) and B (Blue) Components</b> .....         | <b>12</b> | Motor Control Module Technical Data .....         | 119        |
| <b>Typical Installation</b> .....                    | <b>13</b> | .....   | 120        |
| <b>Component Identification</b> .....                | <b>14</b> | Dimensions .....                                  | 121        |
| HFR Hydraulic Power Pack .....                       | 17        | <b>California Proposition 65</b> .....            | <b>121</b> |
| Motor Control Module (MCM) .....                     | 18        | <b>Graco Standard Warranty</b> .....              | <b>122</b> |
| Advanced Display Module (ADM) .....                  | 20        | <b>Graco Information</b> .....                    | <b>122</b> |
| Fluid Control Module (FCM) .....                     | 23        |   |            |
| Temperature Control Module .....                     | 24        |   |            |
| <b>Setup</b> .....                                   | <b>27</b> |   |            |
| <b>Startup</b> .....                                 | <b>42</b> |   |            |
| <b>Shutdown</b> .....                                | <b>43</b> |   |            |
| <b>Pressure Relief Procedure</b> .....               | <b>43</b> |   |            |
| <b>Flushing</b> .....                                | <b>44</b> |   |            |
| <b>Maintenance</b> .....                             | <b>45</b> |   |            |
| Install Upgrade Tokens .....                         | 46        |   |            |
| Programming Tokens/Updating System Software          | 46        |   |            |
| .....  | 46        |   |            |
| <b>Troubleshooting</b> .....                         | <b>49</b> |   |            |
| Light Tower (Optional) .....                         | 49        |   |            |
| <b>Appendix A - ADM Icons Overview</b> .....         | <b>51</b> |   |            |
| Setup Screen Icons .....                             | 51        |   |            |
| Run Screen Icons .....                               | 52        |   |            |
| <b>Appendix B - ADM Setup Screens Overview</b> ..... | <b>53</b> |   |            |
| <b>Appendix C - ADM Run Screens Overview</b> .....   | <b>71</b> |   |            |

# Related Manuals

Manuals are available at [www.graco.com](http://www.graco.com). Component manuals below are in English:

| <b>System Manuals</b>                |  |
|--------------------------------------|--|
| 313998                               | HFR Repair-Parts                                     |
| <b>Power Distribution Box Manual</b> |  |
| 3A0239                               | Power Distribution Boxes Instructions-Parts          |
| <b>Pumpline Manuals</b>              |  |
| 3A0019                               | Z-Series Chemical Pumps Instructions-Parts           |
| 3A0020                               | HFR Hydraulic Actuator Instructions-Parts            |
| <b>Feed System Manuals</b>           |  |
| 3A0238                               | AC Hydraulic Power Pack Instructions-Parts           |
| 3A0235                               | Feed Supply Kits Instructions-Parts                  |
| 3A0395                               | Stainless Steel Tank Feed Systems Instructions-Parts |
| 3A1299                               | Carbon Steel Tank Feed Systems Instructions-Parts    |
| 3A0237                               | Heated Hoses and Applicator Kits, Instructions-Parts |
| 308495                               | Viscon® Heater Kit Manual                            |
| <b>Dispense Valve Manuals</b>        |  |
| 313536                               | GX-16, Operation                                     |
| <b>Accessory Manuals</b>             |  |
| 3A1149                               | HFR Discrete Gateway Module Kits Manual              |
| 312864                               | HFR Communications Gateway Module Instructions-Parts |
| 3A1936                               | Agitator Kit Instructions-Parts                      |
| 3A1962                               | Agitator Kit with Heat Blanket Instructions-Parts    |
| 3A1657                               | HFR Flow Meter Kits Instructions-Parts               |
| 332544                               | HFR for NVH Prepoly Refresh Kit Instructions-Parts   |
|                                      |  |

| <b>Communications Gateway Module Manuals</b> |   |
|--|---|
| 313997                                       | HFR Setup and Operation manual  |
| 3A2175                                       | HFRL and HFRS Setup and operations Manual.                              |
| 3A1704                                       | Communications Gateway module Installation Kit - for HFR or NVH systems |
| 312864                                       | Communications Gateway Module, Instructions and Parts                   |

# Models

| System    | Full Load Peak Amps Per Phase* | Voltage (phase) | Primary Heater Watts A (Red) | Primary Heater Watts B (Blue) | Max Flow Rate♦<br>lb/min<br>(kg/min) | Approximate Output per Cycle (A+B)<br>gal. (liter) | Hydraulic Pressure Ratio | Maximum Fluid Working Pressure ‡<br>psi (MPa, bar) |               |
|-----------|--------------------------------|-----------------|------------------------------|-------------------------------|--------------------------------------|--|--------------------------|--|---------------|
| 24N569    | 90                             | 230V (3)        | 6,000                        | 4,000                         | 18 (8.2)                             | 0.033 (0.125)                                      | 1.9:1                    | 2000<br>(14, 138)                                  |               |
| 24N570 ★✘ | 68                             | 400V (3)        |                              |                               | 24 (11)                              | 0.045 (0.170)                                      | 1.4:1                    |  |               |
| 24N571    | 90                             | 230V (3)        |                              |                               |                                      | 6,000  | 17 (7.7)                 |  | 0.032 (0.121) |
| 24N572 ★✘ | 68                             | 400V (3)        |                              |                               | 4,000                                |  | 18 (8.2)                 |  | 0.033 (0.125) |
| 24N573    | 90                             | 230V (3)        |                              | 6,000                         |                                      | 17 (7.7)   | 0.032 (0.121)            |  | 3.7:1         |
| 24N574 ★✘ | 68                             | 400V (3)        |                              |                               |                                      |  |                          |  |               |
| 24N575    | 90                             | 230V (3)        |                              | 6,000                         |                                      | 17 (7.7)   | 0.032 (0.121)            |  | 3.7:1         |
| 24N576 ★✘ | 68                             | 400V (3)        |                              |                               | 4,000                                |  |                          |  |               |

| System   | Material Ratio (A:B) | A (Red) Pump Size | B (Blue) Pump Size | A (Red) Orifice | B (Blue) Orifice | 25' (7.6 m) Chemical Hose Bundle | 10' (3 m) Chemical Hose Bundle |
|----------|----------------------|-------------------|--------------------|-----------------|------------------|----------------------------------|--------------------------------|
| 24N569   | 24:1                 | 120               | 5                  | .061            | .011             | 24J290                           | 24J316                         |
| 24N570 ★ |                      |                   |                    |                 |                  |                                  |                                |
| 24N571   | 16:1                 | 160               | 10                 | .057            | .014             |                                  |                                |
| 24N572 ★ |                      |                   |                    |                 |                  |                                  |                                |
| 24N573   | 1:1                  | 60                | 60                 | .039            | .039             | 24N287                           | 24N289                         |
| 24N574 ★ |                      |                   |                    |                 |                  |                                  |                                |
| 24N575   | 24:1                 | 120               | 5                  | .085            | .013             | 24K681                           |                                |
| 24N576 ★ |                      |                   |                    |                 |                  |                                  |                                |

| System   | 27.5' (8.4 m) Hydraulic Hose Bundle | 10' (3 m) Hydraulic Hose Bundle |
|----------|-------------------------------------|---------------------------------|
| 24N569   | 24V197                              | 24J177                          |
| 24N570 ★ |                                     |                                 |
| 24N571   |                                     |                                 |
| 24N572 ★ |                                     |                                 |
| 24N573   |                                     |                                 |
| 24N574 ★ |                                     |                                 |
| 24N575   |                                     |                                 |
| 24N576 ★ |                                     |                                 |



- \* *Full load amps with all devices operating at maximum capabilities. Fuse requirements at various flow rates and mix chamber sizes may be less.*
- ◆ *Flow rate is independent of frequency 50/60 Hz.*
- ★ **CE** *approved.*
- ‡ *The maximum fluid working pressure for the base machine without hoses is 3000 psi (20.7 MPa, 207 bar). If hoses rated at less than 3000 psi are installed, the system maximum fluid working pressure becomes the rating of the hoses. If 2000 psi hoses were purchased and installed by Graco, the working pressure for the machine is already setup for the lower 2000 psi (13.8 MPa, 138 bar) working pressure by Graco. If the machine was purchased without hoses and aftermarket hoses rated at or above 3000 psi are to be installed, see instruction manual 313998 for the procedure to setup the machine for higher rated hoses. The change in working pressure is made by changing a rotary switch setting in the Motor Control Module. The minimum pressure rating for hoses is 2000 psi. Do not install hoses with a pressure rating lower than 2000 psi.*
- ✱ **See 400 V Power Requirements.**

### **400 V Power Requirements**

- 400 V systems are intended for International voltage requirements. Not for voltage requirements in North America.
- If a 400 volt configuration is operated in North America, a special transformer rated for 400 V (“Y” configuration (4 wire)) may be required.
- North America mostly employs a 3 wire or Delta configuration. The two configurations are not interchangeable.

# Accessories

## Applicator

| Part   | Description                                |
|--------|--|
| 24J187 | GX-16, 24:1, Straight, Machine Mount       |
| 24K233 | GX-16, 24:1, Left, Machine Mount           |
| 24K234 | GX-16, No Orifice, Left, Machine Mount     |
| 24E876 | GX-16, No Orifice, Straight, Machine Mount |
| 24E877 | GX-16, 24:1, Right, Machine Mount          |
| 24E878 | GX-16, No Orifice, Right, Machine Mount    |

## GX-16 Orifices

| Part   | Description       |
|--------|-------------------|
| 257701 | 0.011 in. Orifice |
| 257702 | 0.013 in. Orifice |
| 24N158 | 0.014 in. Orifice |
| 257703 | 0.016 in. Orifice |
| 257704 | 0.018 in. Orifice |
| 257705 | 0.020 in. Orifice |
| 257706 | 0.022 in. Orifice |
| 257707 | 0.023 in. Orifice |
| 257708 | 0.024 in. Orifice |
| 257709 | 0.025 in. Orifice |
| 257710 | 0.026 in. Orifice |
| 257711 | 0.028 in. Orifice |
| 257712 | 0.029 in. Orifice |
| 257713 | 0.032 in. Orifice |
| 257714 | 0.035 in. Orifice |
| 257715 | 0.036 in. Orifice |
| 257716 | 0.038 in. Orifice |
| 257717 | 0.039 in. Orifice |
| 257718 | 0.040 in. Orifice |
| 257719 | 0.042 in. Orifice |
| 257720 | 0.043 in. Orifice |
| 257721 | 0.044 in. Orifice |
| 257722 | 0.049 in. Orifice |
| 257723 | 0.052 in. Orifice |
| 24N159 | 0.057 in. Orifice |
| 257724 | 0.061 in. Orifice |
| 24K682 | 0.085 in. Orifice |

## B (Blue) and A (Red) Feed Tanks

| Part   | Description  |
|--------|--|
| 24N594 | 20 gal. (75 l) Stainless Steel Tank, No Agitation, Insulation, 3 Level Sensors, A-Side |
| 24N595 | 20 gal. (75 l) Stainless Steel Tank, No Agitation, Insulation, 3 Level Sensors, B-Side |
| 24N578 | 20 gal. (75 l) Carbon Steel Tank, No Agitation, 3 Level Sensors, A-Side                |
| 24N597 | 20 gal. (75 l) Carbon Steel Tank, No Agitation, 3 Level Sensors, B-Side                |
| 24N579 | 2 gal. (8 l) Stainless Steel Tank, No Agitation, 1 Level Sensor, B-Side                |

## AC Power Pack

| Part   | Description                             |
|--------|---|
| 24J912 | 230V, AC Power Pack                     |
| 24J913 | 400V, AC Power Pack                     |
| 24E347 | Hydraulic Power Pack Level Sensor Kit   |
| 24C872 | Hydraulic Power Pack Pressure Gauge Kit |
| 24E348 | Hydraulic Power Pack Temperature Sensor |
| 124217 | Power Pack Accumulator Charging Kit     |

## Refill Kits

| Part   | Description                      |
|--------|----------------------------------|
| 24M418 | Low Volume, 2 gal. (7.6 l) tank  |
| 24M419 | High Volume, 20 gal. (76 l) tank |

## GX-16 Shutoff Valve Kit

| Part   | Description   |
|--------|---|
| 24M596 | GX-16 Shutoff Valve Kit<br>For use with: 24N569, 24N570, 24N571, 24N572, 24N573, 24N574 |
| 24M368 | GX-16 Shutoff Valve Kit<br>For use with: 24N575, 24N576                                 |

## GX-16 Proximity Kit

| Part   | Description         |
|--------|---------------------|
| 24K659 | GX-16 Proximity Kit |

## Additional Accessories

| Part    | Description  |
|---------|--|
| 24C871  | Hydraulic Power Pack Hydraulic Tank Fluid Level Sensor   |
| 24C873  | Hydraulic Power Pack Manifold Oil Temperature Sensor   |
| 121728  | Extension Cable for Advanced Display Module, 4 meter,  |
| 255468  | Light Tower  |
| 255244  | Foot Switch with Guard and 4 meter Cable   |
| 24G389  | Pneumatic Agitator for 20 gal. (75 l) Carbon Steel Tank, No Heat                                       |
| 24K344  | Pneumatic Agitator for 20 gal. (75 l) Carbon Steel Tank, Heat  |
| 24K348  | Pneumatic Agitator for 20 gal. (75 l) Stainless Steel Tank, No Heat                                    |
| 24K346  | Pneumatic Agitator for 20 gal. (75 l) Stainless Steel Tank, Heat                                       |
| 24K223  | Isolated Pistol Grip Adapter   |
| 123694  | Straight Gun Cover   |
| 124226  | 90° Gun Cover  |
| 123695  | 12 ft (3.7 m) Hose Cover   |
| 125236  | Z-Series Pump Cover  |
| 125113  | Gun Cover Handle Hole Cover  |
| 248280  | 3 oz. Quik Shot Grease Tube (10 Pack)  |
| 117792  | 3 oz. Grease Gun   |
| 0553-6  | 14 oz. Synthetic Grease Tube   |
| 255468  | Light Tower Kit  |
| 24T182* | Flow Meter Kit, NVH Cart, 24:1 and 16:1  |
| 24T183* | Flow Meter Kit, NVH Cart, 1:1  |
| 24T180  | PrePoly Refresh Kit, NVH Cart, with Autofill   |
| 24T181  | PrePoly Refresh Kit, NVH Cart, without Autofill  |
| 26C463  | Kit, Handle for Dispense Valve, Ready/Dispense LED Indications, for GX-16, MD2, and EP Dispense Valve. |

\* Flow meter electronics kit, 24J318, is required for flow meter kit installation.

## Communications Gateway Module (CGM)

| Part   | Description  |
|--------|--|
| 24J415 | CGM Mounting Kit<br>(Required for all applications)                |
| CGMDN0 | GCA Gateway Module, DeviceNet Fieldbus                             |
| CGMEP0 | GCA Gateway Module, EtherNet/IP Fieldbus                           |
| CGMPB0 | GCA Gateway Module, PROFIBUS Fieldbus                              |
| CGMPN0 | GCA Gateway Module, PROFINET Fieldbus                              |
| 26B872 | Kit, CGM module, New PLC/Robot Interface for New Designs           |
| 19C802 | Token Assembly, HFR map with Data Exchange                         |
| 19C885 | Flash Drive, HFR Sample Program, Support Files, Sample PLC Program |

## Bag Filter Kits

| Part           | Description                      |
|----------------|----------------------------------|
| 24J312         | High Volume Filter Kit (40 Mesh) |
| 24P095         | Low Volume Filter Kit (100 Mesh) |
| 125147         | 40 Mesh Filter Replacement       |
| 125148         | 100 Mesh Filter Replacement      |
| 0135-4.30x.313 | TEV O-Ring for Lid Seal          |
| 0131-4.30x.313 | EP O-Ring for Lid Seal           |

## GX-16 Fitting Kits

The following kit is for Models 24N575 and 24N576 only.






| Part   | Description     |
|--------|-----------------|
| 24N435 | Gun Fitting Kit |

The following kits are for all other Models.

| Part   | Description                                |
|--------|--|
| 24K672 | Right Orientation, 90° Fitting Adapter Kit |
| 24K674 | Left Orientation, 90° Fitting Adapter Kit  |

# Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbol refers to procedure-specific risk. Refer back to these warnings. Additional, product-specific warnings may be found throughout the body of this manual where applicable.

|  <b>WARNING</b> |   |
|--|---|
|                 | <p><b>ELECTRIC SHOCK HAZARD</b></p> <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> <li>• Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment.</li> <li>• Connect only to grounded power source.</li> <li>• All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.</li> </ul>  |
|                 | <p><b>TOXIC FLUID OR FUMES HAZARD</b></p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> <li>• Read MSDSs to know the specific hazards of the fluids you are using.</li> <li>• Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.</li> <li>• Always wear chemically impermeable gloves when spraying, dispensing, or cleaning equipment.</li> </ul>  |
|               | <p><b>PERSONAL PROTECTIVE EQUIPMENT</b></p> <p>You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This equipment includes but is not limited to:</p> <ul style="list-style-type: none"> <li>• Protective eyewear, and hearing protection.</li> <li>• Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.</li> </ul>   |
|               | <p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Do not point dispensing device at anyone or at any part of the body.</li> <li>• Do not put your hand over the fluid outlet.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Follow the <b>Pressure Relief Procedure</b> when you stop dispensing and before cleaning, checking, or servicing equipment.</li> <li>• Tighten all fluid connections before operating the equipment.</li> <li>• Check hoses and couplings daily. Replace worn or damaged parts immediately.</li> </ul> |


**WARNING**
**FIRE AND EXPLOSION HAZARD**

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. To help prevent fire and explosion:

- Use equipment only in well ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Ground all equipment in the work area. See **Grounding** instructions.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail.
- If there is static sparking or you feel a shock, **stop operation immediately**. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.

**PRESSURIZED ALUMINUM PARTS HAZARD**

Use of fluids that are incompatible with aluminum in pressurized equipment can cause serious chemical reaction and equipment rupture. Failure to follow this warning can result in death, serious injury, or property damage.

- Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents.
- Many other fluids may contain chemicals that can react with aluminum. Contact your material supplier for compatibility.

**PRESSURIZED EQUIPMENT HAZARD**

Fluid from the gun/dispense valve, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.

- Follow the **Pressure Relief Procedure** when you stop spraying and before cleaning, checking, or servicing equipment.
- Tighten all fluid connections before operating the equipment.
- Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.

**⚠ WARNING**



**EQUIPMENT MISUSE HAZARD**

Misuse can cause death or serious injury.

- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Data** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Data** in all equipment manuals. Read fluid and solvent manufacturer’s warnings. For complete information about your material, request MSDS from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure. Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer’s replacement parts only.
- Do not alter or modify equipment.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.



**MOVING PARTS HAZARD**

Moving parts can pinch, cut or amputate fingers and other body parts.

- Keep clear of moving parts.
- Do not operate equipment with protective guards or covers removed.
- Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the **Pressure Relief Procedure** and disconnect all power sources.



**BURN HAZARD**

Equipment surfaces and fluid that’s heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.

# Important Two-Component Material Information

## Isocyanate Conditions



Spraying or dispensing materials containing isocyanates creates potentially harmful mists, vapors, and atomized particulates.

Read material manufacturer's warnings and material MSDS to know specific hazards and precautions related to isocyanates.

Prevent inhalation of isocyanate mists, vapors, and atomized particulates by providing sufficient ventilation in the work area. If sufficient ventilation is not available, a supplied-air respirator is required for everyone in the work area.

To prevent contact with isocyanates, appropriate personal protective equipment, including chemically impermeable gloves, boots, aprons, and goggles, is also required for everyone in the work area.

## Material Self-ignition



Some materials may become self-igniting if applied too thickly. Read material manufacturer's warnings and material MSDS.

## Keep Components A (Red) and B (Blue) Separate



Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage equipment. To prevent cross-contamination of the equipment's wetted parts, **never** interchange component A (Red) and component B (Blue) parts.

## Moisture Sensitivity of Isocyanates

Isocyanates (ISO) are catalysts used in two component foam and polyurea coatings. ISO will react with moisture (such as humidity) to form small, hard, abrasive crystals, which become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity. If used, this partially cured ISO will reduce performance and the life of all wetted parts.

**NOTE:** The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.

To prevent exposing ISO to moisture:

- Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. **Never** store ISO in an open container.
- Use moisture-proof hoses specifically designed for ISO, such as those supplied with your system.
- Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use.
- Never use solvent on one side if it has been contaminated from the other side.
- Always lubricate threaded parts with ISO pump oil or grease when reassembling.

## Foam Resins with 245 fa Blowing Agents

Some foam blowing agents will froth at temperatures above 90°F (33°C) when not under pressure, especially if agitated. To reduce frothing, minimize preheating in a circulation system.

## Changing Materials

- When changing materials, flush the equipment multiple times to ensure it is thoroughly clean.
- Always clean the fluid inlet strainers after flushing.
- Check with your material manufacturer for chemical compatibility.
- Most materials use ISO on the A (Red) side, but some use ISO on the B (Blue) side. See the following section.

## A (Red) and B (Blue) Components

### IMPORTANT!

Material suppliers can vary in how they refer to plural component materials.

Be aware that when standing in front of the manifold on proportioner:


- Component A (Red) is on the left side.
- Component B (Blue) is on the right side.

For all machines:

- The A (Red) side is intended for ISO, hardeners, and catalysts.
- If one of the materials being used is moisture-sensitive, that material should always be in the A (Red) side.
- The B (Blue) side is intended for polyols, resins, and bases.



# Typical Installation



**FIG. 1: Typical Installation**

**Key:**


- A Tank Stand - A (Red)
- B Tank Stand - B (Blue)
- C AC Power Pack
- D HFR Power Pack
- E Dispense Gun
- F Fluid Temperature Sensor (FTS)
- G Manifold
- H Main Hose Bundle
- J Whip Hose Bundle

# Component Identification





**Key for FIG. 2 and FIG. 3.**

- AA Advanced Display Module (see page 20)
- BA Component A (Red) Pressure Relief Outlet
- BB Component B (Blue) Pressure Relief Outlet
- FA Component A (Red) Fluid Manifold Inlet (on left side of manifold block)
- FB Component B (Blue) Fluid Manifold Inlet
- FM HFR Fluid Manifold
- FP Feed Inlet Pressure Gauge
- FT Feed Inlet Temperature Gauge
- GA Component A (Red) Outlet Pressure Gauge
- GB Component B (Blue) Outlet Pressure Gauge
- HA Component A (Red) Hose Connection (from feed to gun or mix head)
- HB Component B (Blue) Hose Connection (from feed to gun or mix head)
- HP Hydraulic Power Pack Assembly
- HT Hydraulic Tank
- LS Pumpline Linear Sensor

- MA Motor Control Module, see page 18
- MP Main Power Switch
- PA Component A (Red) Pump
- PB Component B (Blue) Pump
- PD Power Distribution Box
- PHB Primary Heater - B Side
- PHA Primary Heater - A Side
- PI Primary Heater Fluid Inlet
- PO Primary Heater Fluid Outlet
- PR Primary Heater RTD
- PS Primary Heater Overtemperature Switch
- SA Component A (Red) PRESSURE RELIEF/DISPENSE Valve
- SB Component B (Blue) PRESSURE RELIEF/DISPENSE Valve
- TA Component A (Red) Pressure Transducer
- TB Component B (Blue) Pressure Transducer
- TC High Power Temperature Control Module (not shown, see page 24)





**FIG. 2: Component Identification, Heated Model shown with shrouds removed**




**FIG. 3: Component Identification, Continued**

## Main Power Switch


Located on top of the power distribution box, see page 14. The main power switch turns power

ON  and OFF . The main power switch does not turn pumps or heat zones on.

## Circuit Breakers




Most circuit breakers are located inside the power distribution box. The main block of circuit breakers in the power distribution box is shown below, with detailed information in the following table. For more information about items in the power distribution box, see power distribution box manual.



| Ref. | Size             |                  | Component            |
|------|------------------|------------------|----------------------|
|      | 400V/<br>3 phase | 230V/<br>3 phase |                      |
| CB1  | 63A              | 30A              | Motor Control Module |
| CB2  | 40A              | 40A              | Primary Heater A     |
| CB5  | 5A               | 5A               | Miscellaneous        |
| CB6  | 5A               | 5A               | Miscellaneous        |
| CB9  | 40A              | 40A              | Primary Heater B     |
| CB11 | 30A              | 30A              | AC Power Pack        |

## HFR Hydraulic Power Pack



**FIG. 4: HFR Hydraulic Power Pack**

**Key:**

DA 9 Gallon Hydraulic Oil Reservoir (see **Technical Data** on page 118 for specifications)  
 DB Electric Motor  
 DD Hydraulic Housing  
 DE Directional Valve  
 DF Motor Control Module (see page 18)

DG Fan  
 DH Oil Filter  
 DJ Shroud (not shown, removed for clarity)  
 DK 3 Way Splitter  
 DL Oil Level Sensor (Optional)


## Motor Control Module (MCM)

**NOTICE**

If the Motor Control Module is replaced, the selector switch must be set prior to initial startup of the Motor Control Module or damage may occur. See HFR Repair manual for details, see **Related Manuals** on page 3.

For MCM location, see reference MA in FIG. 2 on page 14. When installed, the end of the MCM with the power input connection (12) faces down and the end with the access cover (A) faces up.

The Motor Control Module uses an 8-position selector switch to set the system maximum working pressure.



**FIG. 5: MCM Component Identification**

| Ref    | Description  |
|--------|--|
| A      | Access Cover   |
| B      | LEDs   |
| C      | Warning Label  |
| 1A, 1B | CAN Connections  |
| 2      | Three-way Splitter to: Oil Low Level Sensor, Dispense Valve Solenoid, and Footswitch |
| 3      | Oil Temperature Sensor   |
| 5      | Electric Motor Temperature Sensor  |
| 6      | LVDT (Position Sensor)   |
| 7      | Three-way Splitter to: Hydraulic Directional Valve, Oil Overtemperature Switch       |
| 8      | Pressure Transducer B (Blue) side  |
| 9      | Pressure Transducer A (Red) side   |
| 10     | Not used   |
| 11     | Motor Position Sensor  |
| 12     | MCM Power Input Connection   |
| 13     | Motor Power Connection   |


## Diagnostic Information

**Table 1: LED (Ref B) Status Signal**

| Module Status LED Signal | Description  |
|--------------------------|--|
| Green on                 | System is powered up.                                      |
| Yellow on                | Internal communication in progress.                        |
| Red solid                | MCM hardware failure. Replace MCM.                         |
| Red flashing fast        | Uploading software.  |
| Red flashing slow        | Token error. Remove token and upload software token again. |

# Advanced Display Module (ADM)

## User Interface



**FIG. 6: ADM Component Identification - Front**

### Buttons


| Ref. | Button                        | Function   |
|------|-------------------------------|--|
| CA   | System enable/disable         | Enables/disables system. When system is disabled, temperature control and dispense operation are disabled. |
| CB   | System Status Indicator Light | Displays system status. See <b>System Status Indicator (CB) Conditions</b> on page 20 for details.         |
| CC   | Stop                          | Stop all system processes.   |

| Ref. | Button     | Function  |
|------|------------|---|
| CD   | Soft Keys  | Defined by application using ADM.   |
| CE   | Cancel     | Cancel a selection or number entry while in the process of entering a number or making a selection. |
| CF   | Enter      | Acknowledge changing a value or making a selection.   |
| CG   | Setup      | Toggle between run and setup screens or password screen if setup screens are password protected.    |
| CH   | Navigation | Navigate within a screen or to a new screen.  |

### System Status Indicator (CB) Conditions

- Green Solid** - Run Mode, System On
- Green Flashing** - Setup Mode, System On
- Yellow Solid** - Run Mode, System Off





r\_24E451\_3B9900\_1a

**FIG. 7: ADM Component Identification - Rear****Key:**

CJ Flat Panel Mount  
 CK Model Number  
 CL USB Module Interface  
 CM CAN Cable Connections

CN Module Status LEDs  
 CP Accessory Cable Connections  
 CR Token Access Cover  
 CS Battery Access Cover

**ADM Module Status LEDs (CN) Conditions**


| Module Status LED Signal | Description  |
|--------------------------|--|
| Green on                 | System is powered up.                                      |
| Yellow on                | Communication in progress.                                 |
| Red solid                | ADM hardware failure.                                      |
| Red flashing fast        | Uploading software.  |
| Red flashing slow        | Token error. Remove token and upload software token again. |

**USB Module Status LEDs (CL) Conditions**

| Module Status LED Signal | Description  |
|--------------------------|--|
| Green flashing           | System is powered up.  |
| Yellow on                | Downloading information to USB                                 |
| Green/Yellow Flashing    | ADM is busy, USB cannot transfer information when in this mode |


## Main Display Components

The following figure calls out the navigational, status, and general informational components of each screen. For details regarding the user interface display see **Shutdown**, page 43.



**FIG. 8: Main Display Components**

## Fluid Control Module (FCM)



**FIG. 9: Fluid Control Module (FCM)**


**Key:**

- A Fluid Control Module
- B Base
- C Module Connection Screws
- D Access Cover
- E Module Status LEDs
- F CAN Connectors

### Diagnostic Information

| Module Status LED (Ref E) Signal | Diagnosis  |
|----------------------------------|--|
| Green on                         | System is powered up                                       |
| Yellow                           | Internal communication in progress                         |
| Red solid                        | FCM hardware failure. Replace FCM.                         |
| Red flashing fast                | Uploading software.  |
| Red flashing slow                | Token error. Remove token and upload software token again. |


## Temperature Control Module



**FIG. 10: High Power Temperature Control Module Sensor Connections**

**Key:**

- |   |  |   |                                      |
|---|--|---|--------------------------------------|
| 1 | Overtemperature Switch Connection (primary heaters only) | 4 | DC Output Connection                 |
| 2 | RTD Temperature Sensor Connection                        | 5 | Input Power Connection               |
| 3 | Output Power Connection                                  | 6 | CAN Connections                      |
|   |  | 7 | Rotary Selector Switch, Token Access |



**FIG. 11: Low Power Temperature Control Module Cable Connections**

- |   |                                   |   |                        |
|---|-----------------------------------|---|------------------------|
| 1 | Overtemperature Switch Connection | 4 | DC Output Connection   |
| 2 | RTD Temperature Sensor Connection | 5 | Input Power Connection |
| 3 | Output Power Connection           | 6 | CAN Connections        |
|   |                                   | 7 | Base                   |



## Temperature Control Module Diagnostic Information

### Module Status LEDs

| Signal                                  | Description   |
|---|---|
| Green on                                | Temperature control module is powered up.   |
| Yellow on                               | Internal communication in progress.   |
| Red solid                               | Temperature control module failure. See Troubleshooting table.                          |
| Red flashing fast                       | Uploading software.   |
| Red flashing slow                       | Token error. Remove token and upload software token again.                              |
| Blue light off (High Power Module only) | Temperature control module is off. See Troubleshooting table.                           |
| Blue flashing (High Power Module only)  | Length of flashes indicates amount of power running through temperature control module. |

## Heat Control Zone Selection

The HFR unit supports four independent temperature control zones and two independent temperature monitoring zones. The high power temperature control modules are located inside the frame below the hydraulic power pack.




## Adjust Rotary Switch

The rotary switch setting indicates which zone the temperature control module will control in the system. The high power module uses an 8-position rotary switch. The low power module uses a 16-position rotary switch.


Set the rotary switch (S) to the specific selection according to the settings listed in the following tables.

### High Power Module Rotary Switch Location



ti12360a

### Low Power Module Rotary Switch Location



ti12361a

### High Power Module Rotary Switch Settings

| Setting     | Zone                  |
|-------------|-----------------------|
| 0           | Not Used              |
| 1           | B (Blue) Primary Heat |
| 2           | B (Blue) Hose Heat    |
| 3           | A (Red) Primary Heat  |
| 4           | A (Red) Hose Heat     |
| 5 through 7 | Not Used              |

### Low Power Module Rotary Switch Settings

| Setting     | Zone                 |
|-------------|----------------------|
| 0 through 4 | Not Used             |
| 5           | B (Blue) Tank Heater |
| 6           | A (Red) Tank Heater  |
| 7           | B (Blue) Chiller     |
| 8           | A (Red) Chiller      |
| 9 through F | Not Used             |

**FIG. 12: Rotary Switch**



# Setup

Perform this setup procedure to secure all necessary machine connections for machine operation.





## 1. Locate system.

- a. Locate system on a level surface. See on page 120 for space requirements.
- b. Do not expose system to rain.

## 2. Electrical requirements. See Models on page 4 for detailed electrical requirements information.

|  |   |  |  |  |  |  |
|--|---|--|--|--|--|--|
|   |  |  |  |  |  |  |
| <p>Installing this equipment requires access to parts which may cause electric shock or other serious injury if work is not performed properly. Have a qualified electrician connect power and ground to main power switch terminals, see step 4 in this setup procedure. All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.</p> |   |  |  |  |  |  |

## 3. Ground system




|   |  |   |   |  |  |  |
|---|--|---|---|--|--|--|
|  |  |  |  |  |  |  |
| <p>This equipment must be grounded.</p>   |  |   |   |  |  |  |

- a. *System*: grounded through power cord. See step 4 on page 27.
- b. *Fluid supply containers*: follow your local code.
- c. *Object being dispensed into*: follow your local code.
- d. *Solvent pails used when flushing*: follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.
- e. *To maintain grounding continuity when flushing or relieving pressure*, hold a metal part of dispense gun firmly to the side of a grounded *metal* pail, then trigger gun.

## 4. Install Drip Pan

- a. Install front pan with studs going through the frame.
- b. Install side pans using the stud on the frame to locate.
- c. Use the supplied fasteners to complete the drip pan installation.

## 5. Connect electrical cord to system.

|   |  |   |  |  |  |  |
|---|--|---|--|--|--|--|
|  |  |  |  |  |  |  |
|---|--|---|--|--|--|--|

**NOTE:** See **Power Line Voltage Surges** information on page 28.

**NOTE:** Power cord is not supplied. See the following table.

**Table 2: Power Cord Requirements**

| Model                           | Cord Requirements<br>AWG (mm <sup>2</sup> ) |
|---------------------------------|---|
| Heated system,<br>230V, 3 phase | 4 (21.2), 3 wire + ground                   |
| Heated system,<br>400V, 3 phase | 4 (21.2), 4 wire + ground †                 |


† Residual Current Device (RCD) must be rated at 300 mA if installed.

**Electrical Cord Wires by Model**

**230V, 3 phase:** L1, L2, L3, GND

**400V, 3 phase:** L1, L2, L3, N, GND

Use 5/32 or 4 mm hex allen wrench to connect the three power leads to L1, L2, L3, and Neutral (as required). Connect green to ground (GND).



**FIG. 13: 400V, 3 phase shown**

**Power Line Voltage Surges**


Power conversion equipment can be sensitive to voltage fluctuations on incoming power. The Motor Control Module falls under the category of power conversion equipment because energy is stored on a capacitive bus and then modulated to control a brushless motor. Engineered design takes this into account and withstands a wide range of conditions, but it is possible for supplied power to occasionally fall outside the tolerable range in industrial plants with high-amperage reactive pulsed loads such as welding equipment. If the tolerable range is exceeded, an overvoltage condition is flagged and the system will shut down in an alarm state to protect itself and alert the user of unstable power. Excessive or repeated overvoltage may permanently damage hardware.

The MAX-HOLD feature on a multimeter can be used to determine peak DC voltage on the line. DC is the proper setting, as opposed to AC, because peak voltage is the critical parameter that affects the DC voltage level stored on the capacitive bus in power conversion equipment. Reading should not regularly exceed approximately 400VDC to avoid tripping the 420VDC alarm level in the Motor Control Module. If power quality is suspect, power conditioning or isolation of the device(s) causing poor power quality is recommended. Consult a qualified electrician if there are any concerns about the available power supply.

**Power Line Test Steps with Multimeter**


- a. Set multimeter to “DC voltage”.
- b. Connect multimeter probes to supplied power line.
- c. Press “Min Max” successively to show the peak positive and negative DC voltages.
- d. Confirm readings do not exceed 400VDC (Motor Control Module alarm issued at 420VDC).

The chart below shows the permissible magnitude and duration of temporary over-voltage events:





## 6. Connect HFR Proximity Cables to the GX-16.




**NOTE:** Refer to the HFR and GX-16 manuals for more details for the following procedures.

**NOTE:** The cable is indicated by a green stripe.

- Connect the GX-16 proximity sensor to the proximity cable.
- Connect the 10 ft (3 m) hydraulic whip hose cable to the 25 ft (7.6 m) chemical hose cable.
- Connect the other end of the cable to the electrical connector found near the fluid manifold on the HFR.

**NOTE:** The electrical connector will be indicated by a green stripe and labeled “PG-MPO”.

## 7. Connect Hydraulic Lines to the system.




### NOTICE

Damage can occur to the directional valve if the hydraulic hose diameter is larger than 3/8 in. (9.5 mm).

To prevent damage to the applicator or directional valves, do not allow any dirt or foreign matter to enter the lines, when connecting the hose kit to the applicator and hydraulic power pack.

- Connect the hydraulic hose to the hydraulic hose fittings (A2 and B2) on the AC power pack.

| Hydraulic Hose Fitting | Hydraulic Hoses | Hydraulic Hose Color Markings |
|------------------------|-----------------|-------------------------------|
| A2                     | Material close  | Green                         |
| B2                     | Material open   | Green/White                   |




**FIG. 14: Hydraulic Fittings on Hydraulic Housing**


- Hand tighten each fitting.
- Tighten each fitting 1/4 turn past hand tight.

## 8. Connect shop air to machine.

**9. Install GX-16 Fitting Adapter Kit (Models 24N575 and 24N576 Only).**




- a. Remove the chemical fittings from the back of the GX-16.
- b. Install JIC #4 fitting assembly into the B Supply port.
- c. Install JIC #6 fitting assembly into the B Return port.
- d. Install JIC #8 fitting assembly into both A Supply and A Return ports.




**10. Install Flow Meter Kit (Optional).**

Refer to HFR Flow Meter Kits, Instruction-Parts manual for installation and setup instructions.




**11. Install PrePoly Refresh Kit (Optional).**

Refer to HFR for NVH Prepoly Refresh Kit, Instructions-Parts for installation and setup instructions.







**FIG. 15: Material Hose Connections**


## 12. Connect Material Hoses




### NOTICE

Avoid routing hoses in walkway areas to prevent operators from tripping on hoses running between system components. This also prevents fittings from leaking.


**NOTE:** Refer to **FIG. 15** on page 32 for visual clarity of the following steps.

- Ensure main power is OFF .
- Ensure A (Red) and B (Blue) inlet valves on the HFR and the material supply ball valves on the tanks are closed.



- Remove reducer fitting from the A (Red) connection of the HFR fluid manifold. Install FTS in the A (Red) material supply line between main hose and whip hose. Ensure the FTS is facing toward the fluid flow of material after installation. See Heated Hose manual for instructions. Refer to **FIG. 15** and **FIG. 16**.

- Remove reducer fitting from B (Blue) connection of the HFR fluid manifold (Models 24N573, 24N574 only). Install the provided additional spacers near the location of the FTS for the remaining material lines. Refer to **FIG. 15** and **FIG. 16**.



**FIG. 16: Material Manifold**

- Install ball valves (optional) between main hose and whip hose. Connect the main hose bundle to the whip hose bundle.


**NOTE:** The ball valve kit is designed to fit in one orientation only.

### NOTICE

If using the ball valve kit, ensure the FTS does not go through the ball valve. Failure to do so will result in damage to the FTS and the inability to close the ball valve.

- Assemble the hydraulic hose sections together and place the assembled hose connection near the FTS area. Refer to **FIG. 15**.
- Connect A (Red) and B (Blue) hoses to A (Red) and B (Blue) outlets on HFR fluid manifold (FM). Hoses are color coded: solid red for component A, solid blue for component B.

- h. Connect cables (Y). Be sure cables have slack when hose bends. Wrap cable and electrical connections with electrical tape. See Heated Hose manual for heated hose connection details and illustrations for the various types of heated hoses.



- i. Connect the other end of the supply hoses (solid color) to the applicator. See the applicator manual for fluid inlet identification.
- j. Connect A (Red) and B (Blue) return hoses (solid with white stripe) to the applicator. See the applicator manual for fluid outlet identification.

**NOTE:** The other end of the return hose will be connected in step n on page 39.

### 13. Connect GX-16 Hydraulic Lines




- a. Navigate to the System Screen 2 and set the mode to run as straight head: prox dispense valve.




Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts.

- b. Verify the mixhead hydraulic power pack is not active by verifying the gauge is at 0.




**FIG. 17: Gauge**


- c. Check the hydraulic fluid level. See **Technical Data** on page 118 for specifications.
- d. Use the supplied 7/16 in. JIC male-male adapter at the gun end to connect hoses together. This creates a hydraulic fluid circulation loop.



**FIG. 18: Hydraulic Loop**

- e. Turn on the power pack by navigating to the Home Screen, Standby Mode and press .


**NOTE:** At Startup, verify the motor rotates in a counter clockwise direction. If it does not, switch the two phases of incoming power. See FIG. 19.



**FIG. 19**

- f. Circulate oil for 3 minutes to purge air from hydraulic hoses.

**NOTE:** Pressure should not increase while air is purged from hoses.


- g. Turn off the power pack by pressing . Look at the gauge to verify no pressure exists in the hydraulic hoses and the AC Power Pack.
- h. Remove the 7/16 in. JIC male-male adapter connecting the hydraulic hoses.

#### NOTICE

To prevent air from entering the hydraulic hoses, do not spill oil while disassembling the adapter connection. If spilling occurs, replace the lost fluid by manually filling the hoses with hydraulic fluid.



- i. Fill both open and close gun chambers with hydraulic fluid.
- j. Attach hydraulic hoses to the gun. Tighten each fitting 1/4 turn past hand tight.

**NOTE:** The hydraulic hose marked with both green and white stripe is for the open port of the gun. The hydraulic hose marked with only a green stripe is for the close port of the gun.



**FIG. 20: Hydraulic Connections**

- k. Attach trigger switch cable (if applicable) to gun and HFR.




**FIG. 21: Cable Connections**

## 14. Setup the Advanced Display Module (ADM)

When main power is turned on by turning the main power switch (MP) to the ON position, the splash screen will be displayed until communication and initialization is complete.



To begin using the ADM, the machine must be on and enabled. To verify the machine is enabled, verify the System Status Indicator Light (CB) is illuminated green, see FIG. 6 on page 20. If the System Status Indicator Light is not green, press the ADM Power On/Off (CA)

button . The System Status Indicator Light will illuminate yellow if the machine is disabled.

The blue token (24M560) must be installed to enable cold start up, temperature monitor zones, and shot times less than one second.

### NOTICE






To ensure proper machine operation, the blue token must remain installed in the ADM during operation.

If the machine is in the Disabled mode screen press



repeatedly to select standby mode.

### Navigation

- Press  or  to navigate to new screens.
- Press  or  to navigate to new screens or to move between fields.
- Press  to activate the desired field or to activate/deactivate an option.

Perform the following tasks to fully setup your system.

Enter Setup Mode by pressing the  button.

- Define shots. See **Shots Screen**, page 54 for more detail.
- Define sequences. See **Sequences Screen**, page 57 for more detail.
- Calibrate HFR**, page 37. See **Calibration Screen, Main**, page 58 for more detail.
- Define pump information. See **System Screen 1**, page 59 for more detail.
- Define dispense valve and other system settings. See **System Screen 2**, page 59 for more detail.
- Define labels and other system settings. See **System Screen 3**, page 60 for more detail.
- If desired, view/reset counters. See **Maintenance Screen**, page 61 for more detail.
- Define level sensors and refill settings. See **Supply Screen**, page 62 for more detail.
- Enable/disable temperature conditioning components. See **Conditioning Screen 1**, page 64 for more detail.
- Define temperature conditioning setpoints. See **Conditioning Screen 2**, page 64 for more detail.
- If Night mode will be used**, define Night mode settings. See **Conditioning Screen 3**, page 65 for more detail.
- Set general system settings. See **Advanced Screen 1**, page 66 for more detail.
- Set units of measure. See **Advanced Screen 2**, page 66 for more detail.
- Enable/disable system features. See **Advanced Screen 3**, page 67 for more detail.









## 15. Calibrate HFR

**NOTE:** Machine is calibrated from the factory. Only perform the following steps when changing or rebuilding pumps.



The HFR calibration procedure is a two step process. The first step, Learn Mode, must be performed whenever the pump line is rebuilt or if any other maintenance is performed that may affect the mechanical tolerances in the pump line. If the machine does not appear to be utilizing the full extent of the pump stroke, or if the machine appears to be contacting the end of the hydraulic cylinder, follow the Learn Mode procedure. The Learn Mode procedure will teach the system the mechanical limits of travel.

### • Learn Mode Procedure:

- a. Ensure the dispense valve is set up as either straight head or straight head prox.
- b. Navigate to the Calibration screen.
- c. Press .
- d. Press  and then . The pump will travel to the right most extreme position.
- e. After the pump stops moving, press  and then press . The pump will travel to the left most extreme position.
- f. After the pump stops moving, press  to return to the main Calibration screen.

**NOTE:** During this process, the system learned the mechanical limits of travel. If the pump did not reach both the left and right extreme limits for any reason, repeat the procedure.

### • Set temperatures:



|   |  |  |  |  |  |  |
|---|--|--|--|--|--|--|
|    |  |  |  |  |  |  |
| <p>This equipment is used with heated fluid, which can cause equipment surfaces to become very hot. To avoid severe burns:</p> <ul style="list-style-type: none"> <li>• Do not touch hot fluid or equipment.</li> <li>• Allow equipment to cool completely before touching it.</li> <li>• Wear gloves if fluid temperature exceeds 110°F (43°C).</li> </ul> |  |  |  |  |  |  |

For detailed temperature adjustments, including alarm levels, or upon initial machine configuration, see **Conditioning Screen 2** on page 64 for details. For minor adjustments to the temperature setpoint once the machine has been initially configured, see the **Status Screen** on page 74.

• **Set system control and dispense modes:** See **System Screen 1** on page 59.

• **Set pump sizes:** See **System Screen 1** on page 59.




### • Define Shot Recipes

- a. Navigate to the Shots screen.
- b. Press  to enter the screen.
- c. Use the directional keypad to navigate to the shot detail column for the desired shot number.
- d. Type the desired setting for that item then press .
- e. Repeat the previous two steps for all desired shot numbers.

### • Change pressure imbalance setting (optional)

The pressure imbalance function detects conditions that can cause off-ratio dispense, such as loss of feed pressure/supply, pump seal failure, clogged fluid inlet filter, or a fluid leak.

The pressure imbalance default is factory-set at 500 psi (3.5 MPa, 35 bar). For tighter ratio error detection, select a lower value. For looser detection or to avoid nuisance alarms, input a higher value.

- a. Navigate to System Screen 3.
- b. Press  to enter the screen.
- c. Navigate to the pressure imbalance field.
- d. Type the desired pressure imbalance setting then press .
- e. Press  and input the specific gravity (SG) of each material into the ADM.

## 16. Flush the System




**NOTE:** System components will contain testing oil from the factory. Perform the following procedure when the machine is initially installed. Both supply and pressure relief must be flushed.

- a. Close both A side (Red) and B side (Blue) feed inlet valves on the system. See FIG. 2 on page 14.
- b. Close A side (Red) and B side (Blue) material return ball valves on the system.
- c. Close both A side (Red) and B side (Blue) material supply ball valves on the system.
- d. Place the applicator return hoses into a container.


### NOTICE

To prevent cross contamination, keep components A (Red) and B (Blue) in separate containers.

- e. Fill tank A (Red) with approximately 5 gal. (19 l) of material and tank B (Blue) with approximately 2 gal. (8 l) of material.
- f. Pressurize both material tanks.



**NOTE:** A minimum feed pressure of 50 psi (0.35 MPa, 3.5 bar) is required at both feed inlet pressure gauges (FP). Maximum feed pressure is 75 psi (517 kPa, 5.2 bar). Maintain A (Red) and B (Blue) feed pressures within 10% of each other.





g. Turn HFR main power ON




h. Navigate to the System Setup Screen. Set the low pressure dispense to 25%.

**NOTE:** The following steps are referring to the B side (Blue) components of the system.

i. Set PRESSURE RELIEF/DISPENSE valve (SA, SB) to DISPENSE  for the corresponding material side.





j. Open feed inlet valve and the material supply ball valve on the system.

k. Navigate to the Standby Screen and push  to start pumps.




**NOTE:** Material will dispense into the container from the applicator material hose at this time. Continue to dispense fluid until no material contamination is noticed.

**NOTE:** If necessary, navigate to Operator Mode to adjust the flow rate.

- l. Stop dispensing by pushing  from the Standby Screen.
- m. Close feed inlet valve and the material supply ball valve on the system.
- n. Connect the applicator return hose to the fluid inlet fitting on the system.



**FIG. 22: Return Lines**

|   |  |  |  |  |  |
|---|--|--|--|--|--|
|    |  |  |  |  |  |
| <p>Do not install shutoffs downstream of the PRESSURE RELIEF/DISPENSE valve outlets (BA, BB). The valves function as overpressure relief valves when set to</p> <p>DISPENSE . Lines must be open so valves can automatically relieve pressure when machine is operating.</p> <p>If circulating fluid back to the supply drums, use high pressure hose rated to withstand the maximum working pressure of this equipment.</p> |  |  |  |  |  |

- o. Ensure all material hose connections are tight.
- p. Open the RETURN ball valves on the tank stand.
- q. Repeat steps j thru p for A side (Red).

### 17. Install GX-16 Orifices




- Close both A side (Red) and B side (Blue) feed inlet valves on the system. See FIG. 2 on page 14.
- Close A side (Red) material return ball valves on the material tank stand.
- Follow **Pressure Relief Procedure** on page 43.
- Remove plugs from GX-16.
- Install orifices provided.

### 18. Pressure check hose

See hose manual. Pressure check for leaks. If no leaks, wrap hose and electrical connections to protect from damage.


### 19. Check hydraulic fluid level

Hydraulic reservoir is filled at the factory. Check fluid level before operating the first time, and weekly thereafter. See **Technical Data** on page 118 for specifications.



ti17747a


**FIG. 23: GX-16 Plug Location**

**20. Install High Volume Fill Kit (Optional).**

r\_24m419\_3a1961\_1a

**FIG. 24: High Volume Refill Kit**

- a. Perform **Pressure Relief Procedure**, page 43.
- b. Close the ball valves located on the day tanks.
- c. Insert the refill valve onto the ball valve.
- d. Connect the air tube from the “open” port on the refill valve to the fitting on the solenoid valve that is located inside the tank stand base cube.
- e. Remove the plug from other port on the solenoid valve and install the air tube fitting.
- f. Connect the air tube from the “close” port on the refill valve to the fitting installed in step e above.

**21. Install Low Volume Fill Kit (Optional).**

r\_24m418\_3a1961\_1a

**FIG. 25: Low Volume Refill Kit**


- a. Perform **Pressure Relief Procedure**, page 43.
- b. Close the ball valves located on the day tanks.
- c. Remove the swivel fitting from the day tank inlet port ball valve.
- d. Insert the refill valve onto the ball valve.
- e. Install the swivel fitting onto the refill valve assembly.
- f. Remove the air tube fitting installed on the solenoid valve located inside the tank stand base cube.
- g. Install the air tube fitting provided with the kit into the open port on the solenoid valve.
- h. Install the air tube from the refill valve to the solenoid valve.

# Startup




To reduce the risk of personal injury, do not operate HFR without all covers and shrouds in place.


1. Check that all machine connections are setup. See **Setup** procedure, page 27.
2. Verify both PRESSURE RELIEF/DISPENSE valves (SA, SB) are set to DISPENSE





3. *If dispense valve has a trigger safety lock, engage the trigger safety lock.*




4. Open system fluid inlet valves and ball valves found on the material tanks. As applicable, ball valves on the material tanks include material supply, applicator return, and pressure relief. Check for leaks.



5. Press  to enable system. LED should be solid green.


6. Navigate to Home Standby screen and press  to initiate auto startup.
7. Check that heat zones are on and temperatures are on target. Check fluid pressure display. Refer to **Status Screen** on page 74 for more details.
8. *If dispense valve has a trigger safety lock, disengage the trigger safety lock.*





- i. Equipment is ready to dispense.


# Shutdown



1. Park pumps.
  - a. From the Home screen, press  and select Standby mode.

- b. Press . Material will not dispense. Pump will park automatically. Once pump is parked, pump will stop moving.



2. Press  to disable the ADM.
3. Turn main power switch (MP) to OFF position.
4. Close A (Red) and B (Blue) fluid supply valves.




5. Perform **Pressure Relief Procedure** on page 43.
6. Shut down feed pumps as required. See feed pump manual.

# Pressure Relief Procedure



1. Press  to disable the ADM.
2. Shut off feed pumps and agitator, if used.
3. Turn PRESSURE RELIEF/DISPENSE valves (SA, SB) to PRESSURE RELIEF/CIRCULATION . Route fluid to waste containers or supply tanks. Ensure gauges drop to 0.



4. **For models with a dispense valve with a safety lock, engage gun safety lock.**
5. Relieve pressure in dispense valve. See dispense valve manual.


# Flushing




Flush equipment only in a well-ventilated area. Do not dispense flammable fluids. Do not turn on heaters while flushing with flammable solvents. Heaters must be off and cool when solvent is in the system.

- To maintain grounding continuity when flushing or relieving pressure, hold a metal part of dispense gun firmly to the side of a grounded *metal* pail, then trigger gun.

- Flush out old fluid with new fluid, or flush out old fluid with a compatible solvent before introducing new fluid.
- Use the lowest possible pressure when flushing.
- All fluid components are compatible with common solvents. Use only moisture-free solvents. See **Run Screen Icons** on page 52 for list of wetted components to verify compatibility of solvent with wetted materials. See solvent manufacturers information for material compatibility.
- To flush feed hoses, pumps, and heaters separately from heated hoses, set PRESSURE RELIEF/DIS-PENSE valves (SA, SB) to PRESSURE RELIEF/CIR-

CULATION . Flush through bleed lines (N).



- To flush entire system, circulate through gun fluid manifold (with manifold removed from gun).
- To prevent moisture from reacting with isocyanate, always leave the system dry or filled with a moisture-free plasticizer or oil. Do not use water. See **Important Two-Component Material Information** on page 11.
- *Solvent pails used when flushing:* follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.




# Maintenance



| Task  | Schedule   |
|---|--|
| Change break-in oil in a new unit   | After first 250 hours of operation or within 3 months, whichever comes first |
| Inspect hydraulic and fluid lines for leaks   | Daily  |
| Check hydraulic fluid level   | Weekly   |
| Grease circulation valves with Fusion <sup>®</sup> grease (117773)  | Weekly   |
| Verify operation of air drying system to prevent isocyanate crystallization                                       | Weekly   |
| Verify vent holes on bottom of electrical cabinet are clear and unobstructed                                      | Weekly   |
| Inspect HFR Powerpack air filter (part 24H018), clean or replace as necessary,                                    | Weekly   |
| Use compressed air to remove dust buildup on control boards, fan, motor (under shield), and hydraulic oil coolers | Monthly  |
| Clean up all hydraulic leaks; identify and repair cause of leak   | As needed  |
| Inspect the gun, fluid lines, trigger switch cable and proximity switch cable for wear or damage                  | Daily  |
| Grease (117773 or 0553-6) the gun   | Weekly or every 15,000 shots   |
| Clean and service the orifices and filters  | As Needed  |
| Check Accumulator Pre-Charge  | Monthly  |
| Check tightness of all clamps and fittings  | Weekly   |
| Check hoses for wear  | Monthly  |
| Replace hydraulic filter  | 6 months   |


| Task  | Schedule |
|---|----------|
| Grease (115982) high volume refill valve, if equipped | Monthly  |
| Change hydraulic fluid                                | Yearly   |

## Grease Circulation Valves With Fusion Grease (117773)



## Check Hydraulic Fluid Level

Check hydraulic fluid level on dipstick. Fluid level must be between indent marks (IM) on dipstick. Refill as required with approved hydraulic fluid; see **Run Screen Icons** on page 52. If fluid is dark in color, change fluid and filter.



## Install Upgrade Tokens

**NOTE:** The Motor Control Module, Fluid Control Module, and Temperature Control Module connection to the system is temporarily disabled during the installation of upgrade tokens.

To install software upgrades:

1. Use correct software token stated in the table. See Graco Control Architecture™ Module Programming manual for instructions.

**NOTE:** Upgrade all modules in the system to the software version on the token, even if you are replacing only one or two modules. Different software versions may not be compatible.

All data in the module (System Settings, USB Logs, Recipes, Maintenance Counters) may be reset to factory default settings. Download all settings and user preferences to a USB before the upgrade, for ease of restoring them following the upgrade.

See manuals for locations of specific GCA components.

The software version history for each system can be viewed in the technical support section at [www.graco.com](http://www.graco.com).

| Token  | Application  |
|--------|--|
| 16H821 | <b>HFR:</b><br>- Advanced Display Module<br>- Motor Control Module<br>- High Power Temperature Control Module<br>- Fluid Control Module (AC Power Pack)<br>- Discrete Gateway Module<br>- Communication Gateway Module |
| 16G407 | <b>Ratio Monitoring (Flow Meters):</b><br>- Fluid Control Module   |




FIG. 26: Remove Access Cover


## Programming Tokens/Updating System Software


On system software version 1.12.001 (February 2020) and later, a single 16H821 programming token can be inserted into the ADM to re-program most of the software modules, after power is cycled. To update the 16C014 “MCM Component Blue” software, the 16H821 token must be installed into the MCM module, then power cycled. Refer to the **Advanced Screen 5** on page 69 in **Appendix B - ADM Setup Screens Overview** for a list of the HFR module software components.

On system software version 1.12.014 and later (October 2020), the capability to program a token using the HFR ADM module and a USB stick (16 gigabytes or smaller) is provided. The user must to obtain the latest 16H822 HFR software, and move the file onto the USB stick in the following directory location:


`\GRACO\SOFTWARE\16H822.gti`

To program an HFR token and update the software, perform the following steps:

1. Enter the system into Disable mode by pressing the mode selection key () from the main home run screen. By pressing the up or down arrow keys, make the "Disable" mode selection as shown on the screen below.




2. Press the Enter key (CF) to make the Disable mode selection.
3. Enter the setup screens by pressing the lock key


() , then navigate to the Advanced 4 screen. It is recommended to temporarily turn off the "Enable Downloading of USB logs" feature for this process, as indicated by the un-checked option shown in the screen below.




4. Select and check the "Use ADM to Program Token" checkbox option, select out of the current screen and navigate one screen left. Go to the "Advanced" setup screen pages.

5. Navigate to the Advanced 8 screen, shown below. The system version of the software currently on the machine is provided ("1.12.013" in the screen below).




6. To program a token with a new version, press the  icon, on the bottom left side of the screen. The screen should appear as shown below.




7. Insert the USB stick with the updated software file into the bottom of the ADM, and insert the black programming token into the right side of the ADM. The token does NOT need to be blanked. The process will blank and write the file from the USB stick to the token.


- After the USB stick is inserted, the short download process may occur. After the download and insertions, the screen should appear as shown below.




- If more than one software file is located in the indicated USB directory, press Enter (CF) to make the selection of the desired file to be programmed to the token.

- To start the programming process, press the  soft key.

- The transfer from the USB stick to the token will take several minutes. After completion, the screen should show a 100% completion and the token will now contain the selected file on the USB stick.



- To program the HFR with the token software, press the  key. If the token will be used for another system, remove the token and exit the screen(s) by pressing the Cancel key. Remember to enable the "Enabled Downloading of USB Logs" option if previously disabled.

# Troubleshooting



Before performing any troubleshooting procedure:

1. Perform **Pressure Relief Procedure** on page 43.
2. Turn main power OFF.
3. Allow equipment to cool.

Try the recommended solutions in the order given for each problem, to avoid unnecessary repairs. Also, determine that all circuit breakers, switches, and controls are properly set and wiring is correct before assuming there is a problem.

## Light Tower (Optional)

| Signal        | Description  |
|---------------|--|
| Green on only | System is powered up and there are no error conditions present |
| Yellow on     | An advisory exists   |
| Red flashing  | A deviation exists   |
| Red on        | The system is shut down due to an alarm occurring.             |

Errors include advisories, deviations, or alarms, so green will only be on when none of these occur. A yellow light can be on at the same time as red (flashing or solid on) when an advisory exists at the same time as a deviation or alarm.

| PROBLEM   | CAUSE  | SOLUTION  |
|---|--|---|
| <b>General</b>  |  |   |
| Display Module completely dark  | No Power   | Verify AC Power switch is ON  |
|   | Thrown Breaker   | Check Machines Breakers and Reset   |
|   | Loose Connection   | Tighten 5-pin cable on Advanced Display Module  |
|   | Bad Display Module   | Replace Advanced Display Module   |
| No or incorrect amount of material dispensed from either side               | Ball Valve closed (if Installed)   | Open tank ball valve.   |
|   | Tank Empty   | Add fluid   |
|   | Tank Clogged   | Clean tank  |
|   | Air In Material  | Prime the machine   |
| Significant material leaking from pump seal                                 | Pump shaft worn and/or shaft seal worn   | Remove pump shaft assembly and reinstall read pump rebuild kit  |
| Material dispensed not correct weight                                       | Specific gravity of one or more of the two materials has changed since calibration | Run calibration   |
|   | Check valve malfunction  | Remove check valve; clean or replace as necessary   |
|   | Piston worn or broken  | Replace Piston  |
| <b>A (Red) and B (Blue) Primary Heaters</b>                                 |  |   |
| Control of primary heat is abnormal; high temperature overshoots            | Dirty RTD connection   | Unplug and re-plug RTD wires.   |
|   | RTD not contacting heater element  | Loosen ferrule nut, push in RTD so tip contact heater element. Holding RTD tip against heater element, tighten ferrule nut 1/4 turn past tight. |
|   | Failed heater element  | Replace   |
|   | Signal failure from RTD  | Check connections   |
|   | RTD wired incorrectly  | Check connections. Power up zones one at a time and verify that temperature for each zone rises.  |
| <b>Hose System</b>  |  |   |
| Material heats but heats slower than usual or it does not reach temperature | Ambient temperature is too cold  | Use auxiliary hose system.  |
|   | FTS failed or not installed correctly  | Check FTS   |

| PROBLEM  | CAUSE  | SOLUTION   |
|--|--|--|
| Material does not maintain temperature while spraying  | Ambient temperature is too cold                          | Increase A (Red) and B (Blue) setpoints to increase fluid temperature and keep it steady   |
|  | Flow too high  | Use smaller mix chamber. Decrease pressure.  |
| Material temperature exceeds setpoint                  | Faulty RTD connections                                   | Verify that all FTS connections are snug and that pins of connectors are snug and that pins of connects are clean. Examine connection of thermocouples to long green plug on heater control board. Unplug and re-plug RTD wires, cleaning off any debris. Unplug and re-plug long green connector on heater control board. |
| Erratic material temperature                           | Faulty RTD connection                                    | Verify that all FTS connections are snug and that pins of connectors are clean. Examine connection of RTD to long green plug on heater control board. Unplug and re-plug RTD wires, cleaning off any debris. Unplug and re-plug long green connector.  |
|  | FTS not installed correctly                              | FTS should be installed close to end of hose in same environment as gun. Verify FTS installation.  |
| Material does not heat                                 | FTS failed or is not contacting correctly                | Check FTS  |
|  | FTS not installed correctly                              | FTS should be installed close to end of hose in same environment as gun. Verify FTS installation.  |
|  | Temperature control alarm                                | See <b>Advanced Display Module (ADM)</b> on page 20  |
| <b>Proportioning System</b>                            |  |  |
| Proportioning pump does not hold pressure when stalled | Pump piston or intake valve leaking                      | <ol style="list-style-type: none"> <li>1. Observe gauges to determine which pump is losing pressure.</li> <li>2. Determine in which direction the pump has stalled by observing which directional valve indicator light is on.</li> <li>3. Repair the valve.</li> </ol>  |
| Material imbalance.                                    | Inadequate flow from pump; cavitation                    | Increase fluid supply to proportioning pump: <ul style="list-style-type: none"> <li>• Use 2:1 supply pump</li> <li>• Use minimum 3/4 in. (19 mm) ID supply hose, as short as practical</li> </ul>  |
|  |  | Fluid is too thick. Consult your material supplier for the recommended fluid temperature to maintain a viscosity of 250 to 1500 centipoise.  |
|  |  | Clean inlet strainer screen  |
|  | Worn pump inlet valve ball/seat or gasket                |  |
|  | Pressure relief/circulation valve leaking back to supply | Remove return line and determine if flow is present while in SPRAY mode  |
| Erratic pump movement                                  | Pump cavitation  | Feed pump pressure is too low. Adjust pressure to maintain 100 psi (0.7 MPa, 7 bar) minimum.   |
| Pump output low  | Obstructed fluid hose or gun; fluid hose ID too small    | Open, clear; use hose with larger ID   |
|  | Worn piston valve or intake valve in displacement pump   | See pump manual 3A0019   |
|  | Inadequate feed pump pressure                            | Check feed pump pressure and adjust to 100 psi (0.7 MPa, 7 bar) minimum.   |


















# Appendix A - ADM Icons Overview













## Setup Screen Icons

| Icon | Description  |
|------|--|
|      | Enter Screen   |
|      | Exit Screen  |
|      | <i>On Learn Mode Calibration screen:</i><br>Move pump<br><br><i>All other screens:</i><br>Begin Dispense   |
|      | Stop Dispense  |
|      | Abort Changing the Label   |
|      | Select left direction  |
|      | Select right direction   |
|      | Backspace  |
|      | Back to main calibration screen from learn mode calibration screen or<br>Back to system screen 2 from mix head operating details screen  |
|      | Access Learn Mode Calibration screen   |
|      | Run MCM Learn Mode   |
|      | Proceed to next step in calibration procedure  |
|      | <i>On Main Calibration screen:</i><br>Calibrate Weight Dispense or Enter Specific Gravity Information<br><br><i>On Flow Meter Calibration screen:</i><br>Use Dispensed Material Weight to Calibrate Flow Meters. If pressed, icon will change and units are changed to volume units. |
|      | Erase Selected Item or Control Data  |

| Icon | Description   |
|------|---|
|      | Erase All Counters on Page                                      |
|      | Access Flowmeter Calibration                                    |
|      | Valve Details   |
|      | Selects all shots to be changed to the same user specific value |
|      | Pressure  |
|      | Shot Number   |
|      | Sequence Position   |
|      | Flow  |
|      | Time (Duration)   |
|      | Tank Blanket Heater   |
|      | Primary Heater  |
|      | Heated Hose   |
|      | Chiller   |
|      | Move Cursor to the Left   |
|      | Move Cursor to the Right  |
|      | Upper/Lower Case Letters  |
|      | Positive / Negative   |
|      | Read Programmed Blue Token                                      |



## Run Screen Icons


| Icon   | Description   |
|--|---|
|   | Select mode.  |
|   | Set system in park (icon will be selected when system is parked)  |
|   | Open, Close Valve   |
|   | A (Red) and B (Blue) refill button (Press to start/abort refill)  |
|   | <b>With a mix head installed:</b> Turns on the mix head hydraulics and puts the machine in low pressure circulation.<br><br>Press a second time to turn off instigated system action. |
|   | <i>If Green:</i><br>Allowed to Dispense<br><br><i>If Yellow:</i><br>System is in a pre-dispense state<br><br><i>If Red:</i><br>Not Allowed to Dispense                                |
|   | Stop Dispense   |
|  OR  | Jump in and use the key pad to select a shot number.  |
|   | Skip the next shot in selected sequence. Only available when the system is not dispensing.  |
|   | Abort sequence and reset to first valid position  |
|   | Edit Operator Dispense Setting  |
|   | Press to enter the Conditioning Control screen  |
|   | Turn on or off the highlighted zone.  |
|   | Turn on or off all zones.   |
|   | Erase a single batch  |
|   | Erase all batch data points   |



| Icon  | Description   |
|---|---|
|    | Sets machine to low pressure  |
|    | Sets machine to high pressure   |
|    | Current and setpoint temperature for primary heater. Not displayed if heat zone is not enabled. |
|    | Current and setpoint temperatures for heated hose. Not displayed if heat zone is not enabled.   |
|    | Current temperatures for heated hose monitor. Not displayed if heat zone is not enabled.        |
|    | Current and setpoint temperatures for tank blanket. Not displayed if heat zone is not enabled.  |
|   | Current temperatures for tank blanket monitor. Not displayed if heat zone is not enabled.       |
|  | Current and setpoint temperatures for chiller. Not displayed if heat zone is not enabled.       |
|  | Current temperatures for chiller monitor. Not displayed if heat zone is not enabled.            |
|  | Amount of material moved through pump (volume tracking)   |
|  | Cycles  |
|  | Activates the PrePoly Refresh   |



# Appendix B - ADM Setup Screens Overview

The ADM will start in the Run screens at the “Home” screen. From the Run screens, press  to access the Setup screens. If the Setup screens password is turned on, use the ADM keypad to enter the password then press .

From the Setup screens, press  to access the Run screens. For Run screens information, see **Technical Data** on page 118. FIG. 27 shows the flow of the Setup screens.



\* Gateway screen will automatically be enabled when a CGM is installed on the system


**FIG. 27: Setup Screens Navigation Diagram**


### Shots Screen

This screen allows the user to edit shot definitions. The contents of this screen change based on the flow units selection. Shots are defined by flow rate and weight or time (duration). See **Home Screen, Shot Mode** on page 72 for information on how to use predefined shots.


**NOTE:** 100 shot definitions are available across ten pages.

To edit a shot definition:



1. Press  then use the arrow keys to navigate to the desired value.



| Shot # | Flow Rate (cc/s) | Volume (cc) | Delta (cc) |
|--------|------------------|-------------|------------|
| 1      | 75.0             | 75.0        | + 2.5      |
| 2      | 0.0              | 0.0         | + 0.0      |
| 3      | 0.0              | 0.0         | + 0.0      |
| 4      | 0.0              | 0.0         | + 0.0      |
| 5      | 0.0              | 0.0         | + 0.0      |
| 6      | 0.0              | 0.0         | + 0.0      |
| 7      | 0.0              | 0.0         | + 0.0      |
| 8      | 0.0              | 0.0         | + 0.0      |
| 9      | 0.0              | 0.0         | + 0.0      |
| 10     | 0.0              | 0.0         | + 0.0      |



| Shot # | Flow Rate (cc/s) | Volume (cc) | Delta (cc) |
|--------|------------------|-------------|------------|
| 1      | 75.0             | 75.0        | + 2.5      |
| 2      | 0.0              | 0.0         | + 0.0      |
| 3      | 0.0              | 0.0         | + 0.0      |
| 4      | 0.0              | 0.0         | + 0.0      |
| 5      | 0.0              | 0.0         | + 0.0      |
| 6      | 0.0              | 0.0         | + 0.0      |
| 7      | 0.0              | 0.0         | + 0.0      |
| 8      | 0.0              | 0.0         | + 0.0      |
| 9      | 0.0              | 0.0         | + 0.0      |
| 10     | 0.0              | 0.0         | + 0.0      |


2. Type the new value then press  to accept the new value.
3. If desired, press  to quickly enter the same value for the rate and time/volume/weight.
4. Repeat step 2 as required.

Due to variation in material properties, the  $\Delta$  column gives the ability to adjust the shot time/volume/weight for each defined shot.

**NOTE:** If the  $\Delta$  column is used, it is recommended that a minimum of 5 shots are dispensed, measured and averaged for each dispense before entering a value for the  $\Delta$  column.

### Time Based Example:

A 75 cc/s shot is defined to dispense for 2 seconds.



| Shot # | Flow Rate (cc/s) | Time (s) | Delta (s) |
|--------|------------------|----------|-----------|
| 1      | 75.0             | 2.00     | + 0.00    |
| 2      | 0.0              | 0.00     | + 0.00    |
| 3      | 0.0              | 0.00     | + 0.00    |
| 4      | 0.0              | 0.00     | + 0.00    |
| 5      | 0.0              | 0.00     | + 0.00    |
| 6      | 0.0              | 0.00     | + 0.00    |
| 7      | 0.0              | 0.00     | + 0.00    |
| 8      | 0.0              | 0.00     | + 0.00    |
| 9      | 0.0              | 0.00     | + 0.00    |
| 10     | 0.0              | 0.00     | + 0.00    |

1. Dispense 5 shots into 5 separate containers.
2. Measure the dispensed amount and record the data.

| Shot | Example 1<br>Dispensed Volume<br>(cc) | Example 2<br>Dispensed Volume<br>(cc) |
|------|---------------------------------------|---------------------------------------|
| 1    | 146.2                                 | 156.2                                 |
| 2    | 146.4                                 | 156.4                                 |
| 3    | 145.6                                 | 155.6                                 |
| 4    | 145.8                                 | 155.8                                 |
| 5    | 146.0                                 | 156.0                                 |

3. Calculate the average of the 5 shots.  
Example 1 = 146cc  
Example 2 = 156cc

- Use the following formula to calculate the  $\Delta$  column value.

$$\frac{((\text{Flow Rate} \times \text{Time}) - \text{Average Volume})}{\text{Flow Rate}}$$

**Example 1:**

$$\frac{((75\text{cc/sec} \times 2\text{sec}) - 146\text{cc})}{75 \text{ cc/sec}} = 0.053 \text{ sec}$$

**Example 2:**

$$\frac{((75\text{cc/sec} \times 2\text{sec}) - 156\text{cc})}{75 \text{ cc/sec}} = -0.08 \text{ sec}$$

- Enter the calculated value in the  $\Delta$  column.

**Example 1:**

| Shot | Flow Rate (cc/s) | Time (s) | $\Delta$ (s) |
|------|------------------|----------|--------------|
| 1    | 75.0             | 2.00     | +0.05        |
| 2    | 0.0              | 0.00     | +0.00        |
| 3    | 0.0              | 0.00     | +0.00        |
| 4    | 0.0              | 0.00     | +0.00        |
| 5    | 0.0              | 0.00     | +0.00        |
| 6    | 0.0              | 0.00     | +0.00        |
| 7    | 0.0              | 0.00     | +0.00        |
| 8    | 0.0              | 0.00     | +0.00        |
| 9    | 0.0              | 0.00     | +0.00        |
| 10   | 0.0              | 0.00     | +0.00        |

**Example 2:**

| Shot | Flow Rate (cc/s) | Time (s) | $\Delta$ (s) |
|------|------------------|----------|--------------|
| 1    | 75.0             | 2.00     | -0.08        |
| 2    | 75.0             | 0.00     | +0.00        |
| 3    | 75.0             | 0.00     | +0.00        |
| 4    | 0.0              | 0.00     | +0.00        |
| 5    | 0.0              | 0.00     | +0.00        |
| 6    | 0.0              | 0.00     | +0.00        |
| 7    | 0.0              | 0.00     | +0.00        |
| 8    | 0.0              | 0.00     | +0.00        |
| 9    | 0.0              | 0.00     | +0.00        |
| 10   | 0.0              | 0.00     | +0.00        |

**NOTE:** Depending on the dispensed volume average, the  $\Delta$  column may be either a positive or negative value.

**Volume/Weight Based Example:**

A 75 cc/s shot is defined to dispense for 75 cc.

| Shot | Flow Rate (cc/s) | Dispensed Volume (cc) | $\Delta$ (cc) |
|------|------------------|-----------------------|---------------|
| 1    | 75.0             | 75.0                  | +0.0          |
| 2    | 0.0              | 0.0                   | +0.0          |
| 3    | 0.0              | 0.0                   | +0.0          |
| 4    | 0.0              | 0.0                   | +0.0          |
| 5    | 0.0              | 0.0                   | +0.0          |
| 6    | 0.0              | 0.0                   | +0.0          |
| 7    | 0.0              | 0.0                   | +0.0          |
| 8    | 0.0              | 0.0                   | +0.0          |
| 9    | 0.0              | 0.0                   | +0.0          |
| 10   | 0.0              | 0.0                   | +0.0          |

- Dispense 5 shots into 5 separate containers.
- Measure the dispensed amount and record the data.

| Shot | Example 3 Dispensed Volume (cc) |
|------|---------------------------------|
| 1    | 72.2                            |
| 2    | 72.4                            |
| 3    | 72.6                            |
| 4    | 72.8                            |
| 5    | 72.5                            |

- Calculate the average of the 5 shots.  
Example 3 = 72.5cc
- Use the following formula to calculate the  $\Delta$  column value.

$$(\text{Requested Amount} - \text{Actual Amount})$$

**Example 3:**

$$(75\text{cc} - 72.5\text{cc} = 2.5\text{cc})$$

- Enter the calculated value in the  $\Delta$  column.

**Example 3:**

|    | Shot Size | Pump Rate (cc/s) | Shot Weight (cc) | Offset (cc) |
|----|-----------|------------------|------------------|-------------|
| 1  | 75.0      | 75.0             | + 2.5            |             |
| 2  | 0.0       | 0.0              | + 0.0            |             |
| 3  | 0.0       | 0.0              | + 0.0            |             |
| 4  | 0.0       | 0.0              | + 0.0            |             |
| 5  | 0.0       | 0.0              | + 0.0            |             |
| 6  | 0.0       | 0.0              | + 0.0            |             |
| 7  | 0.0       | 0.0              | + 0.0            |             |
| 8  | 0.0       | 0.0              | + 0.0            |             |
| 9  | 0.0       | 0.0              | + 0.0            |             |
| 10 | 0.0       | 0.0              | + 0.0            |             |

**Shot Calibration Table**

This screen allows the user to set the offset,  $\Delta(g)$ , for a calculated range of shot sizes based on pump sizes and material specific gravity.

**NOTE:** This table is only available when defining the shot by weight.

Setpoint: 75.0 cc/s

| Shot Size | Offset | Shot Size | Offset |
|-----------|--------|-----------|--------|
| 11-15 +   | 1.0    | 73-106 +  | 7.0    |
| 16-18 +   | 2.0    | 107-145 + | 8.0    |
| 19-27 +   | 3.0    | 146-187 + | 9.0    |
| 28-41 +   | 4.0    | 188-280 + | 10.0   |
| 42-54 +   | 5.0    | 281-354 + | 11.0   |
| 55-72 +   | 6.0    | 355+ +    | 12.0   |

To enable the shot calibration table:

- Navigate to **Advanced Screen 4**.

|                                     |                                 |
|-------------------------------------|---------------------------------|
| <input type="checkbox"/>            | Enable Diagnostic Screen        |
| <input type="checkbox"/>            | Low Material Disables Dispense  |
| <input type="checkbox"/>            | Limit Rate on Stall to Pressure |
| <input checked="" type="checkbox"/> | Enable Range Calibration        |
| <input type="checkbox"/>            | Enable Prepoly Refresh          |
| <input type="checkbox"/>            | Enable Leak Detection           |
| <hr/>                               |                                 |
| <input checked="" type="checkbox"/> | Enable Downloading of USB Logs  |
| <input type="checkbox"/>            | Enable USB Errors:              |
| Date of Last Download:              | 08/16/13                        |

- Press then use the arrow keys to navigate to the “Enable Range Calibration” option.

- Press to activate the option.

To edit a shot definition:

- Navigate to **Shots Screen**.

|    | Shot Size | Pump Rate (cc/s) | Shot Weight (g) | Offset (g) |
|----|-----------|------------------|-----------------|------------|
| 1  | 75.0      | 12.0             | + 1.0           |            |
| 2  | 0.0       | 1.0              | + 12.0          |            |
| 3  | 0.0       | 1.0              | + 12.0          |            |
| 4  | 0.0       | 1.0              | + 12.0          |            |
| 5  | 0.0       | 0.0              | + 0.0           |            |
| 6  | 0.0       | 0.0              | + 0.0           |            |
| 7  | 0.0       | 0.0              | + 0.0           |            |
| 8  | 0.0       | 0.0              | + 0.0           |            |
| 9  | 0.0       | 0.0              | + 0.0           |            |
| 10 | 0.0       | 0.0              | + 0.0           |            |

- Press to enter the screen.
- Press to show the shot calibration table.
- Press then use the arrow keys to navigate to the desired value.

Setpoint: 75.0 cc/s

| Shot Size | Offset | Shot Size | Offset |
|-----------|--------|-----------|--------|
| 11-15 +   | 1.0    | 73-106 +  | 7.0    |
| 16-18 +   | 2.0    | 107-145 + | 8.0    |
| 19-27 +   | 3.0    | 146-187 + | 9.0    |
| 28-41 +   | 4.0    | 188-280 + | 10.0   |
| 42-54 +   | 5.0    | 281-354 + | 11.0   |
| 55-72 +   | 6.0    | 355+ +    | 12.0   |

- Type the new value then press to accept the new value.
- Repeat as required for other ranges.

**Weight Based Example Using Shot Calibration Table:**

**NOTE:** The offset needs to be determined for each range and may need to be modified if the flow rate changes. Visit [www.graco.com](http://www.graco.com) and search for PKE “Shot Calibration Table Worksheet” to assist in the calculations for the following procedure.

**NOTE:** Offset ranges are dependent on material ratio and material specific gravity. The values shown are for reference only.

1. Dispense five shots into separate containers for an average range.
2. Measure the amount for each shot size and record the data.
3. Repeat steps 1 and 2 for all twelve ranges.
4. Calculate the average for each range and record the data.

$$\frac{(Shot1 + Shot2 + Shot3 + Shot4 + Shot5)}{5}$$

5. Calculate the offset of each shot size and record the data.

$$Target\ Shot\ Size - Average\ Shot\ Size$$

6. Enter the offset into the table.

| Shot Size | Offset | Shot Size | Offset |
|-----------|--------|-----------|--------|
| 11-15     | 1.0    | 73-106    | 7.0    |
| 16-18     | 2.0    | 107-145   | 8.0    |
| 19-27     | 3.0    | 146-187   | 9.0    |
| 28-41     | 4.0    | 188-280   | 10.0   |
| 42-54     | 5.0    | 281-354   | 11.0   |
| 55-72     | 6.0    | 355+      | 12.0   |

7. Repeat steps 1 through 6 for more precise offsets.

**Example:**

| Step Ref. | Shot Number       | Range: 11-15g<br>Target Shot Size: 13g |
|-----------|-------------------|--|
| 1,2       | Shot 1            | 11.600                                 |
| 1,2       | Shot 2            | 12.200                                 |
| 1,2       | Shot 3            | 12.400                                 |
| 1,2       | Shot 4            | 11.900                                 |
| 1,2       | Shot 5            | 12.000                                 |
| 4         | Average Shot Size | 12.02                                  |
| 5         | Offset            | 0.98                                   |

**Sequences Screen**

These screens allow the user to select a sequence of shot numbers or recipe numbers previously defined in the Shot screens. After a sequence is defined, the user can dispense the sequence starting from the first position containing a shot number, and ending with the last position containing a non-zero number. The Sequence screens will only allow the user to select a shot number previously defined in the Shot screens. Shot numbers containing blank data will not be available for selection in a sequence. Blank positions (containing a 0) in sequence will be skipped by the HFR sequence logic. For example, sequence “Y” in the screen shown below will dispense shot numbers 11, 12, 13, 14, 15, and end with 16 if executed completely.


See **Home Screen, Sequence Mode** on page 73 for information on how to use predefined sequences.





**NOTE:** 26 (A-Z) sequences with up to 20 positions each are available across 52 pages.

**NOTE:** Sequence positions are made from shots defined in the **Shots Screen**.

To edit a sequence:

1. Press then use the arrow keys to navigate to the desired value.

2. Type the new value then press  to accept the new value.




| 08/18/20 16:11  |   |   |  |
|---|---|---|--|
| ← Shots Sequences Calibration →   |   |   |  |
| Sequence No Active Errors   |   |   |  |
|  |   |   |  |
|   |  |  |  (cc) |
| Y1  | 11  |   | 101.0  |
| Y2  | 12  |   | 102.0  |
| Y3  | 13  |   | 103.0  |
| Y4  | 14  |   | 104.0  |
| Y5  | 15  |   | 105.0  |
| Y6  | 0   | 0   |  |
| Y7  | 0   | 0   |  |
| Y8  | 0   | 0   |  |
| Y9  | 16  |   | 106.0  |
| Y10   | 0   | 0   |  |

### Calibration Screen, Main


This screen shows calibration information for the system and provides access to other calibration screens. See **Calibrate HFR** on page 37 for how to use the calibration screens to calibrate the machine.

The date next to each key represents the last time that calibration was performed.

The “Cal. Min” and “Cal. Max” values are the system recognized extreme ends of piston travel. See **Calibration Screen, Learn Mode**.

| 01/07/16 12:47  |                    |                      |  |
|---|--------------------|----------------------|--|
| ← Sequences Calibration System →  |                    |                      |  |
| Standby No Active Errors  |                    |                      |  |
|  | Previous: --/--/-- |                      |  |
|   | Cal. Max: 9000     | Range: 10200 - 12600 |  |
|   | Cal. Min: 4500     | Range: 1600 - 4000   |  |
|  | Previous: 09/17/13 |                      |  |
|  | Erase Control Data |                      |  |


Press  to go to the **Calibration Screen, Learn Mode** screen.

Press  to erase the motor control database in the motor control module.

### Calibration Screen, Learn Mode

This screen allows the user to calibrate piston position. The piston can be moved to the left and right to obtain the full range of motion. See **Calibrate HFR** on page 37 for how to use this screen to calibrate the machine.


*Current position*



*Previously saved left position*      *Previously saved right position*

Press  and then  to move the pump all the way to the left.

Press  and then  to move the pump all the way to the right.

Press  to return to the **Calibration Screen, Main**. This saves the new left and right numbers.

### System Screen 1

This screen allows the user to set important system settings. Control Mode can be set to Flow. With Control Mode set to Flow, the machine will dispense at a continuous flow rate regardless of pressure fluctuations unless pressure alarm conditions occur.


Dispense Mode can be set to Time, Volume, and Weight. Dispense Mode controls how displayed amounts are measured. See **Calibrate HFR** on page 37 for more information.

Pump sizes and inlet pressures must be entered on this screen.

| NOTICE   |
|--|
| If pump sizes and inlet pressures are not entered properly, system performance will be affected. |

The inlet pressure must be set to the maximum feed pressure that will be seen by that side of the machine.


The maximum working pressure for the machine is displayed on this screen. The maximum working pressure is dependent on the installed hoses and dispense valve. The maximum working pressure is set to the lowest rated system component. If 2000 psi hoses are installed and the maximum working pressure displayed is not 2000 psi, see manual 313998 for instructions to set the maximum working pressure for hoses. If the installed dispense valve rating is below the maximum working pressure shown here, verify the correct dispense valve is selected on System Screen 2.





### System Screen 2

This screen allows the user to set which items are installed on the machine.

The hydraulic level sensor and hydraulic RTD for both the pump line and mix head must be marked as enabled when installed in the system. If the sensors are not marked as enabled, they will be ignored by the machine controls.

Select the dispense valve installed in the system. This selection is critical to ensure proper operation of the machine. When a mix head is selected,  button will

become active when the  is pressed. When active, pressing this button will open a screen used to define the mix head operating parameters. See the **Mix Head Operating Details Screen** on page 60.




Post Dispense Shot Disable is a feature where the user can disable shot requests for zero to five seconds after the completion of a dispense. This feature is not applicable for P2/Fusion Dispense Valves. This feature can not be active if the Pre Dispense Delay feature is active.


Pre Dispense Delay is a feature where the HFR can delay the start of a dispense until the user has pressed and held the foot switch for the duration entered. For example, if the user enters a five second duration, the footswitch must be held on continuously for five seconds before the HFR will start a dispense. This feature is not available for recirculation systems or applicable for P2/Fusion Dispense Valve applications. This feature can not be active if the Post Dispense Shot Disable feature is active.

### Mix Head Operating Details Screen

This screen allows the user to define the mix head operating parameters.

- **Low Pressure Circulation:** The percentage of set-point, 10%-90%, at which the system will run during low pressure circulation.
- **Pre-Dispense Circulation:** The time for which the system will circulate at high pressure prior to dispensing when the dispense command is triggered while the system is in low pressure circulation.
- **Post-Dispense Circulation:** The time duration that the system will remain in high pressure circulation after a dispense before dropping into low pressure circulation. Entering “0” disables the post-dispense time.






Press  to go back to the **System Screen 2**.

### System Screen 3

This screen allows the user to edit the labels for the A (Red) and B (Blue) sides of the machine. The labels set for the A (Red) and B (Blue) sides of the machine are displayed throughout the screens. Labels are limited to five characters.

To edit a label:


1. Press .
2. **To edit the A (Red) label,** press . **To edit the B (Blue) label,** press the down arrow then press . The keyboard will appear on the screen. See **Keyboard Screen** on page 61.

The pressure imbalance setting is set from this screen. Pressure imbalance is the allowable difference in pressure between the two materials before an alarm is triggered. The input range is 145-2000 psi (1-14 MPa, 10-138 bar).

The flowmeter types are defined on this screen. The ratio deviation value is the allowable percentage before the machine displays a pop-up notification. The ratio alarm value is the allowable percentage difference before the machine will stop a dispense.

The ratio displayed between chemicals can be changed between blue or red, allowing either chemical to be displayed as a ratio to 1.


This screen allows the user to enter material specific gravities.










*Pressure Imbalance Setting*




### Keyboard Screen


This screen is used to edit the A (Red) and B (Blue) labels on the ADM. Use arrow keys to select the desired letter and press  to accept the letter.





1. Use arrow keys to select the desired letter and press  to accept the letter. To erase all text, press . To delete one letter, press . To move the cursor one letter to the left, press . To move the cursor one letter to the right, press . To toggle the letters from upper/lower case, press .



2. When finished entering the new label, press .



### Maintenance Screen

This screen shows shot number, sequence position, dispense valve, and accumulator charge cycle counters. Press  and navigate to the drop down box.

Press  and scroll to a range of counters to view.

Press  again to select the range of counters and display them on the screen.

Counters may be erased individually. Navigate to the counter you want to erase and press . Alternatively, each counter displayed on the page may be erased simultaneously by pressing .




## Supply Screen

This screen allows the user to specify the operating parameters for off-board, integrated tanks and indicate which positions have level sensors installed. See the Tank Feed Systems manual for information about installing level sensors, see **Related Manuals** on page 3. The user may select from the following refill settings: Disabled, Monitor, Manual, Auto Top-Off, Auto Full-Volume.

**NOTE:** Use the “Disabled” setting if off-board tanks are not installed.

- Manual refill will run until either the high level sensor sees material, the user aborts the refill via the refill button on the run screens, or the refill time-out expires
- The low level alarm will clear when the condition clears



The following describes system operation when each tank mode is selected.

- **Disabled**
  - Disables tank operation
- **Monitor (2 Sensors)**
  - The top sensor generates a high level deviation and the bottom sensor generates a low level alarm
  - Refill is not supported, no button is provided on the run screens to initiate refill
  - Errors will clear when the corresponding condition clears
- **Manual (2 Sensors)**
  - The top sensor generates a high level deviation and the bottom sensor generates a low level alarm
  - A button is provided to the user on the run screens to initiate a manual refill operation at any time

- **Monitor (3 Sensors)**
  - Same as **Monitor (2 Sensors)** section, except that a filled condition is considered as material filled up to the second or middle sensor
- **Manual (3 Sensors)**
  - Same as **Manual (2 Sensors)** section, except that a filled condition is considered as material filled up to the second or middle sensor. Refill operations will fill to middle sensor, and material reaching the top or third sensor is considered a high level deviation
- **Auto Top-Off (2 or 3 Sensors)**
  - The low level sensor will generate a low level alarm
  - *Two level sensors installed:* When the high level sensor does not see material, automatic refill will begin and continue until either the high level sensor sees material or until the refill time-out expires
  - *Three level sensors installed:* When the middle level sensor does not see material, automatic refill will begin and continue until either the middle level sensor sees material or until the refill time-out expires
  - The low level alarm will clear when the condition clears
  - A button is provided to the user on the run screens to initiate an automatic refill operation at any time, this button can also be used to abort a refill operation
- **Auto Full-Volume (2 Sensors)**
  - The low level sensor will initiate an automatic refill when it does not see material
  - Automatic refill will continue until either the high level sensor sees material or until the refill time-out expires
  - The low level alarm will clear when the condition clears
  - A button is provided to the user on the run screens to initiate an automatic refill operation at any time, this button can also be used to abort a refill operation
- **Report Red (or Blue) High level in bit 2**
  - If active (checked ) the HFR (or NVH) will report a full tank high level condition (top sensor detects material) as a 7, rather than 3 (bit 2 set rather than cleared) over the field bus automation interface.

If a refill setting other than Disabled is selected, the user must set at least two level sensor locations as installed by checking the check box on the screen. If all three locations are set to installed, the system will default to the Auto-Top Off refill setting and operate as follows:

- The low level sensor will generate a low level alarm.
- The high level sensor will generate a high level deviation and abort any automatic refill operation.
- When the middle sensor is not satisfied, automatic refill will begin and will run until either the middle sensor is satisfied, the high level sensor generates a deviation (if the middle sensor fails), or the refill time-out expires.
- The low level alarm and the high level deviation will clear when the condition clears.
- A button is provided to the user on the Run screens to initiate an automatic refill operation at any time. This button can also be used to abort a refill operation.

#### *Refill Timeout*

The refill time-out setting may be set by the user as a means to abort the refill in the case of a high level sensor failure. When an automatic refill begins, the time-out counter will begin to count down. If the timer expires before the high level sensor is triggered, the refill will abort. A refill must be manually started to enable auto refills again.

#### *Refill Sensor Type*

The Low-Temp Sensor setting limits tank temperatures to 150°F (66°C). And the High-Temp Sensor setting limits tank temperatures to 190°F (88°C).

#### **NOTICE**


If you are using low temperature sensors and select the High-Temp Sensor setting and set the temperature above 150°F (66°C), damage to the level sensors will occur.

#### *Refill Setting*

### Conditioning Screen 1

This screen allows the user to select which temperature conditioning components are installed in the system.


Check the box next to the component type for the appropriate side of the system to indicate that a component is installed. A maximum of four components and two monitoring zones may be selected.



### Conditioning Screen 2

This screen shows the fluid path for the temperature conditioning components and temperature setpoints for each component.


**NOTE:** If tank blanket heaters or inline heaters are installed along with hose heat, the hose heat setting will be limited to at or below the inline or tank heat setting.




**NOTE:** All components are shown installed for reference only. Only 4 components and two monitoring zones can be installed at one time.

To edit the temperature setpoint and alarms for a particular component:

1. Press then use the arrow keys to navigate to the component you wish to edit.



2. Press to display the setpoint and alarm values associated with that component.




3. Edit the setpoint and alarm values and then press to return to **Conditioning Screen 2**.

**NOTE:** The high alarm and low alarm values must be at least +/-9°F (5°C) than the material temperature value.

### Conditioning Screen 3


This screen allows the user to configure Night Mode operation. In Night Mode, the system will cycle on and

off periodically or turn on at a preset time. Press  and select periodic or time schemes.

When the system is in Night Mode and in an “On” cycle, the system will circulate in low pressure. The installed conditioning zones will be on and controlling to their respective setpoints. When the system is in Night Mode and in an “Off” cycle, the system will be idle. The system will not be circulating and the conditioning zones will not be actively controlling temperature. When in Night Mode, supply tanks will not fill.


#### Periodic Night Mode Conditioning Screen

This screen allows the user to set the on and off times of the machine in one minute intervals.






#### Time Based Night Mode Conditioning Screen

This screen allows the user to set a specific time each day to turn the machine on or off. The times can be set on or off by either each day separately, Monday through Friday where each day has the same on or off times, or Sunday through Saturday where each day has the same on or off times.



To set the on/off machine times:

1. Press  to enter the screen.
2. Press left or right arrow keys to highlight the day selection column. Continue to press the left or right arrow keys to select the desired day, work week (Monday thru Friday), or full week (Sunday thru Saturday) duration.
3. Press the up or down arrow keys to select the desired hour to schedule the on or off machine times.
4. Press  to enter the selected hour and select the desired time (15 minute increments) for either machine on or off to occur.
5. Press  and select either on or off for the time duration selected.

| Bar Color | Description                   |
|-----------|-------------------------------|
| Green     | Machine is ON                 |
| Red       | Machine is OFF                |
| Blue      | Machine PrePoly Refresh Start |

6. To erase times, repeat steps 1 thru 3 and press



once the desired time duration has been selected.

**NOTE:** If times are entered in the weekly schedule, individual days can not be erased.

**NOTE:** Set the Prepoly Timeout one minute beyond the time it takes for the material to reach the middle sensor.

### Cold Start Up Mode

Allows the user to select what mode the machine will enter once the cold start-up is complete. Selecting no change will leave the machine in either standby or night modes circulating at the set low pressure percentage.

### Auto High Pressure

Changes the machine to high pressure circulation when the mode is changed from either standby or night modes.

### Calendar Time Based Night Mode Conditioning Screen

This screen shows a summary of Time Based Night Mode on or off times that were set by the **Time Based Night Mode Conditioning Screen**.

|       | Mon | Tue | Wed | Thu | Fri | Sat | Sun |
|-------|-----|-----|-----|-----|-----|-----|-----|
| 1:00  |     |     |     |     |     |     |     |
| 3:00  |     |     |     |     |     |     |     |
| 5:00  |     |     |     |     |     |     |     |
| 7:00  |     |     |     |     |     |     |     |
| 9:00  |     |     |     |     |     |     |     |
| 11:00 |     |     |     |     |     |     |     |
| 13:00 |     |     |     |     |     |     |     |
| 15:00 |     |     |     |     |     |     |     |
| 17:00 |     |     |     |     |     |     |     |
| 19:00 |     |     |     |     |     |     |     |
| 21:00 |     |     |     |     |     |     |     |
| 23:00 |     |     |     |     |     |     |     |

### Advanced Screen 1

This screen allows the user to set the language, date format, current date, time, setup screens password, screen saver delay, and turn on or off silent mode.

08/18/11 10:53 Conditioning Advanced Shots

Night No Active Errors

Language: English

Date Format: mm/dd/yy

Date: 08 / 18 / 11

Time: 10 : 53

Password: 0000

Screen Saver: 5 minutes

Silent Mode:

- **Time:** formatted in 24 hour time.
- **Password:** Enables the setup screens to be password protected. Entering "0000" disables the feature.
- **Screen Saver:** Enter the amount of time until the backlight turns off. Entering "0" leave it constantly on.
- **Silent Mode:** Check this box to turn off the buzzer for key presses.

### Advanced Screen 2

This screen allows the user to set the units of measure.

01/12/10 12:58 Conditioning Advanced Shots

Shot No Active Errors

Volume Units: cc

Weight Units: g


Pressure Units: psi

Temperature Units: PF

Flow Units: Weight

Rate Units: /second

## Advanced Screen 3



This screen allows the user to control the availability of some key system features.

- Disable Dispensing From Display:** Check this box to disable dispensing from the ADM. A footswitch, dispense valve trigger, or other external signal will be the only way to initiate a dispense.
- Disable Modifying Temp Setpoint:** Check this box to disable modifying temperature setpoints from the Run screens. This is only applicable if temperature control items are installed and enabled.
- Disable Operator Mode Adjustments:** When this box is checked, the user will not be able to adjust the dispense settings in Operator Mode.
- Temperature Alarm Disables Dispense:** When this box is checked, the system will reject dispense requests when any enabled heat/chiller zones are below/above their setpoint. The HFR will also generate a warning advisory if the user dispenses with a heat zone off while this feature is on.
- Enable Operator Mode Cavitation Alarm:** Check this box to enable cavitation alarms in Operator Mode. Clear this box to disable cavitation alarms in Operator Mode.
- Complete Dispense with Setpoint Error:** When this box is checked, the shot will continue dispensing even if the system never reaches the desired setpoint (flow or pressure).
- Cavitation Errors Disabled:** When this box is checked, the Cavitation error generation logic within the HFR or NVH product will be turned OFF (not recommended for production use). If a cavitation error is generated, it informs the user that one of the HFR pumps may not have properly filled, and the ratio of the two materials may not be correct. When the state of this control is changed, an ECC1 event (“Cavitation Errors ON”) or an ECC0 event (“Cavitation Errors OFF”) will be generated on the event screen and the USB logging function.
- Stop Dispense with Cavitation Error:** This control will be enabled (Not Greyed out) when the Cavitation Errors Disabled control is not checked. When this control is active and checked, the HFR or NVR system will stop dispensing if a cavitation error is generated and the dispense and material is exiting the dispense valve. If the control is not checked, the cavitation error pop-up window will display but the dispense will continue.



- **Micro Motion Enabled:** If checked (default is NOT checked), the HFR will be capable of producing low flows down to 0.16 cycles/minute, from the default low rate of 3 cycles/minute.

**NOTE:** If the HFR is in pressure mode, the selection is not relevant.

If the resultant low flow selection produces HFR motor speeds less than 100 RPM or results in motor stator currents less than 1.0 Amps RMS, the selected flow may become unstable (as displayed on the Diagnostic Run Screen to the left of the home run screen, during a dispense). If this situation is present, more material restriction or a higher flow selection may be required. The motor speed can be monitored on the Diagnostic Run screen, which must be enabled or turned ON by checking the “Enable Diagnostic Screen” option on the Advanced #4 setup screen.

- **2x Trigger For Dispense:** When this box is checked, the machine will require a double trigger pull to initiate dispensing in shot or sequence mode.
- **Dispense from Home Position:** When this box is checked, the machine will be required to reach a defined home position before dispensing in shot or sequence mode.
- **Disable Setpoint Not Reached Error:** Checking or enabling this option will turn off the generation of Set point Not Reached deviations, which may occur if the flow rate entered for the machine is a low value.

- **Enable Diagnostic Screen:** Check this box to enable the optional ADM screens, enabling USB log downloading, and erasing USB logs. For more information about USB operation, see **Appendix F - USB Operation** on page 92. For more information about the optional screens, see **Diagnostic** screen on page 76.

- **Low Material Disables Dispense:** When this box is checked, the current dispense will terminate and prevent additional dispenses when the supply system indicates a low level.

- **Limit Rate on Stall to Pressure:** Check this box to enable Limit Rate on Stall to Pressure. This will slow the rate of pressure rise on a stall to pressure system.

- **Enable Range Calibration:** Check this box to enable Range Calibration. This creates a range of shot offsets in a table based on the size of the shot. The user must calibrate each range at the specified flow rate. If the flow rate is changed, the table must be recalibrated.

- **Enable PrePoly Refresh:** Check this box to enable Prepoly Refresh. A Prepoly refresh will initiate a cold start, heat the system to a specified temperature (**Conditioning Screen 3**), empty the prepoly tank to the low level sensor and refill the tank. When enabled, either the user may initiate a refresh manually or through a scheduled task.

- **Night Mode, Disabled, or Standby Modes:** Automatic refills are disabled. If the material level drops below the low level sensor, a low level alarm is thrown.
- **Shot, Operator or Sequence Modes:** The system will monitor the amount of automatic refills requested after the last shot has been taken. If the system sees two refills without dispensing, the system will generate a leak detection warning and disable the system. The system must be completely powered down to clear the error.

- **Enable Leak Detection:** Check this box to enable Leak Detection. Leak detection is intended for catastrophic leaks only. It requires a Graco auto fill control to be enabled and working. Leak detection is not active during dispense.

**Advanced Screen 4**





- Red Tank Leak detect On and Blue Tank leak Detect On:** These controls will become enabled (not greyed out) if the corresponding tank system is online. If the function is enabled (checked) the tank stand logic will generate a leak error if more than two automatic fill operations occur, and no dispenses have occurred during that time.
- Use ADM to Program Token:** If checked, the user will be able to update the system software by using the ADM to program a token, as described in **Programming Tokens/Updating System Software** section page 46.

**Advanced Screen 5**

| 04/22/21 13:57             | Advanced             | Gateway          |
|----------------------------|----------------------|------------------|
| Standby                    | No Active Errors     |                  |
| Module                     | Software Part Number | Software Version |
| System                     | 16H822               | 1.13.005         |
| Advanced Display           | 16E122               | 1.18.032         |
| USB Configuration          | 16G102               | 1.11.002         |
| MCM Application Blue       | 15Y820               | 1.13.022         |
| MCM Component Blue         | 16C014               | 1.09.012         |
| Blue Primary Heat          | 15M871               | 1.07.005         |
| Blue Tank Monitor          | 16A206               | 1.05.012         |
| Ratio/ Inlet Pressure Mon. | 16D755               | 1.01.013         |
| Gateway                    | 17P796               | 3.01.004         |

Numbers shown are for reference only and may be different on your system.

This screen displays software information.

**Advanced Screen 6**

|                                     |                                     |          |
|-------------------------------------|-------------------------------------|----------|
| 03/28/22 16:53                      | Advanced                            | Gateway  |
| Night                               | No Active Errors                    |          |
|                                     | Controlling/ Stall Pump             | Auto     |
|                                     | Maximum DV Response                 | 25 mS    |
|                                     | Minimum Stall to Pressure           | 86 %     |
| Recirculation Options               |                                     |          |
| <input type="checkbox"/>            | Tap to High Pressure Recirculation  |          |
| <input checked="" type="checkbox"/> | HFR Recirculation Valves Installed  |          |
| <input type="checkbox"/>            | Auto Pressurize After Recirculation |          |
|                                     | Maximum Recirculation Pressure      | 34.5 bar |
| <input checked="" type="checkbox"/> | Auto Circulate Between Dispenses    |          |
| <input checked="" type="checkbox"/> | Pressurize Before Opening DV        |          |
|                                     | Maximum Pressurize Time             | 3000 mS  |

**Tap to High Pressure Recirculation** – This feature if checked (default is NOT checked), will command the HFR to interpret a footswitch tap as a go to high pressure recirculation mode, but will NOT dispense material

(same as pressing the “” key on the main run screen). This feature only applies to full recirculation systems (S-Head, S-Head with Prox., and L-Head dispense valve options), and is disabled if the system is NOT a full recirculation system.

Other items on this screen do not pertain to full recirculation systems and are therefore disabled.

**Advanced Screen 7**

The HFR setup Advanced #7 screen contains the following control options:

|                |                                     |                                     |
|----------------|-------------------------------------|-------------------------------------|
| 02/12/20 15:46 | Advanced                            | Gateway                             |
| Standby        | No Active Errors                    |                                     |
|                | <input type="checkbox"/>            | Disable Pressure Imbalance Alarms   |
|                | <input checked="" type="checkbox"/> | Control Dispense Ready Light        |
|                |                                     | Light Tower Options: Standard 3 Lit |
|                |                                     |                                     |

- Disable Pressure Imbalance Alarms** – Checking this option will disable the generation of pressure imbalance alarms resulting from an excessive pressure difference between the HFR Blue and Red pumps. This control is intended to make the initial installation of the HFR easier, and is typically not intended to be “checked” when the machine is used for production. This is especially true for impingement type dispense valve options (GX-16, GX-16 with Prox, L-Head) where excessive pressure differences can cause problems within the dispense valve.
- Control Dispense Ready Light** – Checking this option will reassign the I/O originally used to sense an optional hydraulic tank low level sensor to an output for driving a ready lamp. Typically a ready lamp (LED) is installed in the handle of a dispense valve.




When this function is checked or turned ON, the ready lamp will be in one of the following states:


a. **Not Ready** (Dark or OFF) - This will occur when not in a dispense mode (disable or night modes), the user is on a setup screen when idle, an alarm is active, the system is in low pressure recirculation mode or not moving (full recirculation type systems only), the system is performing a manual or semi-automatic recirculation operation (Auto Circulate Between Dispenses is OFF), or when the stall to pressure logic is OFF (Fusion/P2 dispense valve type systems only).

b. **Ready** (LED is flashing at a rate of 4 hertz) - This will occur when all conditions outlined in the previous state are NOT true, the system is idle (or in high pressure recirculation mode if using a full recirculation system), and when the system is NOT dispensing.

c. **Dispensing** (LED is ON) - This will occur when the system is actively dispensing material out of the valve, or when recirculating material through a manual or semi-automatic recirculation kit.


- **Light Tower Options** - If using the light tower option for the HFR, the user must select the correct light tower option used with their system. The Standard 3 Light and Custom Clear Lens options are currently available using the drop-down selection.
- **Blue Token Reader** – This feature is represented by the blue token graphic shown next to the bottom


left softkey graphic (  ). To enable this function, first enter the screen by pressing the top left soft key (  ). Once entered into the screen, the bottom left soft key will be enabled (  ), which allows the user to trigger a token reading.



Insert the programmed blue token into the token reader slot on the bottom right hand side of the


ADM module, then press the  key to trigger a new token read. After a token read is complete, the screen will provide the token data file part number and description.



If the data on the token is not recognizable or the token is blank, the screen will display a message reading "Token Data NOT Recognized." If another token needs read, insert the next token and trigger a read by pressing the  key.

# Appendix C - ADM Run Screens Overview





Run screens are divided into five major sections: status, errors, events, and maintenance. The following diagram demonstrates the flow of the Run screens beginning with the Home screen.



**FIG. 28: Run Screens Navigation Diagram**


## Home Screen

The Home screen is the first screen that displays in the Run screens. It shows the current fluid pressure on the A (Red) and B (Blue) fluid outlets of the pump and if there are any active errors. If tanks are installed in the system, the fill level is shown on each tank. The ratio is also displayed as either Red:1 or Blue:1 depending on which display has been setup. See **System Screen 3** on page 60.

To select an operating mode, press  repeatedly until the desired mode is shown then press  to select the mode. Alternately, press  and use the up and down arrow keys until the desired mode is shown, then press  to select the mode. The available operating modes are operator, sequence, shot, standby, night, and disabled.


## Home Screen, Disabled Mode


When this mode is selected, the machine will not be able to dispense or condition (heat/cool) material. The setup screens cannot be accessed while in Disabled mode. Use the Select mode button to exit Disabled mode.






### Home Screen, Standby Mode


In Standby Mode, the user can enable heating, park the pumps, refill the tanks, circulate materials.



Press  to change operating modes.

Press  to move the pumps all the way to the left and turns the hydraulic power pack off.




Press  or  to initiate a tank refill. If a tank is filling, pressing either button will abort the filling operation.

Press  to stop or start the hydraulic power pack and run the start-up process.


### Home Screen, Shot Mode



This mode allows the user to select one of 100 pre-defined shot numbers. See **Shots Screen** on page 54 for information about editing shot definitions.

To use a predefined shot:

1. Enter shot mode.
2. Press  and use the numeric keypad to enter the desired shot number.
3. Press  to select the shot number.
4. Press  to initiate a dispense. The system will go to high pressure mode and dispense a shot after the pre-dispense timer, see **Mix Head Operating Details Screen** on page 60, expires.

**NOTE:** There is a three second delay after a dispense before another dispense can be initiated.




5. Press  to switch between low and high pressure modes without dispensing.
6. During a dispense, press  to abort the dispense.
7. See **Home Screen, Standby Mode** on page 72 for other button functions.


### Home Screen, Sequence Mode


This mode allows the user to select one of five sequences (A-E). The progress bar on the bottom of the screen shows the progress of a shot dispensing from the selected sequence. See **Sequences Screen** on page 57 for information about editing sequence definitions.


**NOTE:** There is a three second delay after a dispense before another dispense can be initiated.

To use a predefined sequence:

1. Enter Sequence Mode.
2. Press the sequence letter/position selection button.
3. Use the left and right arrows to toggle between letter and position selection. When selecting a sequence letter (A-E), use the up and down arrow keys to scroll through the available letters. When selecting a sequence position, type in the desired position with the numeric keypad. The system will reject invalid letter/position selections.
4. Press  to accept the sequence letter/position.
5. Press the Dispense button to begin dispensing.






6. Press  to skip to the next sequence position.


7. Press  to abort the sequence.
8. See **Home Screen, Shot Mode** on page 72 for other button functions.


### Home Screen, Operator Mode

This mode allows users to set a flow rate to dispense material without using predefined shot information.

1. To edit the flow rate, press . The value to change will now be highlighted. Type the new value then press  to accept it.



2. Press  to initiate a dispense. The system will go to high pressure mode and dispense a shot after the pre-dispense timer, see **Mix Head Operating**


**Details Screen** on page 60, expires. Press the  to stop the dispense.

**NOTE:** There is a three second delay after a dispense before another dispense can be initiated.

3. If an external trigger is used, press and hold the trigger to initiate a dispense. Release the trigger to stop the dispense.
4. See **Home Screen, Shot Mode** on page 72 for other button functions.

### Home Screen, Night Mode


In Night Mode, the system will cycle on and off periodically or turn on at a preset time. Entering night mode will turn pumps and all conditioning zones off. The circulation on/off cycle begins automatically upon entering Night Mode. See **Conditioning Screen 3** on page 65.



### Status Screen

The status screen provides all of the operational functionality of the Home screen except for operating mode selection. Refer to the Home screen and operating mode descriptions for information on this functionality.

In addition to the functionality provided by the Home screen, the Status screen also provides material conditioning information and control.





### Status Screen, Conditioning Control



This screen allows users to turn on and off heat zones individually or all at once. When a zone is on it is actively controlling temperature. Refer to the table below for color code definitions.


| Zone Setting | Color  | Definition        |
|--------------|--------|-------------------|
| OFF          | Black  | Dispense Disabled |
|              | Grey   | Dispense Allowed  |
| ON           | Yellow | Dispense Disabled |
|              | Green  | Dispense Allowed  |

To turn a single zone on/off:

1. Press  to enter the Conditioning Control screen.
2. Use the arrows keys to navigate to the desired zone.
3. Press  to turn on the selected zone. When a zone is on, the button will be selected. Press the button again to turn off the zone.

To turn on/off all zones:

1. Press  to enter the Conditioning Control screen.
2. Press the  to turn on all zones. When one or more zones are on, the button will be selected. Press the button again to turn off all zones.



*All zones shown for reference. Only four zones may be active at one time.*

### Errors Screens

This screen shows users a list of errors that have occurred in the system. Each error entry includes a description and error code along with a date and time stamp. There are 5 pages, each holding 10 errors. The 50 most recent errors are shown.

Refer to the **Troubleshooting** section on page 49 for a detailed description of all of the system errors.

| 03/10/10 15:34 |       | Status           | Errors                     | Events |
|----------------|-------|------------------|----------------------------|--------|
| Shot           |       | No Active Errors |                            |        |
| Date           | Time  | Code-Class       | Description                |        |
| 03/09/10       | 16:35 | L122-D:          | Blue Low Material Level    | 3      |
| 03/09/10       | 15:05 | CAC3-A:          | Comm. Error Red Tank       | 4      |
| 03/09/10       | 15:05 | P6B2-D:          | Blue Pressure Sensor Fault | 5      |
| 03/09/10       | 15:05 | P6A1-D:          | Red Pressure Sensor Fault  | 1      |
| 03/09/10       | 15:05 | D6A1-D:          | Position Sensor Fault      | 2      |
| 03/09/10       | 15:05 | T4H1-A:          | Oil Temp. Shutdown         |        |
| 03/09/10       | 15:05 | T4N1-A:          | Motor Temp. Shutdown       |        |
| 03/09/10       | 13:48 | L122-D:          | Blue Low Material Level    |        |
| 03/09/10       | 13:47 | L122-D:          | Blue Low Material Level    |        |
| 03/09/10       | 13:44 | L122-D:          | Blue Low Material Level    |        |

### Events Screens




This screen shows users a list of events that have occurred in the system. Each event includes a description and event code along with a date and time stamp. There are 20 pages, each holding 10 events. The 200 most recent events are shown.








Refer to the **Troubleshooting** section on page 49 for a detailed description of all of the system events.

| 03/10/10 15:32 |       | Errors           | Events                  | Maintenance |
|----------------|-------|------------------|-------------------------|-------------|
| Shot           |       | No Active Errors |                         |             |
| Date           | Time  | Code-Class       | Description             |             |
| 03/09/10       | 10:09 | EM00-R:          | System Powered Off      | 6           |
| 03/08/10       | 16:14 | EQU1-R:          | Settings Downloaded     | 7           |
| 03/08/10       | 16:14 | EQU3-R:          | Language Downloaded     | 8           |
| 03/08/10       | 16:14 | EQU5-R:          | Logs Downloaded         | 9           |
| 03/08/10       | 16:13 | EA00-R:          | Disp. Occurred (Shot 2) | 10          |
| 03/08/10       | 16:13 | EA00-R:          | Disp. Occurred (Shot 2) | 11          |
| 03/08/10       | 16:13 | EA00-R:          | Disp. Occurred (Shot 2) | 12          |
| 03/08/10       | 16:13 | EA00-R:          | Disp. Occurred (Shot 2) |             |
| 03/08/10       | 16:13 | EA00-R:          | Disp. Occurred (Shot 2) |             |

### Maintenance Screen

This screen displays historical information for each pump in the system. The Batch counters are resettable and count both material usage and pump cycles. The Total counters are not resettable by the user. They also count both material usage and pump cycles. For material usage counters, units are displayed next to the volume/weight indicator icons.

To erase a batch counter, press  and navigate to the field to be erased. Press  to erase that data point. Alternatively,  may be pressed to erase all of the batch data points simultaneously.

| 01/12/10 12:41  |   | Events           | Maintenance | Home |
|---|---|------------------|-------------|------|
| Sequence  |   | No Active Errors |             |      |
|   |   | RED              | BLUE        |      |
|     |   | Batch            |             |      |
|     |  (g) | 475406           | 519589      |      |
|    |     | 23737            | 23737       |      |
|   |   | Total            |             |      |
|  | (g)   | 241650175        | 270756665   |      |
|  |   | 26959            | 26959       |      |

**NOTE:** In a circulation system, the pumpline must be stopped to erase counters.

### Optional Screens

The optional Diagnostic screen can be enabled in the **Advanced Screen 4** screen, see page 68.

#### Diagnostic

|                 |                 |                  |                 |        |
|-----------------|-----------------|------------------|-----------------|--------|
| 07/26/11 08:28  |                 | ← Maintenance    | Diagnostic      | Home → |
| Standby         |                 | No Active Errors |                 |        |
| Temperature(°F) |                 |                  |                 |        |
| IGBT<br>79      | Capacitor<br>97 | Motor<br>73      | Hydraulic<br>-- |        |
| Current (Amps)  |                 |                  |                 |        |
| BUS<br>0.0      | Phase 1<br>0.0  | Phase 2<br>0.0   | Phase 3<br>0.0  |        |
| Voltage (Volts) |                 | Speed (RPM)      |                 | PWM    |
| BUS<br>335      | Motor<br>0      | Motor<br>0       | Motor<br>0      |        |

The Diagnostic screen shows status information for various components in the Motor Control Module.



## Appendix D - ADM Error Codes

| Error Code | Error Name                 | Error Description   | Error Type | Cause                                     | Solution  |  |
|------------|----------------------------|---|------------|---|---|--|
| A4A2       | Red Hose Overcurrent       | An over current was detected on the output  |            | Bad heaters                               | Measure resistance of heater  |  |
| A4A3       | Red Inline Overcurrent     |   |            |   |   |  |
| A4A6       | Red Blanket Overcurrent    |   |            |   |   |  |
| A4A7       | Red Chiller Overcurrent    |   |            | High voltage                              | Measure voltage across the disconnect switch. Voltage should measure between 190 and 264 Vac.   |  |
| A4B1       | Blue Inline Overcurrent    |   |            | Bad heaters                               | Measure resistance of heater  |  |
| A4B4       | Blue Hose Overcurrent      |   |            |   |   |  |
| A4B5       | Blue Blanket Overcurrent   |   |            |   |   |  |
| A4B8       | Blue Chiller Overcurrent   |   |            | Shorted Temperature Control Module        | If temperature rises for a zone that has been disabled, replace Temperature Control Module  |  |
| A4H1       | Motor Over Current         | High current has been detected on a phase and has been shutdown to prevent damage | Alarm      | Bad internal wiring of the motor          | Replace motor   |  |
| A4H3       | Mix Head Motor Overload    | Excessive Current to AC Power Pack Motor.   |            | Short circuit of motor wiring             | Check wiring to the motor to ensure no bare wires are touching and that no wires are shorted to ground  |  |
|            |                            |   |            | Short circuit within AC Power Pack Motor. | Replace motor.  |  |
| A4M1       | Motor Over Current         | Too much current is being drawn from the wall                                     |            | Low voltage from the wall during load     | Make sure the supply line is properly sized for the load and is above the minimum voltage requirements  |  |
| A4N1       | Motor Over Current         | A hardware current fault has occurred causing a system shutdown                   |            | Short circuit of motor wiring             | Check wiring to the motor to ensure no bare wires are touching and that no wires are shorted to ground  |  |
|            |                            |   |            | Motor rotor has become locked             | Unplug the directional valve (so pressure will not build) and try to move the motor again. If this succeeds then the power pack may need to be replaced. If the motor is still unable to move, the bearings or hydraulic pump have likely failed in the motor and will need to be replaced. |  |
| A7A2       | Red Hose Control Fault     | Unexpected current to heater/chiller  |            |   | Shorted Temperature Control Module  | If temperature rises for a zone that has been disabled, replace Temperature Control Module |
| A7A3       | Red Inline Control Fault   |   |            |   |   |  |
| A7A6       | Red Blanket Control Fault  |   |            |   |   |  |
| A7A7       | Red Chiller Control Fault  |   |            |   |   |  |
| A7B5       | Blue Blanket Control Fault |   |            |   |   |  |
| A7B1       | Blue Inline Control Fault  |   |            |   |   |  |
| A7B4       | Blue Hose Control Fault    |   |            |   |   |  |
| A7B8       | Blue Chiller Control Fault |   |            |   |   |  |

Appendix D - ADM Error Codes

| Error Code | Error Name              | Error Description   | Error Type                    | Cause  | Solution  |                             |  |
|------------|-------------------------|---|-------------------------------|--|---|-----------------------------|--|
| A8A2       | No Red Hose Current     | No current to the conditioning zone   | Alarm                         | Tripped circuit breaker  | Visually check circuit breaker for a tripped condition  |                             |  |
| A8A3       | No Red Inline Current   |   |                               |  |   |                             |  |
| A8A6       | No Red Blanket Current  |   |                               |  |   |                             |  |
| A8B1       | No Blue Inline Current  |   |                               | Low power  | Measure voltage across input terminals on power line filter. Voltage should measure between 190 and 264 Vac         |                             |  |
| A8B4       | No Blue Hose Current    |   |                               |  |   |                             |  |
| A8B5       | No Blue Blanket Current |   |                               |  |   |                             |  |
| A8B7       | No Red Chiller Current  |   |                               |  |   | Cable unplugged/loose power | Check for loose or disconnected wires or plugs |
| A8B8       | No Blue Chiller Current |   |                               |  |   |                             |  |
| A9C1       | Motor Over Current      | A software error has occurred commanding too much current   | Bad Motor Control Module code | Check for MCM software update, load latest MCM software, if problem persists contact Graco |   |                             |  |
| B9C0       | Small Shot Request      | The requested dispense amount is below the minimum amount of the system (25% of the combined pump volumes is the minimum) | Deviation                     | Pumps are defined with the wrong size  | On the ADM go into the Setup screens to the System screens then make sure that the pump sizes are defined correctly |                             |  |
|            |                         |   |                               | Requested shot is below the capabilities of the current pump setup                         | If the user has to be able to take the shot the system must be fitted with smaller pumps                            |                             |  |
| B9C1       |                         | The requested dispense amount (time/volume/weight) is below the minimum amount of the system                              |                               | Short shot size  | Increase the time/volume/weight of the shot   |                             |  |

| Error Code | Error Name                     | Error Description                                       | Error Type | Cause   | Solution   |
|------------|--------------------------------|---|------------|---|--|
| CAA2       | Comm. Error Red Hose           | Communication error                                     | Alarm      | Module missing power                                    | Check power supply connection  |
| CAA3       | Comm. Error Red Inline         |   |            | Module not programmed                                   | Program the module   |
| CAA6       | Comm. Error Red Blanket        |   |            | Module bad  | Replace module   |
| CAA7       | Comm. Error Red Chiller        |   |            |   |  |
| CAB1       | Comm. Error Blue Inline        |   |            |   |  |
| CAB4       | Comm. Error Blue Hose          |   |            |   |  |
| CAB5       | Comm. Error Blue Blanket       |   |            |   |  |
| CAB8       | Comm. Error Blue Chiller       |   |            |   |  |
| CAC1       | Comm. Error Motor              |   |            |   |  |
| CAC2       | Comm. Error MCM                |   |            |   |  |
| CAC3       | Comm. Error Red Tank           |   |            |   |  |
| CAC4       | Comm. Error Blue Tank          |   |            |   |  |
| CAC5       | Comm. Error Mix Head           |   |            |   |  |
| CAC6       | Comm. Error Mix Head 2         |   |            |   |  |
| CAC7       | Comm. Error Ratio Monitor      |   |            |   |  |
| CAC9       | Comm. Error Small Dispense Kit |   |            |   |  |
| CACN       | Comm. Error Gateway            |   |            |   |  |
| CACP       | Comm. Error DGM                |   |            |   |  |
| CACR       | Comm. Error Remote Pendant     |   |            |   |  |
| CAD1       | Comm. Error Mixer              | Voltex Mixer Module is Off line (HFR Only)              | Alarm      | CAN cable to Voltex FCM3 is disconnected. FCM3 failure. | Reconnect, ensure cable. Verify proper LED indications on Voltex FCM3. |
| CUCN       | Gateway Heartbeat Error        | Heartbeat Error   | Alarm      | PLC is not maintaining heartbeat                        | Ensure PLC is triggering the heartbeat                                 |
|            |                                |   |            | Module missing power                                    | Check power supply connection  |
|            |                                |   |            | Module not programmed                                   | Program the module   |
|            |                                |   |            | Module Bad  | Replace module   |
| D1A1       | Setpoint Not Reached           | The set point was not reached and the pump was shutdown | Deviation  | Material restriction too high for requested flow        | Reduce flow request  |
| D2A1       | Setpoint Not Reached           | The set point was not reached                           | Deviation  | Pump cannot reach the requested pressure                | Increase restriction in the system                                     |
|            |                                |   |            | Pump cannot reach the requested flow                    | Decrease restriction in the system                                     |

Appendix D - ADM Error Codes

| Error Code | Error Name              | Error Description   | Error Type                                     | Cause  | Solution   |
|------------|-------------------------|---|--|--|--|
| D3A1       | Setpoint Exceeded       | The set point was exceeded  | Deviation                                      | System underwent a change that caused a large drop in restriction (such as new orifices) | Erase learned System Data, found in the setup screens under calibration                                      |
|            |                         |   |  | No material in pumps   | Make sure the material lines are open and have proper feed pressure  |
| D4A1       | Setpoint Exceeded       | The maximum cycles per minute of the pump has been exceeded   | Deviation                                      | Restriction for the pump is not sufficient   | Increase the restriction or lower the set point  |
| D5A1       | Invalid Learn Mode Data | This calibration lets the MCM know where the ends of the pump are. If the data gathered during this process is outside of normal parameters the machine will operate with a greatly reduced stroke. | Deviation                                      | Recalibrate the machine  | Rerun the learn mode calibration   |
|            |                         |   |  | Loose/bad connection   | Check to ensure the pressure transducer is properly installed and all wires are properly connected           |
|            |                         |   |  | Bad linear position sensor   | Verify pump moves to limits, if problem persists replace linear position sensor                              |
| D6A1       | Position Sensor Fault   | The linear position sensor is returning data that should not be possible during normal operation  | Alarm  | Loose/bad connection to linear position sensor   | Check to ensure the linear position sensor is properly installed and all wires are properly connected        |
|            |                         |   |  | Bad linear position sensor   | Replace linear position sensor   |
|            |                         |   |  | Linear position sensor may be loose where attached to pump housing                       | Re-tighten the sensor and re-calibrate the machine   |
| DDA1       | Red Pump Cavitation     | Cavitation was detected on the given pump   | Deviation                                      | Insufficient material being supplied or insufficient material pressure on feed system    | Verify that incoming ball valves are open  |
| DDB2       | Blue Pump Cavitation    |   |  | Debris or packout in the incoming fluid filter   | Inspect filter for debris of filler packout and clean or replace as necessary                                |
| DEH3       | Soft Stop Asserted      | Soft Stop on AC Power Pack has been pressed.  | Alarm  | User has pressed the Red Soft Stop Button on AC Power Pack.                              | Pull out Soft Stop button.   |
| DFA1       | Pump Not Parked         | The pump failed to reach the park position  | Deviation                                      | Orifices blocked   | Clear blockage   |
|            |                         |   |  | Hose blocked   | Clear or replace hose as necessary   |
|            |                         |   |  | Dispense valve failed to open  | Check to make sure the dispense valve is properly configured and connected to the MCM                        |
| DR6A       | Check Flow Meter Red    | Flow Meter has caused a fault   | Deviation                                      | Cogs in flow meter are not turning   | Check that flow meter is matched to nominal pump output  |
| DR6B       | Check Flow Meter Blue   |   |  | Cable unplugged/loose power  | check of loose or disconnected wires or plugs  |
| DSC0       | Pumps Not Defined       | The type or size of the Red or Blue material pumps have not been defined  | Alarm  | Properly setup the system  | On the ADM go into the setup screens -> System-> then make sure that the pump type and size are set (not --) |
| F1A0       | Low Flow Red            | Flow is below the defined low limit   |  | Deviation  | Cogs in flow meter are not turning   |
| F1B0       | Low Flow Blue           |   | Check for loose or disconnected wires or plugs |  |  |
| F2A0       | Low Flow Red            |   | Deviation                                      | Cable unplugged/loose power  | Check that flow meter is matched to nominal pump output  |
| F2B0       | Low Flow Blue           |   |  |  | Check for loose or disconnected wires or plugs   |
| F3A0       | High Flow Red           | Flow is above the defined low limit   | Deviation                                      | Cogs in flow meter are turning rapidly   | Check that flow meter is matched to nominal pump output  |
| F3B0       | High Flow Blue          |   |  |  |  |
| F4A0       | High Flow Red           |   | Alarm  |  |  |
| F4B0       | High Flow Blue          |   |  |  |  |

| Error Code | Error Name                        | Error Description   | Error Type | Cause   | Solution  |
|------------|-----------------------------------|---|------------|---|---|
| F7D1       | Pump Failed to Stall              | When the pump tried to stall to pressure the pump traveled more than it should in normal operation (only applies to dead-headed system) | Deviation  | Failure of the dispense valve   | Ensure the valve has a proper air supply and seals properly. If not, service the valve as necessary.  |
|            |                                   |   |            | Material leak   | Visually inspect the machine and hoses for sign of leakage. <b>NOTE:</b> This error will display after 2 full piston strokes so the leak will be substantial. |
|            |                                   |   |            | Out of material   | Fill tanks  |
| L111       | Red Low Material Level            | Low material level in tanks   | Deviation  | Tanks low on material   | Fill tanks with material  |
| L122       | Blue Low Material Level           |   |            | Loose/broken connection   | If the tanks appear to have plenty of material check to make sure the level sensor is connected to the proper port and that the cord is not damaged           |
|            |                                   |   |            | Bad level sensor  | Replace level sensor  |
| L311       | Red High Material Level           | High material level in tanks  | Deviation  | Defective fill valve  | If the tanks appear to have plenty of material check to make sure the level sensor is connected to the proper port and that the cord is not damaged           |
| L322       | Blue High Material Level          |   |            |   |   |
| L6A1       | Red Auto Refill Timeout           | The tank stand has been filling for a time greater than expected  | Deviation  | No material is actually being fed   | Make sure the feed pumps are operating properly   |
| L6B2       | Blue Auto Refill Timeout          |   |            | Loose level sensor connection   | Check for loose or disconnected wires or plugs  |
|            |                                   |   |            | Bad level sensor  | Replace level sensor  |
| L9AX       | Red Tank Leak Detected            | Possible Leak in Red Tank detected  | Deviation  | System did two or more automatic tank fill operations without a dispense during the same time | Check hose connections between tank output, and pump inlet. Check tank fittings.  |
| L9BX       | Blue Tank Leak Detected           | Possible Leak in Blue Tank detected   |            |   |   |
| L8A1       | Red Tank Sensor Failure           | A level sensor had ceased working   | Deviation  | Bad level sensor  | Replace level sensor  |
| MBH1       | Low Oil Level                     | The volume of oil in the tank is below the minimum level needed for the system to properly operate                                      | Alarm      | Low oil level   | Check oil level and if low add more hydraulic fluid   |
|            |                                   |   |            | Loose/bad connection  | Check to ensure the hydraulic oil level sensor is properly connected to the MCM and that the wire has not been damaged  |
|            |                                   |   |            | Bad level sensor  | Replace sensor  |
|            |                                   |   |            | Leak in hydraulic driver  | Inspect hydraulic driver end seals and early leak detection tubing. Replace seals as necessary and replace lost oil.  |
|            |                                   |   |            | Leak in the hydraulic reservoir, heat exchanger   | Inspect the hydraulic reservoir fittings and filter for leaks. Repair or replace as necessary and replace lost oil.   |
| MBH3       | Low Mix Head Oil Level            | Oil level in AC Power Pack too low.   | Alarm      | Level Sensor bad. Function turned ON without sensor installed.                                | Add oil.  |
| MBN1       | Low Motor Performance             | The motor magnetism has decreased to the point where performance is greatly reduced   | Advisory   | Prolonged exposure to heat or high voltage  | If error persists and performance can no longer satisfy the user requirements the motor will need to be replaced  |
| MMUX       | USB Logs Full                     | USB log has reached the maximum entries   | Advisory   | USB logs have not been downloaded   | Download USB logs to a memory stick<br>Uncheck the Enable USB errors on Advanced screen 4   |
| N1D0       | Material Dispense Below Alarm     | Material dispense is below the defined limit  | Alarm      | Cogs in flow meter are not turning  | Check that flow meter is matched to nominal pump output   |
| N2D0       | Material Dispense Below Deviation |   | Deviation  |   |   |
| N3D0       | Material Dispense Above Deviation | Material dispense is above the defined limit  | Deviation  | Cable unplugged/loose power   | Check for loose or disconnected wires or plugs  |

| Error Code  | Error Name  | Error Description   | Error Type | Cause  | Solution   |
|---|---|---|------------|--|--|
| N4A1  | Pump Failed to Move   | The MCM attempted to move the pump but no movement was detected   | Deviation  | Motor failure  | Visually check to ensure the pump is moving, if not ensure the motor is wired properly                                 |
|   |   |   |            | Hydraulic power pack failure                                     | If motor is moving but pump is not and pressure is not building they hydraulic power pack may need servicing           |
|   |   |   |            | Loose/bad connection to the linear position sensor               | Check to ensure the linear position sensor is properly connected to the MCM and the wiring has not be damaged          |
|   |   |   |            | Failure of the linear position sensor                            | Replace the linear position sensor   |
|   |   |   |            | Motor no longer coupled to hydraulic pump                        | Reset coupler per specifications and retighten set screws  |
|   |   |   |            | Supply tube from hydraulic pump to manifold is loose or broken   | Retighten or replace supply tube   |
|   |   |   |            | Broken motor shaft   | Replace motor  |
|   |   |   |            | Over-pressure valve dumping to tank                              | Verify that no outside forces are stopping the pump from moving, then inspect over-pressure valve for damage or debris |
| N4D0  | Material Dispense Above Alarm   | Material dispense is above the defined limit  | Alarm      | Cable unplugged/loose power                                      | Check for loose or disconnected wires or plugs   |
| P1H3  | Low Accumulator Pressure  | AC Power Pack pressure too low, or failed to reach desired pressure.  | Alarm      | Accumulator Directional Valve will not shift to charge position. | Check control line to Directional Valve. Replace Directional Valve.  |
| P400  | Thermal Pressure Rise   | Pressure has risen to an unsafe level due to thermal expansion of materials. All conditioning zones have automatically been turned off. | Deviation  | High pressure  | Open the dispense valve manually or open the valves to bleed pressure  |
| P4A1  | Red Pressure Shutdown   | The material pump pressure exceeded the maximum operating pressure as defined in the setup screens                                      | Alarm      | Dispense valve failed to open                                    | Check to make sure the dispense valve is properly configured and connected to the MCM                                  |
| P4B2  | Blue Pressure Shutdown  |   |            | Bad dispense valve   | Replace dispense valve   |
|   |   |   |            | Restriction in the material lines                                | Check to ensure there is no blockage   |
|   |   |   |            | Invalid maximum pressure defined                                 | Make sure the requested pressure is within the max operating pressure, which can be found on the setup screen System 1 |
|   |   |   |            | Orifices blocked   | Clear blockage   |
|   |   |   |            | Hose blocked   | Clear blockage or replace hose as necessary  |
|   |   |   |            | Dispense valve failed to open                                    | Check to make sure the dispense valve is properly configured and connected to the MCM                                  |
|   |   |   |            | P4D0   | Pressure Imbalance   |
| Pressure imbalance is defined too low                   | On the ADM go into the setup screens -> System-> and ensure the pressure imbalance value is the maximum acceptable to prevent unnecessary alarms which will abort dispenses |   |            |  |  |
| Orifice blocks closed off too much on one or both sides | Verify that one or both of the orifice blocks dispense when adjusted to the fully open position then adjust accordingly   |   |            |  |  |
| Debris in the orifice block                             | Relieve system pressure then remove the orifice from the orifice block and inspect for debris in the cavity   |   |            |  |  |
| Material fillers may have packed out in an orifice      | Relieve system pressure and remove the orifice from the orifice block and inspect for pack out. Clean or replace as necessary.  |   |            |  |  |
| Out of material   | Fill tanks with material  |   |            |  |  |
| Feed system defective                                   | Replace defective item  |   |            |  |  |

| Error Code | Error Name                         | Error Description   | Error Type | Cause  | Solution  |
|------------|------------------------------------|---|------------|--|---|
| P4H3       | High Accumulator Pressure          | AC Power Pack pressure too high                               | Alarm      | Accumulator Directional Valve stuck in charge position.                                | Check control line to Directional Valve. Replace Directional Valve.   |
| P6A1       | Red Pressure Sensor Fault          | The pressure sensor is providing invalid/no pressure readings | Alarm      | Loose/bad connection   | Check to ensure the pressure transducer is properly installed and all wires are properly connected  |
| P6B2       | Blue Pressure Sensor Fault         |   | Alarm      | Bad sensor<br>No material in pump  | Replace pressure transducer<br>Fill tanks   |
| P6H1       | Power Pack Pressure Sensor Fault   | There is a failure with the AC Power pack pressure sensor     | Alarm      | Pressure sensor become disconnected. Pressure sensor wiring became broken.             | <ol style="list-style-type: none"> <li>1. Replace pressure sensor.</li> <li>2. Check wiring.</li> <li>3. Possible failure with AC power FCm3 module.</li> </ol>   |
| P9H1       | Accumulator Charges too Frequently | The AC Power pack charges too often                           | Advisory   | The time between consecutive hydraulic pressure charges in AC power pack was too short | <ol style="list-style-type: none"> <li>1. Accumulator in the AC power pack needs adjusted.</li> <li>2. There is a possible leak in GX-16, L-head dispense valve, a hose, manifold, etc. Fix accordingly.</li> </ol> |
| R1D0       | Low Ratio Alarm                    | Ratio monitor has detected an out of ratio condition          | Alarm      | Material A to Material B is out of ratio   | Check feed system   |
| R2D0       | Low Ratio Deviation                |   | Deviation  |  |   |
| R3D0       | High Ratio Deviation               |   | Deviation  |  |   |
| R4D0       | High Ratio Alarm                   |   | Alarm      |  |   |
| T1A2       | Red Hose Low Fluid Temp.           | Fluid temperature is below the defined low alarm limit        | Alarm      | Tripped circuit breaker  | Visually check circuit breaker for a tripped condition  |
| T1A3       | Red Inline Low Fluid Temp.         |   |            |  |   |
| T1A6       | Red Tank Low Fluid Temp.           |   |            |  |   |
| T1A7       | Red Chiller Low Fluid Temp.        |   |            | Cable unplugged/loose power  | Check for loose or disconnected wires or plugs  |
| T1B1       | Blue Inline Low Fluid Temp.        |   |            | Tripped circuit breaker  | Visually check circuit breaker for a tripped condition  |
| T1B4       | Blue Hose Low Fluid Temp.          |   |            | Low power  | Measure voltage across input terminals on power line filter. Voltage should measure between 190 and 264 Vac   |
| T1B5       | Blue Tank Low Fluid Temp.          |   |            | Tripped circuit breaker  | Visually check circuit breaker for a tripped condition  |
| T1B8       | Blue Chiller Low Fluid Temp.       |   |            | Bad heater(s)  | Measure resistance of heater(s)   |
| T20X       | Dispensing Disabled Low Temp       | Dispensing disabled because of temperature                    | Advisory   | Temperature is out of alarm limits   | Check temperature alarm limits  |

Appendix D - ADM Error Codes

| Error Code | Error Name                    | Error Description  | Error Type | Cause   | Solution   |
|------------|-------------------------------|--|------------|---|--|
| T2AA       | Red Hose Low Fluid Temp.      | Fluid temperature for a monitor zone is below the defined low alarm limit  | Deviation  | Temperature is out of alarm limits                  | Check temperature alarm limits   |
| T2AE       | Red Tank Low Fluid Temp.      |  |            |   |  |
| T2AF       | Red Chiller Low Fluid Temp.   |  |            |   |  |
| T2BC       | Blue Hose Low Fluid Temp.     |  |            |   |  |
| T2BD       | Blue tank Low Fluid Temp.     |  |            |   |  |
| T2BG       | Blue Chiller Low Fluid Temp.  |  |            |   |  |
| T30X       | Dispensing Disabled High Temp | Dispensing disabled because of temperature   | Deviation  | Cable unplugged/loose power                         | Check for loose or disconnected wires or plugs   |
| T3AA       | Red Hose High Fluid Temp.     | Fluid temperature for a monitor zone is above the defined high alarm limit   | Deviation  | Inline heater is not turned on                      | Turn on inline heater  |
| T3AE       | Red Tank High Fluid Temp.     |  |            |   |  |
| T3AF       | Red Chiller High Fluid Temp.  |  |            |   |  |
| T3BC       | Blue Hose High Fluid Temp.    |  |            |   |  |
| T3BD       | Blue Tank High Fluid Temp.    |  |            |   |  |
| T3BG       | Blue Chiller High Fluid Temp. |  |            |   |  |
| T3H1       | Oil Temp. Cutback             | The hydraulic oil temperature is approaching a level where damage is possible so the Motor Control Module is limiting the output to a safe level | Deviation  | No power to fan                                     | Check cord to make sure fan has power  |
|            |                               |  |            | Debris is fan or fan grill                          | Clear debris from fan/fan grill  |
|            |                               |  |            | Low air volume from fan                             | Try to stop fan by lightly pressing on the center with a pencil eraser. If the fan slows down easily it will need to be replaced |
| T3N1       | Motor Temp. Cutback           | Motor temperature is approaching a level where damage is possible so the motor control module is limiting the output to a safe level             | Advisory   | No power to fan                                     | Check cord to make sure fan has power  |
|            |                               |  |            | Debris is fan or fan grill                          | clear debris from fan/fan grill  |
|            |                               |  |            | Low air volume from fan                             | Try to stop fan by lightly pressing on the center with a pencil eraser. If the fan slows down easily it will need to be replaced |
|            |                               |  |            | Ambient environmental conditions are too hot        | Move machine to an area below 120°F  |
|            |                               |  |            | Motor/pump coupler may be rubbing on hydraulic pump | Reset coupler per specifications and retighten set screws  |



| Error Code | Error Name                    | Error Description   | Error Type | Cause  | Solution   |
|------------|-------------------------------|---|------------|--|--|
| T4A2       | Red Hose High Fluid Temp.     | Fluid temperature is above the defined high alarm limit   | Alarm      | Defective Temperature Control Module   | Replace Power Temperature Control Module   |
| T4A3       | Red Inline High Fluid Temp.   |   |            |  |  |
| T4A6       | Red Tank High Fluid Temp.     |   |            |  |  |
| T4A7       | Red Chiller High Fluid Temp.  |   |            |  |  |
| T4B1       | Blue Inline High Fluid Temp.  |   |            |  |  |
| T4B4       | Blue Hose High Fluid Temp.    |   |            |  |  |
| T4B5       | Blue Tank High Fluid Temp.    |   |            | Defective RTD  | Replace RTD  |
| T4B8       | Blue Chiller High Fluid Temp. |   |            | Loose connections  | Tighten connections  |
| T4C1       | Motor Control High Temp.      | The temperature the MCM has reached a level where product life will be decreased drastically and has been shutdown for protection | Alarm      | No power to fan  | Check cord to make sure fan has power  |
|            |                               |   |            | Debris is fan or heatsink  | Clear debris from fan or heatsink  |
|            |                               |   |            | Low air volume from fan  | Try to stop fan by lightly pressing on the center with a pencil eraser. If the fan slows down easily it will need to be replaced |
|            |                               |   |            | Motor may be damaged   | Replace motor  |
|            |                               |   |            | Debris is packed in the MCM's heat sink fins   | Clear debris from MCM heat sink fins   |
| T4H1       | Oil Temp. Shutdown            | The hydraulic oil is at a temperature where performance is impacted significantly and has resulted in a system shutdown           | Alarm      | No Power to Fan  | Check cord to make sure fan has power  |
|            |                               |   |            | Debris in fan or fan grill   | Clear debris from fan/fan grill  |
|            |                               |   |            | Low air volume from fan  | Try to stop fan by lightly pressing on the center with a pencil eraser. If the fan slows down easily it will need to be replaced |
| T4H3       | High Mix Head Oil Temp.       | AC Power Pack temperature too high.   | Alarm      | RTD Sensor option turned ON without RTD installed. Oil temperature is excessively hot. | If oil is not hot, replace sensor.   |
| T4N1       | Motor Temp. Shutdown          | Motor temperature is too high and system has been shutdown to prevent possible damage   | Alarm      | No power to fan  | Check cord to make sure fan has power  |
|            |                               |   |            | Debris is fan or fan grill   | Clear debris from fan/fan grill  |
|            |                               |   |            | Low air volume from fan  | Try to stop fan by lightly pressing on the center with a pencil eraser. If the fan slows down easily it will need to be replaced |
|            |                               |   |            | Ambient environmental conditions are too hot   | Move machine to an area below 120°F  |
|            |                               |   |            | Motor may be damaged   | Motor may need to be replaced  |

Appendix D - ADM Error Codes

| Error Code | Error Name                | Error Description                                | Error Type | Cause   | Solution                |                             |   |  |   |
|------------|---------------------------|--|------------|---|-------------------------|-----------------------------|---|--|---|
| T6A2       | Red Hose FTS Fault        | RTD 1 is giving no or invalid data               | Alarm      | Loose or bad connection                           | Check RTD wiring        |                             |   |  |   |
| T6A3       | Red Inline RTD Fault      |  |            |   |                         |                             |   |  |   |
| T6A6       | Red Tank RTD Fault        |  |            |   |                         |                             |   |  |   |
| T6A7       | Red Chiller RTD Fault     |  |            |   |                         |                             |   |  |   |
| T6B5       | Blue Tank RTD Fault       |  |            |   |                         |                             |   |  |   |
| T6B1       | Blue Inline RTD Fault     |  |            |   |                         |                             |   |  |   |
| T6B4       | Blue Hose FTS Fault       |  |            |   |                         |                             |   |  |   |
| T6B8       | Blue Chiller RTD Fault    |  |            |   |                         | Bad RTD                     | Replace RTD   |  |   |
| T6C5       | Blue Blanket RTD Fault    | RTD 2 is giving no or invalid data               |            | Alarm   | Loose or bad connection | Check RTD wiring            |   |  |   |
| T6C6       | Red Blanket RTD Fault     |  |            |   |                         |                             |   |  |   |
| T6C7       | Red Chiller RTD Fault     |  |            |   |                         |                             |   |  |   |
| T6C8       | Blue Chiller RTD Fault    |  |            |   |                         |                             | Loose or bad connection   | Check RTD wiring                                       |   |
| T8A2       | No Heat Red Hose          | No temperature rise                              |            |   | Alarm                   | Cable unplugged/loose power | Check for loose or disconnected wires or plugs  |  |   |
| T8A3       | No Heat Red Inline        |  |            |   |                         |                             |   |  |   |
| T8A6       | No Heat Red Tank          |  |            |   |                         | Tripped circuit breaker     | Visually check circuit breaker for a tripped condition  |  |   |
| T8A7       | No Cooling Red Chiller    | No temperature decline                           | Alarm      |   |                         | Low Power                   | Measure voltage across input terminals on power line filter. Voltage should measure between 190 and 264 Vac |  |   |
| T8B1       | No Heat Blue Inline       | No temperature rise                              |            |   |                         |                             |   |  |   |
| T8B4       | No Heat Blue Hose         |  |            |   |                         |                             | Bad heater(s)   | Measure resistance of heater(s)                        |   |
| T8B5       | No Heat Blue Tank         |  |            |   |                         |                             | Tripped circuit breaker   | Visually check circuit breaker for a tripped condition |   |
| T8B8       | No Cooling Blue Chiller   | No temperature decline                           |            |   |                         |                             | Alarm   | Defective cooling valve                                | Disconnect the valve and measure the voltage across the wires when the chiller is running to ensure 24V is being delivered to the valve. If so, the cooling valve will likely need replacing. |
|            |                           |  |            |   |                         |                             |   | Chilled water supply off                               | Turn on chilled water supply  |
|            |                           |  |            |   |                         |                             |   | Loose or bad connection                                | Check RTD wiring  |
| T8CX       | Heater(s) off             | User is dispensing with an enabled heat zone off |            |   |                         |                             |   | Advisory   | Heater is off   |
|            |                           |  |            | Temperature Alarm Disables Dispense feature is on |                         |                             |   |  | Turn Temperature Alarm Disables Dispense feature off  |
| T9A3       | Red Inline Temp. Cutoff   | Heater overtemperature cutoff                    |            | Alarm   |                         |                             |   | Defective High Power Temperature Control Module        | Replace High Power Temperature Control Module   |
| T9A6       | Red Blanket Temp. Cutoff  |  |            |   |                         |                             |   | Defective RTD  | Replace RTD   |
| T9B1       | Blue Inline Temp. Cutoff  |  |            |   |                         |                             |   | Loose connections                                      | Tighten connections   |
| T9B5       | Blue Blanket Temp. Cutoff |  |            |   | Defective RTD           |                             |   | Replace RTD  |   |



| Error Code | Error Name                 | Error Description  | Error Type | Cause   | Solution   |   |
|------------|----------------------------|--|------------|---|--|---|
| T9C1       | Blue Inline Ctrl Shutdown  | PCB over temperature   |            | Overheated Temperature Control Module               | Turn conditioning zone off. Wait a few minutes. If the condition does not clear or regenerates consistently, replace heater module |   |
| T9C2       | Red Hose Ctrl Shutdown     |  |            |   |  |   |
| T9C3       | Red Inline Ctrl Shutdown   |  |            |   |  |   |
| T9C4       | Blue Hose Ctrl Shutdown    |  |            |   |  |   |
| T9C5       | Blue Blanket Ctrl Shutdown |  |            |   |  |   |
| T9C7       | Red Chiller Ctrl Shutdown  |  |            |   |  |   |
| T9C8       | Blue Chiller Ctrl Shutdown |  |            |   |  |   |
| V1H1       | Motor Control Undervoltage | The voltage to the MCM has dropped to a level where performance is greatly affected                      | Alarm      | Tripped circuit breaker                             | Visually check circuit breaker for a tripped condition   |   |
|            |                            |  |            | Supply lines providing low voltage                  | Check incoming voltage to ensure it is above the minimum operating voltage   |   |
| V4A2       | Red Hose Overvoltage       | High line voltage  |            |   | Incoming line voltage is too high  | Measure voltage across disconnect switch. Voltage should measure between 190 and 264 Vac. |
| V4A3       | Red Inline Overvoltage     |  |            |   |  |   |
| V4A6       | Red Blanket Overvoltage    |  |            |   |  |   |
| V4A7       | Red Chiller Overvoltage    |  |            |   |  |   |
| V4B1       | Blue Inline Overvoltage    |  |            |   |  |   |
| V4B4       | Blue Hose Overvoltage      |  |            |   |  |   |
| V4B5       | Blue Blanket Overvoltage   |  |            |   |  |   |
| V4B8       | Blue Chiller Overvoltage   |  |            |   |  |   |
| V4H0       | Motor Control Overvoltage  | The voltage to the MCM has reached an unsafe level and has been shutdown in an attempt to prevent damage |            | Supply lines providing high voltage                 | Check incoming voltage to ensure it is below the maximum operating voltage   |   |
| WBD1       | Mixer Motor Fault          | Voltex mixer failed to spin, operate (HFR Only)  | Deviation  | Mixer clogging, or mixed material hardening         | Verify mixer reaching requested RPM using the Mixer Run screen. Clean or replace mixer if necessary.                               |   |
| WBH1       | Motor Encoder Fault        | An error has been detected on the motor position sensor  | Alarm      | Failing sensors                                     | If error persists the motor will need to be replaced   |   |
| WDD3       | M1 Cleanout Extend Fault   | Clean-Out Rod in dispense valve ("L-Head") failed to move.   | Alarm      | Clean-Out Rod Valve faulty.                         | Check control line to Clean-Out Valve. Replace Hydraulic Valve.  |   |
| WDF1       | M1 Material Extend Fault   | Material Rod in dispense valve failed to close. Pump halted.   | Alarm      | Material Rod failed to close. Pump movement halted. | Hydraulic lines installed backwards. + DC voltage shorted to the Valve Control Line.   |   |

Appendix D - ADM Error Codes

| Error Code | Error Name                        | Error Description  | Error Type | Cause  | Solution   |
|------------|-----------------------------------|--|------------|--|--|
| WDF1       | M1 Material Extend Fault          | Material rod in dispense valve failed to open during a dispense.   | Deviation  | Material Rod stuck closed. Shot duration too short.            | Take a long shot to determine if it corrects the problem.  |
| WDF1       | M1 Material Rod Shift Fail        | The material rod failed to move on a straight head   | Alarm      | Stuck material rod<br>No power to directional valve            | Check that material rod is able to freely move<br>Make sure the directional valve has power              |
|            | Dispense Valve Open Failure       | Dispense valve was slow or did not open after commanded open.  | Deviation  | GX-16 or L-Head DV was slow to open, or did not open.          | Clean mix chamber area/ Material rod area of DV.<br>Make sure directional valve has power.               |
|            | Dispense Valve Failed to Close    | Dispense valve failed to close approximately 1 second after commanded to close.  |            | GX-16 or L-Head DV did not close or is stuck open.             |  |
| WKH1       | High Motor Speed                  | The motor has reached a speed that should not be reached in normal operation and was shutdown to prevent possible damage | Alarm      | No power to directional valve                                  | Make sure the directional valve has power  |
|            |                                   |  |            | Bad directional valve connection                               | Make sure the cord to the directional valve is connected to the correct port and the cord is not damaged |
|            |                                   |  |            | Directional valve failure                                      | The directional valve will need to be replaced   |
|            |                                   |  |            | Hydraulic power pack failure                                   | The hydraulic power pack will need repair  |
|            |                                   |  |            | Defective encoder  | Replace encoder  |
|            |                                   |  |            | Motor no longer coupled to hydraulic pump                      | Reset coupler per specifications and retighten set screws  |
|            |                                   |  |            | Supply tube from hydraulic pump to manifold is loose or broken | Retighten or replace supply tube   |
|            |                                   |  |            | Broken motor shaft   | Replace motor  |
| WM01       | Blue Inline Con. Fault            | High current to relay 1  | Alarm      | Broken contactor   | Replace contactor  |
| WM02       | Red Hose Con. Fault               |  |            |  |  |
| WM03       | Red Inline Con. Fault             |  |            |  |  |
| WM04       | Blue Hose Con. Fault              |  |            |  |  |
| WM05       | Blue Tank Con. Fault              |  |            |  |  |
| WM06       | Red Tank Con. Fault               |  |            |  |  |
| WM07       | Red Chiller Con. Fault            |  |            |  |  |
| WM08       | Blue Chiller Con. Fault           |  |            |  |  |
| WMA6       | Red Blanket High Temp.            | Tank blanket is above the defined high alarm limit   | Alarm      | Defective RTD  | Replace RTD  |
| WMB5       | Blue Blanket High Temp.           |  |            | Defective High Power Temperature Control Module                | Replace High Power Temperature Control Module  |
|            |                                   |  |            | Loose connections  | Tighten connections  |
| WMCX       | Questionable Shot Recipe Detected | The logic has detected an excessively large rate (flow or pressure) or amount to a shot recipe.                          | Advisory   | Erroneous entry by user  | Find the shot number with the problem, and redefine the excessive rate or amount recipe element.         |

| Error Code | Error Name                   | Error Description   | Error Type | Cause  | Solution  |
|------------|------------------------------|---|------------|--|---|
| WMC1       | Blue Inline Con. Fault       |   |            |  |   |
| WMC2       | Red Hose Con. Fault          |   |            |  |   |
| WMC3       | Red Inline Con. Fault        |   |            |  |   |
| WMC4       | Blue Hose Con. Fault         |   |            |  |   |
| WMC5       | Blue Tank Con. Fault         |   |            |  |   |
| WMC6       | Red Tank Con. Fault          | Unexpected current to relay 1   | Alarm      | Shorted module   | If temperature is being affected by a zone that has been disabled, replace heat module  |
| WMC7       | Red Chiller Con. Fault       |   |            |  |   |
| WMC8       | Blue Chiller Con. Fault      |   |            |  |   |
| WMH1       | Motor Controller Fault       | A general fault has occurred within the MCM   | Deviation  | Internal hardware failure  | Cycle power, if the error persists the MCM will need to be replaced   |
| W0U0       | USB Update Failed            | The ADM tried to upload a system settings file but failed   | Alarm      | System Settings file is corrupt  | Replace the system settings file with a backup or new file  |
| WSC0       | Invalid Setpoint Request     | The requested controlling value (pressure or flow) is outside the limits of the system  | Deviation  | System incorrectly setup   | On the ADM go into the setup screens -> System-> and ensure that all pages have properly defined values   |
|            |                              |   |            | Shot incorrectly defined   | Redefine shot with control parameters within the limits of the system   |
|            | Invalid Gel Timer Definition | The shot that was entered for the gel timer is not a valid shot. This must be fixed before the gel timer will function properly | Deviation  | Gel timer shot is below the minimum dispense amount or set for a invalid pressure/flow<br>The MCM has determined that the gel timer shot will not be able to be executed based parameters entered in the ADM | Select a different shot or modify existing shot data<br><br>If you are certain that the shot is within parameters, try running the Learn Mode routine found in the setup screen Calibration. If the error persists, a gel shot with reduced control parameters is required. |

## Appendix E - System Events

| Event Code and String                     | Triggers  |
|---|---|
| EAA0-R: Prepoly Refresh Started           | While in night mode, the prepoly refresh started.   |
| EA0-R: Night Mode Recirc On               | While in night mode the system has automatically entered a low circulation mode and attempted to turn on all enabled conditioning zones.  |
| EA00-R: Disp. Occurred (Shot #)           | A dispense has occurred of the given shot number.   |
| EBA0-R: Prepoly Refresh Complete          | While in night mode, the prepoly refresh completed successfully.  |
| EB00-R: Stop Button Pressed               | The Red stop button was pressed on the Advanced Display Module.   |
| EBR0-R: Night Mode Recirc Off             | While in night mode the system has automatically stopped the low circulation mode and turned off all conditioning zones.  |
| ECA1-R: Red Material SG Modified          | The Red materials specific gravity was modified.  |
| ECB2-R: Blue Material SG Modified         | The Blue materials specific gravity was modified.   |
| ECC1-R: Cavitation Errors On              | User has turned ON the Cavitation Error Generation logic (default, and recommended state for production use) using the ADM module or Field Bus interface.   |
| ECC0-R: Cavitation Errors Off             | User has turned OFF the Cavitation Error Generation logic (NOT recommended for production use) using the ADM module or Field Bus interface. If turned OFF, and an HFR pump does not completely fill, the error will NOT be generated and the ratio of the 2 materials may be correct. This event will also be generated if set when the HFR (or NVH) product powers up. |
| ECD0-R: Mixer Motor Disabled for Dispense | User has activated function (Pressed  key) which may have negative effects on future dispenses.  |
| ECD1-R: Mixer Motor Enabled for Dispense  | User has re-enabled the mixer motor for dispensing.   |
| ECF0-R: Mixer Air OFF for Dispense        | User has activated function (Pressed  key) which may have negative effects on future dispenses.  |
| ECF1-R: Mixer Air Enabled for Dispense    | User has re-enabled Air Nucleation for dispensing.  |

| Event Code and String                | Triggers  |
|--------------------------------------|---|
| ECGX: Dispense Recipe Altered by PLC | The rate (flow or pressure) or amount has been altered by the controlling CGM/PLC interface when the system was in shot mode. |
| ECH0-R: Learn Mode Executed          | A learn mode calibration was successfully completed.  |
| EH00-R: Gel Timer Dispense           | The gel timer expired and the system automatically took the gel shot.   |
| EL00-R: System Powered On            | The System was powered on.  |
| EM00-R: System Powered Off           | The System was powered off.   |
| ENN0-R: Automatic Cal. Performed     | The system was successfully characterized with the Automatic calibration.   |
| ENC1-R: Cal. Point 1 Weight Entered  | A value for the first point in the three point calibration was entered.   |
| ENC2-R: Cal. Point 2 Weight Entered  | A value for the second point in the three point calibration was entered.  |
| ENC4-R: Cal. Point 1 Weight Erased   | The running average for point one of the three point calibration was erased.  |
| ENC5-R: Cal. Point 2 Weight Erased   | The running average for point two of the three point calibration was erased.  |
| END0-R: Ratio Check Dispense         | A ratio check shot was dispensed from the ratio check calibration screen.   |
| EQU1-R: Settings Downloaded          | The system settings were successfully transferred from the ADM to a USB drive.  |
| EQU3-R: Language Downloaded          | The custom language file was successfully transferred from the ADM to a USB drive.  |
| EQU4-R: Language Uploaded            | The custom language file was successfully transferred from the USB drive to the ADM.  |
| EQU5-R: Logs Downloaded              | The Error/Event and Shot data logs were successfully transferred from the ADM to a USB drive.                                 |
| ER01-R: Shot Count Reset             | A counter from the shot counters maintenance page was erased  |
| ER02-R: Seq. Position Count Reset    | A counter from the sequence counters maintenance page was erased  |
| ERA1-R: Red Material Volume Reset    | The resettable totalizer for the Red material volume was reset to zero.   |
| ERB1-R: Blue Material Volume Reset   | The resettable totalizer for the Blue material volume was reset to zero.  |
| ERA2-R: Red Material Weight Reset    | The resettable totalizer for the Red material weight was reset to zero.   |
| ERB2-R: Blue Material Weight Reset   | The resettable totalizer for the Blue material weight was reset to zero.  |
| ERA3-R: Red Cycle Count Reset        | The resettable cycle counter for the Red pump was reset to zero.  |

| <b>Event Code and String</b>     | <b>Triggers</b>  |
|----------------------------------|--|
| ERB3-R: Blue Cycle Count Reset   | The resettable cycle counter for the Blue pump was reset to zero.                    |
| EWA0-R: Prepoly Refresh Canceled | While in night mode, the prepoly refresh was canceled                                |
| REQU-R: Settings Uploaded        | The system settings file was successfully transferred from the USB drive to the ADM. |

# Appendix F - USB Operation

## Overview

There are 3 main uses for the USB on a GMS system:

- Ability to download a log of up to the past 50,000 errors, events, or jobs that can contain over 150,000 snapshots of critical dispense information
- Ability to download, modify, and upload custom language files
- Ability to download and upload system configurations
  - This data includes most user selectable and user configurable settings.
  - This data does not include pump counters, error and event logs, shot and sequence counters.

## USB Options

The only options for USB on the ADM are in **Advanced Screen 4**, see page 68.



The first option is a checkbox that enables or disables the downloading of the Error Event and Shot Data log files. The Shot Data log runs during all circulation, shots, and operator modes.

The second option is the Erase icon which will reset the last download date to a time where all logs can be downloaded. This will allow the user to download all the USB log entries, which may take over 2 hours if the log files are full. Currently the ADM does not monitor the USB logs and alert the user when data may be overwritten so in order to minimize download times and the risk of losing data it is recommended that the user download the logs every 2 weeks or more often if the machine is used during more than one full shift a day.

The third option is a checkbox that enables or disables the ability to record errors associated with the USB logs.

## Download Log Files


If the “Enable Downloading of USB Logs” is checked, the user can use a USB stick-drive to download the log files.

| NOTICE   |
|--|
| <p>Low-quality USB stick drives may lead to burning out the USB port on the ADM. Use only high-quality USB stick-drives with the ADM USB port.</p> |

To download the log files, insert a high-quality USB stick-drive into the USB port in the bottom of the ADM. The ADM will automatically begin downloading the log files as well as the custom language file (DISP-TEXT.TXT) and the system settings (SETTINGS.TXT). The status of the download will be shown in the Status bar.



# Log Files, Folder Structure



**Fig. 29: DOWNLOAD, DATAxxxx Folders**

Each time a stick-drive is inserted into the ADM USB port, a new folder named DATAxxxx is created. The number at the end of the folder name is incremented each time a stick-drive is inserted and data is downloaded or uploaded. In each DATAxxxx folder there are three log files. They are formatted as .csv (comma separated value) files and can be opened by most text editors or data processing programs such as Excel.

## Example 1-ERROR File

The 1-ERROR file is the Errors and Events log file.

| Date      | Time     | Error Log                                   | Event Log                   | Active Shot Number |
|-----------|----------|---|-----------------------------|--------------------|
| 4/11/2012 | 14:12:17 | No Active Errors                            | EC0X-R:Setup Values Changed | -                  |
| 4/11/2012 | 14:13:26 | No Active Errors                            | EC0X-R:Setup Values Changed | -                  |
| 4/11/2012 | 14:14:14 | No Active Errors                            | EC0X-R:Setup Values Changed | -                  |
| 4/11/2012 | 14:15:00 | No Active Errors                            | EC0X-R:Setup Values Changed | -                  |
| 4/11/2012 | 14:17:11 | P4D0-A: Pressure Imbalance                  | No Event                    | -                  |
| 4/11/2012 | 14:17:17 | Error Cleared: P4D0-A: Pressure Imbalance   | No Event                    | -                  |
| 4/11/2012 | 14:17:31 | DDA1-D: Red Pump Cavitation                 | No Event                    | -                  |
| 4/11/2012 | 14:17:44 | DDB2-D: Blue Pump Cavitation                | No Event                    | -                  |
| 4/11/2012 | 14:20:18 | Error Cleared: DDA1-D: Red Pump Cavitation  | No Event                    | -                  |
| 4/11/2012 | 14:20:18 | Error Cleared: DDB2-D: Blue Pump Cavitation | No Event                    | -                  |
| 4/11/2012 | 14:20:46 | P4D0-A: Pressure Imbalance                  | No Event                    | -                  |
| 4/11/2012 | 14:20:52 | Error Cleared: P4D0-A: Pressure Imbalance   | No Event                    | -                  |
| 4/11/2012 | 14:23:59 | No Active Errors                            | EM00-R: System Powered Off  | -                  |
| 4/11/2012 | 14:24:00 | No Active Errors                            | EL00-R: System Powered On   | -                  |
| 4/11/2012 | 14:48:47 | No Active Errors                            | EM00-R: System Powered Off  | -                  |
| 4/11/2012 | 14:48:48 | No Active Errors                            | EL00-R: System Powered On   | -                  |
| 4/11/2012 | 14:50:03 | No Active Errors                            | EM00-R: System Powered Off  | -                  |
| 4/11/2012 | 14:50:10 | No Active Errors                            | EL00-R: System Powered On   | -                  |
| 4/11/2012 | 14:50:18 | No Active Errors                            | EM00-R: System Powered Off  | -                  |
| 4/12/2012 | 7:51:33  | No Active Errors                            | EL00-R: System Powered On   | -                  |
| 4/12/2012 | 7:52:35  | DDA1-D: Red Pump Cavitation                 | No Event                    | -                  |
| 4/12/2012 | 7:52:39  | DDB2-D: Blue Pump Cavitation                | No Event                    | -                  |

### Example 2-JOB File

The 2-JOB file is the Shot Data Log file.


|    | A                            | B        | C                       | D                                | E                     | F                              | G                      | H                               | I                    | J                             | K                          |
|----|------------------------------|----------|-------------------------|----------------------------------|-----------------------|--------------------------------|------------------------|---------------------------------|----------------------|-------------------------------|----------------------------|
| 1  | Job Log                      |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 2  | S/N: 06201073                |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 3  | Software Part Number: 16N420 |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 4  | Software Version: 1.01.002   |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 5  | 4/23/2012 11:09              |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 6  |                              |          |                         |                                  |                       |                                |                        |                                 |                      |                               |                            |
| 7  | Date                         | Time     | Inline Blue<br>RTD Temp | Requested<br>Inline Blue<br>Temp | Hose Blue<br>FTS Temp | Requested<br>Hose Blue<br>Temp | Inline Red<br>RTD Temp | Requested<br>Inline Red<br>Temp | Hose Red FTS<br>Temp | Requested<br>Hose Red<br>Temp | Tank Bl<br>Materia<br>Temp |
| 8  | 4/11/2012                    | 14:16:52 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 9  | 4/11/2012                    | 14:16:54 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 10 | 4/11/2012                    | 14:16:56 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 11 | 4/11/2012                    | 14:16:58 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 12 | 4/11/2012                    | 14:17:00 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 13 | 4/11/2012                    | 14:17:02 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 14 | 4/11/2012                    | 14:17:04 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 15 | 4/11/2012                    | 14:17:07 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 16 | 4/11/2012                    | 14:17:09 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 17 | 4/11/2012                    | 14:17:11 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |
| 18 | 4/11/2012                    | 14:17:28 | -                       |                                  | -                     |                                |                        |                                 | -                    |                               |                            |

### Example 3-SYSTEM File

The 3-SYSTEM file is the Software Version log file.

|    | A                            | B       | C                    | D                | E | F | G | H |
|----|------------------------------|---------|----------------------|------------------|---|---|---|---|
| 1  | System Software Log          |         |                      |                  |   |   |   |   |
| 2  | S/N: 06201073                |         |                      |                  |   |   |   |   |
| 3  | Software Part Number: 16N420 |         |                      |                  |   |   |   |   |
| 4  | Software Version: 1.01.002   |         |                      |                  |   |   |   |   |
| 5  | 4/23/2012 11:11              |         |                      |                  |   |   |   |   |
| 6  |                              |         |                      |                  |   |   |   |   |
| 7  | Date                         | Time    | Node:                | Software Version |   |   |   |   |
| 8  | 4/23/2012                    | 6:53:49 | MCM Application Blue | 1.01.108         |   |   |   |   |
| 9  | 4/23/2012                    | 6:53:49 | MCM Component Blue   | 1.09.001         |   |   |   |   |
| 10 | 4/23/2012                    | 6:53:49 | Blue Tank Monitor    | 1.01.001         |   |   |   |   |
| 11 | 4/23/2012                    | 6:53:49 | Red Primary Heat     | 1.05.008         |   |   |   |   |
| 12 | 4/23/2012                    | 6:53:49 | Blue Hose Heat       | 1.05.008         |   |   |   |   |
| 13 | 4/23/2012                    | 6:53:49 | USB Configuration    | 1.07.001         |   |   |   |   |
| 14 | 4/23/2012                    | 6:53:49 | Advanced Display     | 1.01.003         |   |   |   |   |
| 15 | 4/23/2012                    | 6:53:50 | Blue Primary Heat    | 1.05.008         |   |   |   |   |
| 16 | 4/23/2012                    | 6:53:51 | Red Hose Heat        | 1.05.008         |   |   |   |   |
| 17 | 4/23/2012                    | 6:53:54 | Red Primary Heat     | 1.05.008         |   |   |   |   |
| 18 | 4/23/2012                    | 6:53:56 | Blue Primary Heat    | 1.05.008         |   |   |   |   |
| 19 |                              |         |                      |                  |   |   |   |   |
| 20 |                              |         |                      |                  |   |   |   |   |
| 21 |                              |         |                      |                  |   |   |   |   |

## Transfer System Settings



### NOTICE

Low-quality USB stick drives may lead to burning out the USB port on the ADM. Use only high-quality USB stick-drives with the ADM USB port.

Use the following process to transfer system settings from one machine to another.

1. Insert a high-quality USB stick-drive into the USB port on the system with the settings to be transferred. Once the download is complete the SETTINGS.TXT file will be located in the "DOWNLOAD" folder.

### NOTICE

The user should never attempt to modify the SETTINGS.TXT file in any way. Graco is not responsible for damages caused by an improperly modified setup file.

2. Plug the USB stick-drive into a computer.
3. Navigate to the DOWNLOAD folder.
4. Copy the SETTINGS.TXT file from the DOWNLOAD folder into the UPLOAD folder.
5. Remove the USB stick-drive from the computer and install it into the ADM USB port for the second machine. The software will automatically begin updating.

**NOTE:** Before the update begins the ADM automatically shuts down the system, aborting any in-progress dispensing. When the software is updating the system a pop-up box will appear to inform the user of the update and the system will lock. Once the update is complete the ADM will tell the user to cycle power to apply the updates. Once this box appears it is safe to remove the drive before cycling power.

6. When the software is done updating, remove the USB stick-drive from the ADM USB port and install in a computer.
7. Navigate to the UPLOAD folder and remove the SETTINGS.TXT file.

**NOTE:** Immediately after uploading the settings, remove the SETTINGS.TXT file from the UPLOAD folder to prevent accidental loss of data the next time the USB stick-drive is inserted into the ADM USB port. If there is a SETTINGS.TXT file in the UPLOAD folder when the USB stick-drive is inserted into the ADM USB port the software will try to update the ADM.

## Update Custom Language

### NOTICE

Low-quality USB stick drives may lead to burning out the USB port on the ADM. Use only high-quality USB stick-drives with the ADM USB port.

Use the following process to customize the text on the ADM. The language file DISPTTEXT.TXT can be modified in Excel but must be saved as a Unicode Text file with the extension .TXT in order for it to properly import.

1. Insert a high-quality USB stick-drive into the USB port on the system with the settings to be transferred. Once the download is complete the DISPTTEXT.TXT file will be located in the "DOWNLOAD" folder.
2. Plug the USB stick-drive into a computer.
3. Navigate to the DOWNLOAD folder.
4. Copy the DISPTTEXT.TXT file from the DOWNLOAD to your computer.
5. Use any data processing software such as Excel to edit the DISPTTEXT.TXT file. When done editing save the file as the "Unicode Text" format. See **Example DISPTTEXT.TXT File** on page 97.
  - a. In the first column, locate the string to change.
  - b. In the second column of the same row, enter the new string.
  - c. Save the file as a Unicode Text file. The name must remain "DISPTTEXT.TXT".
6. Copy the edited DISPTTEXT.TXT file into the UPLOAD folder.
7. Remove the USB stick-drive from the computer and install it into the ADM USB port. The software will automatically begin updating.

**NOTE:** Before the update begins the ADM automatically shuts down the system, aborting any in-progress dispensing. When the software is updating the system a pop-up box will appear to inform the user of the update and the system will lock. Once the update is complete the ADM will tell the user to cycle power to apply the updates. Once this box appears it is safe to remove the drive before cycling power.


8. When the software is done updating, remove the USB stick-drive from the ADM USB port and install in a computer.
9. Navigate to the UPLOAD folder and remove the DISPTTEXT.TXT file.

**NOTE:** Immediately following uploading the language file, remove the DISPTTEXT.TXT file from the UPLOAD folder to prevent accidental loss of data the next time the USB stick-drive is inserted into the ADM USB port. If there is a DISPTTEXT.TXT file in the UPLOAD folder when the USB stick-drive is inserted into the ADM USB port the software will try to update the ADM.

### Example SETTINGS.TXT File

**NOTICE**

The user should never attempt to modify the SETTINGS.TXT file in any way. Graco is not responsible for damages caused by an improperly modified setup file.



### Example DISPTXT.TXT File

|     | A                            | B      |
|-----|------------------------------|--------|
| 1   | English                      | Custom |
| 2   |                              |        |
| 234 | Blue MCM Overvoltage         |        |
| 235 | Blue MCM Undervoltage        |        |
| 236 | Blue Motor Encoder Fault     |        |
| 237 | Blue Motor Controller Fault  |        |
| 238 | Blue Motor Low Performance   |        |
| 239 | Blue Motor High Speed        |        |
| 240 | Blue Pump Failed to Move     |        |
| 241 | Invalid Setpoint Request     |        |
| 242 | Small Shot Request           |        |
| 243 | Pressure Imbalance           |        |
| 244 | Pumps Not Defined            |        |
| 245 | Invalid Learn Mode Data Blue |        |
| 246 | Invalid Weight Cal. Data     |        |
| 247 | Blue Position Sensor Fault   |        |
| 248 | Red Pressure Sensor Fault    |        |
| 249 | Blue Pressure Sensor Fault   |        |
| 250 | Blue Setpoint Not Reached    |        |
| 251 | Blue Setpoint Not Reached    |        |
| 252 | Blue Setpoint Exceeded       |        |

The screenshot also shows the application title bar 'DISPTXT' and the Windows taskbar at the bottom.

# Appendix G - Communications Gateway Module Installation Kit

## Overview

The Communications Gateway Module (CGM) provides a control link between the HFR (Hydraulic Fixed Ratio) or NVH (Noise, vibration & Harshness foam) Dispense type systems using a selected fieldbus. The CGM interface provides the means for report monitoring and control by external automation systems, robot or PLC.

See **Available Internal Data**, page 102 for a list of internal data from and to the HFR/ NVH system that can be viewed or modified by the PLC/ Robot fieldbus master. The data in that section is intended to be an alternative, smaller sized and more reliable map for controlling a HFR or NVH system than the communication interface defined in Graco manual 3A1704. Furthermore, this newer map will support some of the newer features provided by the HFR product, such as a Dynamic Mixer option, ability to change recirculation flow rates, and ability to request a dispense using the field bus interface. Both maps are supported by the HFR/ NVH system.

Order Graco Map token assembly 19C802, USB stick assembly 19C885 or kit assembly 26B872 to get the interface described in this document.

When the corresponding map outlined in this document is installed, the Map ID field and Map Name fields should be as the image provided in FIG. 30 on the corresponding Gateway setup screen on the HFR/NVH ADM display module. The Gateway setup screens are described later.




FIG. 30: New HFR map ID and Name Image

## Installation

### To install the CGM in the desired location:

1. Remove the access cover (D). Loosen the two screws (C) and remove the CGM from the base (B). See FIG. 31 .





FIG. 31

2. Mount base (B) in desired location with four screws supplied in this kit. See FIG. 32 page 99.






**FIG. 32**

3. Mount CGM (A) on base (B) with two screws (C).
4. Install access cover (D).
5. Connect CAN cable from either CAN connection on the CGM to the CAN connection found on the CGM to the CAN connection found on the bottom of the ADM. See FIG. 33.


**NOTICE**

To avoid severe damage to CGA modules, ensure the CAN cable is connected to the appropriate CAN connection.



**FIG. 33**

6. If Used, connect the Ethernet, DeviceNet, or Profibus cable to the CGM as applicable. Connect the other end of the cable to the FieldBus device. See FIG. 34.



**FIG. 34**

7. Perform the Install or update data map procedure in Communications Gateway Module, Instructions and Parts manual 312864.
8. See **Available Internal Data**, page 102 for details on FieldBus pinout setup.
9. Perform the setup to configure the FieldBus.

## Setup - Gateway Screens

The gateway screens are used to configure the fieldbus. These screens are shown only if a CGM is correctly installed in your system. See **Installation** page 98.

1. With the system on and enabled, press to access the setup screens.
2. Press the left arrow key once to navigate to the main gateway screen. See FIG. 35.

### EtherNet/IP FieldBus Screens

These screens are shown only if you have EtherNet/IP FieldBus CGM installed.

### Screen 1

This screen enables the user to set the IP address, DHCP settings, subnet mask, gateway, and DNS information. See FIG. 35.




FIG. 35 EtherNet/IP Fieldbus Screen 1

### Screen 2

This screen displays the hardware revision, system serial number, and data map identification information. See FIG. 36.




FIG. 36 EtherNet FieldBus Screen 2

### DeviceNet FieldBus Screen

These screens show only if you have a DeviceNet FieldBus CGM installed.

This screen enables the user to set the device address, and baud rate, and to view the hardware revision, system serial number, and data map identification information. See FIG. 37.




FIG. 37 DeviceNet FieldBus Screen

### PROFIBUS FieldBus Screen

These screens shown only if you have a PROFIBUS FieldBus CGM installed.

### Screen 1

This screen enables the user to set the IP address, DHCP settings, subnet mask, gateway, and DNS information. See FIG. 38.




FIG. 38 PROFIBUS FieldBus Screen 1



### Screen 2

This screen displays the hardware revision, system serial number, and data map identification information. See FIG. 39.




FIG. 39 PROFIBUS FieldBus Screen 2

### Screen 2

This screen enables the user to set the station name, install date, location tag, function tag, and description. See FIG. 41.




FIG. 41 PROFINET FieldBus Screen 2

### PROFINET Fieldbus Screens

These screens are shown only if you have a PROFINET FieldBus CGM installed.

#### Screen 1

This screen enables the user to set the IP address, DHCP settings, subnet mask, gateway, and DNS information. See FIG. 40.




FIG. 40 PROFINET FieldBus Screen 1

## Available Internal Data

See **I/O Signal Descriptions**, page 105 for additional details regarding each input/output unless stated otherwise.

- Bytes are stored in each instance in little endian order. (Byte order within instance: Least significant to most significant.)
- Values are subject to the same maximum and minimum restrictions of the ADM

### Input data (Signals from HFR/NVH to PLC/Controlling Logic)

| Instance | Byte(s) | Input Bit(s) | Description   |
|----------|---------|--------------|---|
| 0        | 0-1     | I00-I15      | Current Pressure, Blue Pump (in 0.01 of bar units)  |
| 1        | 2-3     | I16-I31      | Current Pressure, Red Pump (in 0.01 of bar units)   |
| 2        | 4-5     | I32-I47      | Current Flow Rate (in 0.01 of cc/sec or g/sec units)  |
| 3        | 6-7     | I48-I63      | Flow Rate or pressure Set Point for Current or Next Dispense (in 0.01 cc/sec, 0.01 g/sec or 0.01 bar units) |
| 4        | 8-9     | I64-I79      | Current Dispense Duration, which counts up starting from 0 (in 0.01 second units).                          |
| 5        | 10-13   | I80-I111     | Amount for current Dispense (In 0.01 CC or 0.01 Gram units, starting from 0)                                |
| 6        | 14-17   | I112-I143    | Amount Set point for Current Dispense (In 0.01 CC, 0.01 Gram, or 0.001 second units, Shot & Sequence Modes) |
| 7        | 18      | I144-I151    | Current Mode Selected.  |
| 8        | 19      | I162-I159    | Current Active Shot Number (1-100, Shot Mode) or Sequence Position (1-20, Sequence Mode).                   |

|    |       |           |   |
|----|-------|-----------|---|
| 9  | 20    | I160-I167 | Current Sequence number (1- 26, for A-Z) selected (Sequence mode only)                  |
| 10 | 21    | I168      | Heart Beat from HFR/NVH MCM (#)   |
|    |       | I169      | Dispense Valve Open/Dispense Active   |
|    |       | I170      | Recirculation Valve Opened (HFR Only)   |
|    |       | I171      | System Startup Command Active   |
|    |       | I172      | Pumps are Parked  |
|    |       | I173      | High Pressure Recirculation Active (NVH Only)   |
|    |       | I174      | Cold Startup Active (Currently NVH Only)  |
|    |       | I175      | System is "Ready" for Dispense Request.   |
| 11 | 22-23 | I176-I191 | Configurable Data Element 1. Default: Additional Status Bits (See Appendix B, #140)     |
| 12 | 24-25 | I192-I207 | Configurable Data Element 2. Default: Error Number Requiring Acknowledgment (0 = None). |
| 13 | 26-27 | I208-I223 | Data Exchange Interface - Pointer Last Serviced (*)                                     |
| 14 | 28-31 | I224-I255 | Data Exchange Interface - Input Data Element (*)  |

**NOTES:**

\* See **Appendix B - ADM Setup Screens Overview** for data exchange.

# Heart Beat signal change from high to low, and low to high at a 0.25 hertz rate.

### Output Data (Signals from PLC to HFR/NVH System)

| Instance | Byte(s) | Output Bit(s) | Description  |
|----------|---------|---------------|--|
| 0        | 0       | O00-O07       | Mode Select Command  |
| 1        | 1       | O08-O15       | Shot Number (1-100) or Sequence Position (1-20) Command. (Shot or Sequence modes only) |
| 2        | 2       | O16-O23       | Sequence Number Select (1-26)  |
| 3        | 3       | O24           | Dispense Valve Open Request (Standby Mode Only)  |
|          |         | O25           | Recirculation Valve Open Request (HFR Only)  |
|          |         | O26           | System Startup Command   |
|          |         | O27           | Park Pump(s) Request (Standby Mode Only)   |
|          |         | O28           | High Pressure Recirculation Request (NVH Only)   |
|          |         | O29           | Dispense Request (@)   |
|          |         | O30           | Spare Command bit 1  |
|          |         | O31           | Spare Command bit 2  |
| 4        | 4-5     | O32           | Turn On System Request   |
|          |         | O33           | PLC/ Robot (CGM) Control Request   |
|          |         | O34           | Heart Beat from PLC (#)  |
|          |         | O35           | ADM Lock Out Request   |
|          |         | O36           | Red Tank Manual Fill Request   |
|          |         | O37           | Blue Tank Manual Fill Request  |
|          |         | O38           | Turn ON Temperature Zones command  |
|          |         | O39           | Disable Dispensing Request (ADM, PLC & Footswitch).                                    |
|          |         | O40           | TBD Bit Command1   |
|          |         | O41           | TBD Bit Command2   |
|          |         | O42           | TBD Bit Command3   |
|          |         | O43           | TBD Bit Command4   |
|          |         | O44           | TBD Bit Command5   |
|          |         | O45           | TBD Bit Command6   |
|          |         | O46           | TBD Bit Command7   |
|          |         | O47           | TBD Bit Command8   |

|    |       |           |  |
|----|-------|-----------|--|
| 5  | 6-7   | O48-O63   | Flow Rate or Pressure Set Point Command for Selected Dispense (in 0.01 cc/sec, 0.01 g/sec or 0.01 bar units, Operator or Shot Modes only).         |
| 6  | 8-9   | O64-O79   | Flow Rate Set Point for Circulation (HFR Only). (in 0.01 cc/sec, 0.01 g/sec units)   |
| 7  | 10-11 | O80-O95   | Error Number Acknowledgment Command (0 = None).  |
| 8  | 12-13 | O96-O111  | Configurable Data Command 1 Default: None  |
| 9  | 14-15 | O112-O127 | Configurable Data Command 2. Default: None   |
| 10 | 16-17 | O128-O143 | Configurable Data Command 3. Default: None   |
| 11 | 18-19 | O144-O159 | Configurable Data Command 4. Default: None   |
| 12 | 20-21 | O160-O175 | Data Exchange Interface – Data Pointer Command (*)   |
| 13 | 22-25 | O176-O207 | Data Exchange Interface – Output Data Element (*)  |
| 14 | 26-29 | O208-O239 | Dispense Amount Set point for Selected Dispense (In 0.01 CC, 0.01 Gram, or 0.001 second units, Shot Mode Only, System must be idle or Circulating) |

#### NOTES:

\* See Appendix B for Data Exchange Interface details.

# Heart Beat signal from PLC need to change state (high to low, and low to high) at least every 4 to 5 seconds. This signal is necessary for the PLC Control the HFR or NVH system.


@ Dispense Request to the HFR is similar to a dispense request using a foot switch (Operator Mode – Press and hold (= 1) entire shot duration, Shot & Sequence modes tap (= 1) to start then release (= 0) and repeat during dispense to abort if necessary).

## Run Screens Available Data.


The HFR/ NVH system software version 1.13.009 or later has two run screens that provide the data between the HFR or NVH system, and the controlling PLC or Robot logic. The screens are available if the HFR/ NVH system detects the presence of a CGM module with the correct map ID.

### Run Screen 1

The first run screen (to the left of the main home screen) provides graphical representations of the data provided to the controlling logic. The bit data below is on (high) when the circle graphic is green, and off (low) when the graphic is Grey. See **New Fieldbus Data Indications Screen** FIG. 42.



**FIG. 43 New Fieldbus Data Commands Screen**



**FIG. 42 New Fieldbus Data Indications Screen**

### Run Screen 2

The second run screen, the Fieldbus commands screen provides graphical representations for the control data requested from the PLC or robot to the HFR/ NVH logic. The commands screen provides a green graphic when a bit request is on (high), and a grey graphic when the bit command is off or low. See FIG. 43.

## I/O Signal Descriptions

This section provides details about the CGM Automation Input and Output Signals.

### PLC/Robot (CGM) Control Request (O33):

This bit must be set (high) before the HFR or NVH will honor any output request from the PLC, robot or controlling logic. Furthermore, the controlling logic needs to provide a dynamic signal to O34 (heart beat from PLC (#)) before requesting control of the HFR or NVH system (refer to “#” note). A simple logic rung where the heart beat output from the HFR (I168) is provided to O34 will satisfy this condition. If the controlling logic only wants to monitor HFR/ NVH activity, clear or make O33 low.

### Mode Selection (Input Instance 7, Output Instance 0)

The signals shown in the following table represent the mode of the HFR or NVH system. The modes shown in the following table are available:

| Mode Number | Mode Name | Description  |
|-------------|-----------|--|
| 1           | Disabled  | Mode when system is OFF. System is off and dormant.  |
| 2           | Standby   | Mode for Parking the pumps, starting circulation (NVH), opening the Dispense Valve. Can NOT dispense in this mode                          |
| 3           | Shot      | Mode for dispensing set amount of material. Up 100 shot recipes (recipe is a dispense rate ((flow or pressure)) and amount) are available. |
| 4           | Sequence  | Mode for dispensing a sequence of up to 20 shot recipes. Up to 26 sequences can be used and stored by the HFR/ NVH.                        |
| 5           | Operator  | Mode for dispensing at a given rate, with no pre-calculated amount.  |
| 7           | Night     | Mode for recirculating and conditioning the materials, while machine not in use. Can NOT dispense material in this mode.                   |

### Shot Number (Input Instance 8, Output Instance 1):

Shot recipes are typically defined on the ADM shot setup screen pages. A shot consists of a dispense rate (flow or pressure) and an amount dispensed (volume, weight or time). The rate is determined if the machine is in constant flow or constant pressure modes. The amount is determined if in volumetric, weight, or a time based amount mode.

### Sequence and Sequence Positions (Input Instances 8 and 9, Output Instances 1 and 2):

When in sequence mode, the data element represents the current (input) or selected (output) position of sequence of shot recipes. The HFR/ NVH system provides capability for 26 different sequences (A – Z), each with up to 20 positions. The sequences can be defined using the sequences screens in the ADM. See FIG. 44. Positions in possible 20 positions can be skipped, and the HFR/ NVH will automatically execute the next defined position. For example, if the controlling PLC requests Sequence Y (#25) position 1, as illustrated in FIG. 44 below, the HFR will execute shot 11 from position 1, shot 12 from position 2, shot 15 from position 5, and finish the sequence with shot 16 from position 9 after each dispense request (O29). To execute the entire sequence, the controlling PLC needs to generated 6 dispense requests when the dispense is to occur. If the controlling PLC requests a position or sequence which is not defined (for instance, sequence Y position 7), the un-defined portion of the request will be ignored.

| Sequence | Shot | Amount (cc) |
|----------|------|-------------|
| Y1       | 11   | 101.0       |
| Y2       | 12   | 102.0       |
| Y3       | 13   | 103.0       |
| Y4       | 14   | 104.0       |
| Y5       | 15   | 105.0       |
| Y6       | 0    | 0           |
| Y7       | 0    | 0           |
| Y8       | 0    | 0           |
| Y9       | 16   | 106.0       |
| Y10      | 0    | 0           |

FIG. 44 Typical Sequence Definition Screen.

### System Startup Control (I171,O26)

Setting the O26 bit will request the following items, based on the figuration of the HFR or NVH system:

- Setting the O26 starts the pumps to circulate material at the recirculation flow rate. If in night mode, the auto circulate between dispenses feature is on and pumps are idle (shot, sequence or operator modes). If the HFR recirculation valves are installed and the recirculation valves are opened



they will display the icon when in shot, sequence or operator modes.

- Setting the O26 bit will pressurize the pumps if in operator mode. Setting this mode makes the system ready for dispensing if using the manual controlled fusion/ P2 dispense valve option only.
- Setting the O26 bit will start the pumps into low pressure circulation mode, and will start the cold start process (if at start up condition) if there is a NVH system.

Clearing the system startup bit will perform the opposite as described above.

### High Pressure Recirculation (I173 and O28):

Setting this bit will command the NVH or full recirculation system into high Pressure mode, required to dispensing material.

### Cold Startup Active (I174):

This indication informs the PLC that a cold startup process is active. If active, the NVH system is slowly starting the pumps and applying heat to the materials to lower the material viscosity (and consequently pump pressures) preparing the materials for dispense. As the process continues, the NVH will slowly increase the material flow as the pump pressures lower due to lowering of the material viscosities. When the process is completed (typically taking about 1/2 an hour), the materials are ready for dispensing. This process is started by setting the system startup control bit after the NVH system has been idle for some time.

### System is "Ready" for Dispense Request. (I175):

This informs the controlling logic it is OK to request a dispense. If set, there are no active alarms, system is in a dispensing mode (operator, shot or sequence), and circulating material if necessary (auto circulation between dispenses on or circulation is on if a NVH system).

### Dispense Request (O29):

This PLC output can be used in place of the foot switch input into the HFR for requesting dispenses. However, if the excessive field bus traffic is present or the field bus has many nodes, the request response time may not be as fast or consistent as using the foot switch input.

### ADM Lock Out (O35), Bit 2 Indication from Additional Status Bits register:

If active, all keys on the ADM will be disabled with exception of the ADM RED key, the run screen navigation keys and the user will be able to acknowledge errors. The soft keys will be visible but will be indications only.

If the controlling PLC clears the PLC/ robot (CGM) control request output (O33), an active ADM lockout condition will be automatically cleared. See Fig. 45.




FIG. 45 HFR automatically circulating after a sequence Z dispense, in ADM lockout mode

### Data Exchange Interface

This is bi-directional interface which provides both transmit and reception of data between the HFR/ NVH system, and the controlling logic (PLC, robot or equivalent). The interface allows a large amount of data to exchange between the systems, while only occupying a very small portion of the map to support the exchange. The interface also allows for future expansion of data without changing the map structure.

**To get, receive or read data from the HFR/ NVH system, the controlling PLC needs to:**

1. Write to the data exchange interface – data pointer command location on the map (output bytes 20 – 21, O160 – O175) a value corresponding to the data the PLC wants to receive.
2. Wait for the HFR to provide the same data exchange interface - Pointer Last Serviced “ number written in the previous step at input byte locations 26 – 27 (I208 – I223).
3. Read the requested data at input byte locations 28 – 31 (I224 – I255), data exchange interface – input data element

**To write or transmit data to the HFR system, the controlling PLC needs to:**

1. Write the data for the HFR system to data exchange interface – output data element location, output byte locations 22 – 25 (O176 – O207).
2. Write to the data exchange interface – data pointer command location on the map (output bytes 20 – 21, O160 – O175) a value corresponding to the data the PLC wants to transmit to the HFR.
3. The HFR will echo back to the PLC the data pointer and the data element after the HFR system processes the data transmit request to input locations 26 – 27 (I208 – I223), and input locations 28 – 31 (I224 – I255) respectively.

**NOTE:** When changes are made over the data exchange interface, the HFR/ NVH system display screen may not update immediately. It may be necessary to navigate away from the screen then back to it, or a new dispense may need to be triggered.

**NOTE:** All Read designations on the Data Exchange are assigned and Even numbers, whereas all Write designations are assigned an Odd number assignments.

## Data Exchange Interface Pointer Designation Table

| Data Exchange Pointer Designation | Description  | Comments, Data Element Descriptions                            | Read/Write |
|-----------------------------------|--|--|------------|
| 0                                 | Interface Not Active                                     | -----  | ---        |
| 1                                 | Red Material Tank Heat, Set point temperature            | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 2                                 |  |  | Read       |
| 3                                 | Blue Material Tank Heat, Set Point temperature           | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 4                                 |  |  | Read       |
| 5                                 | Red Material Inline Heater, Set point temperature        | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 6                                 |  |  | Read       |
| 7                                 | Blue Material Inline Heater, Set Point temperature       | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 8                                 |  |  | Read       |
| 9                                 | Red Material Hose Heat, Set point temperature            | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 10                                |  |  | Read       |
| 11                                | Blue Material Hose Heat, Set Point temperature           | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 12                                |  |  | Read       |
| 13                                | Red Material Chiller Temperature, Set point temperature  | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 14                                |  |  | Read       |
| 15                                | Blue Material Chiller Temperature, Set Point temperature | Set or Get Set Point temperature, in 0.1 C <sup>0</sup> units. | Write      |
| 16                                |  |  | Read       |
| 80                                | Red Material Tank Zone, temperature                      | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units.  | Read       |
| 82                                | Blue Material Tank Zone, temperature                     | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units.  | Read       |
| 84                                | Red Tank Blanket Zone, temperature                       | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 86                                | Blue Tank Blanket Zone, temperature                      | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 88                                | Red Material Inline Heater Zone, temperature             | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 90                                | Blue Material Inline Heater Zone, temperature            | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 92                                | Red Material Hose Heat Zone, temperature                 | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 94                                | Blue Material Hose Heat, temperature                     | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |
| 96                                | Red Material Chiller Zone, temperature                   | Current Zone Actual Temperature, in 0.1 C <sup>0</sup> units   | Read       |



| Data Exchange Pointer Designation | Description                             | Comments, Data Element Descriptions  | Read/Write |
|-----------------------------------|---|--|------------|
| 98                                | Blue Material Chiller Zone, temperature | Current Zone Actual Temperature, in 0.1 C° units   | Read       |
| 102                               | Heater Zones Enabled Bit Masks          | Bit 0 = Red Tank Zone Enabled (1) or Disabled (0).<br>Bit 1 = Blue Tank Zone Enabled or Disabled.<br>Bit 2 = Red Inline Heater Enabled or Disabled.<br>Bit 3 = Blue Inline Heater Enabled or Disabled.<br>Bit 4 = Red Hose Heater Enabled or Disabled.<br>Bit 5 = Blue Hose Heater Enabled or Disabled.<br>Bit 6 = Red Chiller Enabled or Disabled.<br>Bit 7 = Blue Chiller Enabled or Disabled. | Read       |
| 103                               | Heater Zones On/Off Bit Masks           | Bit 0 = Red Tank Zone Turned ON (1)/ Off (0).<br>Bit 1 = Blue Tank Zone Turned ON/ Off.<br>Bit 2 = Red Inline Heater Turned ON/ Off.<br>Bit 3 = Blue Inline Heater Turned ON/ Off.<br>Bit 4 = Red Hose Heater Turned ON/ Off.<br>Bit 5 = Blue Hose Heater Turned ON/ Off.<br>Bit 6 = Red Chiller Turned ON/ Off.<br>Bit 7 = Blue Chiller Turned ON/ Off.   | Write      |
| 104                               |   |  | Read       |
| 120                               | Current Tank Level Status               | Least Significant Byte – Red Tank Level<br>2 <sup>nd</sup> Significant Byte – Blue Tank Level<br>Level indications/ Byte:<br>1 = Material is below Low Level sensor.<br>2 = Material between Low and High Level (2 <sup>nd</sup> ) sensors.<br>3 = Tank Full (at 2 <sup>nd</sup> sensor, or above).<br>7 = Material at or above top sensor (“Report xxx High Level in bit 2” feature ON).        | Read       |
| 121                               | Tank Filling Control/Status, Red Tank   | 1 = Active Filling (Read) or Manual Fill Request (Write).<br>0 = Filling NOT Active (Read), or Abort Manual Fill (Write).  | Write      |
| 122                               |   |  | Read       |
| 123                               | Tank Filling Control/Status, Blue Tank  | 1 = Active Filling (Read) or Manual Fill Request (Write).<br>0 = Filling NOT Active (Read), or Abort Manual Fill (Write).  | Write      |
| 124                               |   |  | Read       |
| 130                               | Ratio, Setpoint                         | In 0.001:1 units of measure. So for instance, a value of 23680 = 23.680:1. Ratio may be inverted based on the setting of the “Ratio:” control selection on the System #3 setup screen. Ratios are either volumetric or weight depending upon the “Flow Units” Selection on the ADM Advanced #2 setup screen.   | Read       |
| 132                               | Ratio, Actual                           | In 0.001:1 units of measure. So for instance, a value of 23721 = 23.721:1. Ratio may be inverted based on the setting of the “Ratio:” control selection on the System #3 setup screen. This data is only valid if HFR or NVH has a Ratio Monitoring option installed.  | Read       |

| Data Exchange Pointer Designation | Description   | Comments, Data Element Descriptions  | Read/Write |
|-----------------------------------|---|--|------------|
| 140                               | Additional Status Bits  | Bit 0: Heart Beat Signal from HFR/ NVH ADM Module.<br>Bit 1: System is "Ready" for Dispense Request.<br>Bit 2: ADM Lockout Active.<br>Bit 3: PLC/ Robot Control Active.<br>Bit 4: Active/ Valid PLC Heart Beat Signal Received by HFR.<br>Bit 5: Alarm is Active<br>Bit 6: Deviation is Active.<br>Bit 7: Advisory is Active.<br>Bit 8: Spare Bit indication for future use.<br>Bit 9: Dispensing is Disabled (ADM, PLC & Footswitch).<br>Bit 10: Clean Out Rod Process Active (L-Systems Only)<br>Bit 11-15: Spare bit indications for future use | Read       |
| 151                               | Error number requiring Acknowledgement  | See error number table in next section. Writing to this register with the error number read, will clear the Error code pop-up window from the HFR screen. If the condition is still present after acknowledgment, the same error number acknowledged will be provided in the next read instruction below.  | Write      |
| 152                               |   |  | Read       |
| 154                               | Error Number Active in System   | See error number table in next section. If more than 1 error is present, the next read will provide the second error number present. If only 2 errors are present, the 3 <sup>rd</sup> read will provide the 1 <sup>st</sup> error provided. If this register is assigned one of the read configurable data registers (see next items in table), if more than 1 error is present, the HFR will present all the active error numbers at approximately a 1 hertz rate.   | Read       |
| 161                               | Set or Read Register "Configurable Data Element 1" Assignment (Input instance 11, I176 – I191)  | Register assignments must be an Even number, and correspond to the Read Assignments in this Table. Once set (Write), the HFR/ NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide data, or smaller.  | Write      |
| 162                               | Assignment (Output instance 12, I192 – I207)  |  | Read       |
| 163                               | Set or Read Register "Configurable Data Element 2" Assignment (Output instance 12, I192 – I207) | Register assignments must be an Even number, and correspond to any Read Assignment in this Table. Once set (Write), the HFR/ NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide data, or smaller  | Write      |
| 164                               | Assignment (Output instance 12, I192 – I207)  |  | Read       |
| 181                               | Set or Read Register "Configurable Data Command 1" Assignment (Output instance 8, O88 – O103)   | Register assignments must be an Odd number, and correspond to any Write Assignment in this Table. Once set (Write), the HFR/ NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide, or smaller.  | Write      |
| 182                               | Assignment (Output instance 8, O88 – O103)  |  | Read       |

| <b>Data Exchange Pointer Designation</b> | <b>Description</b>                                    | <b>Comments, Data Element Descriptions</b>   | <b>Read/Write</b> |
|--|---|--|-------------------|
| 183                                      | Set or Read Register<br>"Configurable Data Command 2" | Register assignments must be an Odd number, and correspond to any Write Assignment in this Table. Once set (Write), the HFR/NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide, or smaller. | Write             |
| 184                                      | Assignment (Output instance 9, O104 – O119)           |  | Read              |
| 185                                      | Set or Read Register<br>"Configurable Data Command 3" | Register assignments must be an Odd number, and correspond to any Write Assignment in this Table. Once set (Write), the HFR/NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide, or smaller. | Write             |
| 186                                      | Assignment (Output instance 10, O120 – O135)          |  | Read              |
| 187                                      | Set or Read Register<br>"Configurable Data Command 4" | Register assignments must be an Odd number, and correspond to any Write Assignment in this Table. Once set (Write), the HFR/NVH will remember the assignment, even after a power cycle. Register assignments should be 16 bits wide, or smaller. | Write             |
| 188                                      | Assignment (Output instance 11, O136 – O151)          |  | Read              |
| 200                                      | Mixed Material in Current or Last Dispense            | Sum of Blue and Red Materials Dispensed (In 0.01 CC or 0.01 Gram units)  | Read              |
| 202                                      | Blue Material in Current or Last Dispense             | (In 0.01 CC or 0.01 Gram units)  | Read              |
| 204                                      | Red Material in Current or Last Dispense              | (In 0.01 CC or 0.01 Gram units)  | Read              |
| 206                                      | Mixed Material Resettable Counter                     | Sum of Blue and Red Resettable Counters (In 0.01 CC or 0.01 Gram units)  | Read              |
| 208                                      | Blue Material Resettable Counter                      | (In 0.01 CC or 0.01 Gram units)  | Read              |
| 210                                      | Red Material Resettable Counter                       | (In 0.01 CC or 0.01 Gram units)  | Read              |
| 212                                      | Pump Resettable Counter                               | (in pump cycles)   | Read              |
| 213                                      | Reset All Resettable Material Counters                | Will set all the resettable counters to 0. System must be idle (Pumps NOT moving) for this command to execute.   | Write             |
| 220                                      | Mixed Material Total Counter                          | Sum of Blue and Red material dispensed from HFR or NVH (In 1 CC or 1 Gram units)   | Read              |
| 222                                      | Blue Material Total Counter                           | Sum of Blue material dispensed from HFR or NVH (In 1 CC or 1 Gram units)   | Read              |
| 224                                      | Red Material Total Counter                            | Sum of Red material dispensed from HFR or NVH (In 1 CC or 1 Gram units)  | Read              |
| 226                                      | Total Pump Cycle Counter                              | Total number of pump cycles for the NVH/ HFR system.   | Read              |

| Data Exchange Pointer Designation | Description  | Comments, Data Element Descriptions  | Read/Write |
|-----------------------------------|--|--|------------|
| 231                               | Dynamic Mixer  | In RPM. Only valid if using Dynamic Mixer (Vortex) option.   | Write      |
| 232                               | Speed Set Point.                                     |  | Read       |
| 234                               | Dynamic Mixer Actual Speed                           | In RPM. Only valid if using Dynamic Mixer (Vortex) option.   | Read       |
| 235                               | Dynamic Mixer Air Nucleation On Time                 | In milli-second increments. Only valid if using Dynamic Mixer (Vortex) option, and "Air Nucleation" turned ON (System #4 setup screen).  | Write      |
| 236                               |  |  | Read       |
| 237                               | Dynamic Mixer Air Nucleation Off Time                | In milli-second increments. Only valid if using Dynamic Mixer (Vortex) option, and "Air Nucleation" turned ON (System #4 setup screen).  | Write      |
| 238                               |  |  | Read       |
| 239                               | Dynamic Mixer, Motor Ramp Up Time                    | In milli-second increments. Only valid if using Dynamic Mixer (Vortex) option.   | Write      |
| 240                               |  |  | Read       |
| 241                               | Dynamic Mixer, On/Off State/ Request                 | 1 = Motor On (read), or Turn ON Request (write). If sending a Turn On Request, the system should be idle and Not dispensing.   | Write      |
| 242                               |  |  | Read       |
| 243                               | Dynamic Mixer, Air Nucleation On/ Off State/ Request | 1 = Air On (read), or Air ON Request (write). If sending a Turn On Request, the system should be idle and Not dispensing.  | Write      |
| 244                               |  |  | Read       |
| 251                               | Recirculation Flow Rate Set Point                    | Set (Write) or get (read) the recirculation flow rate set point in in 0.01 cc/sec, 0.01 g/sec units (HFR Systems with Circulation Valves Installed).   | Write      |
| 252                               |  |  | Read       |
| 253                               | Low pressure Circulation Percentage                  | Set (Write) or get (read) the Low pressure Circulation flow rate percentage (System #2 Setup screen). Values of 10 – 90 % allowed (NVH Systems only).  | Write      |
| 254                               |  |  | Read       |
| 260                               | Read System Version                                  | A 32-bit string in the format of 0xXXCCBBAA.<br>0xCC...Build Version<br>0xBB...Minor Version<br>0xAA...Major Version   | Read       |
| 262                               | Read System Date                                     | A 32-bit string in the format of 0xDDCCBBAA.<br>0xDD...Year (0x0D corresponds to 2013)<br>0xCC...Month (0x0A corresponds to October)<br>0xBB...Day<br>0xAA...Day of Week (0x01 Corresponds to Monday)  | Read       |
| 271                               | Cavitation Errors Disabled                           | Set (Write) or get (Read) if the Cavitation Error generation logic is Disabled (= 1, not recommended for production use) or Enabled (= 0, if logic is Active). Refer to "Cavitation Errors Disabled" option on ADM Advanced #3 setup screen for current state. | Write      |
| 272                               |  |  | Read       |
| 273-65, xxx                       | Reserved for Future Use                              | -----  | -----      |

## Error Number Tables:

The following table documents all the possible error numbers and codes generated by a HFR or NVH system. If no error is present, a 0 will be provided in the corresponding register (No Active Errors). The Code column indicates the 4 digit code presented to the user on the ADM. The following error codes have been assigned one of the 3 possible levels, documented in column 4:

- Alarm (A) – Most severe, typically shutting down the system.
- Deviation (D) – Less severe condition which may or may not shut down the system.
- Advisory (V) – Simply a warning, which does NOT shut down a system.

The last column reflects the text description provided to the user (when HFR/ NVH configured to English) when the error number is generated.

| Item # | Error Number | Code | Level | Description                 |
|--------|--------------|------|-------|-----------------------------|
| 0      | 0            | n/a  | ---   | No Active Errors            |
| 1      | 1            | T4N1 | A     | Blue Motor Temp. Shutdown   |
| 2      | 2            | T3N1 | V     | Blue Motor Temp. Cutback    |
| 3      | 3            | T4H1 | A     | Blue MCM Oil Temp. Shutdown |
| 4      | 4            | T3H1 | D     | Blue MCM Oil Temp. Cutback  |
| 5      | 5            | MBH1 | A     | Blue MCM Low Oil Level      |
| 6      | 6            | A4H1 | A     | Blue Motor Over Current     |
| 7      | 7            | A4N1 | A     | Blue Motor Over Current     |
| 8      | 8            | A4M1 | A     | Blue Motor Over Current     |
| 9      | 9            | A9C1 | A     | Blue Motor Over Current     |
| 10     | 10           | T4C1 | A     | Blue MCM High Temp.         |
| 11     | 11           | V4H0 | A     | Blue MCM Overvoltage        |
| 12     | 12           | V1H1 | A     | Blue MCM Undervoltage       |
| 13     | 13           | WBH1 | A     | Blue Motor Encoder Fault    |

| Item # | Error Number | Code | Level | Description                    |
|--------|--------------|------|-------|--------------------------------|
| 14     | 14           | WMH1 | D     | Blue Motor Controller Fault    |
| 15     | 15           | MBN1 | V     | Blue Motor Low Performance     |
| 16     | 16           | WKH1 | A     | Blue Motor High Speed          |
| 17     | 17           | N4A1 | D     | Blue Pump Failed to Move       |
| 18     | 18           | WSC0 | D     | Invalid Setpoint Request       |
| 19     | 19           | B9C0 | D     | Small Shot Request             |
| 20     | 20           | P4D0 | A     | Pressure Imbalance             |
| 21     | 21           | DSC0 | A     | Pumps Not Defined              |
| 22     | 22           | D5A1 | D     | Invalid Learn Mode Data Blue   |
| 23     | 23           | 500  | D     | Invalid Weight Cal. Data       |
| 24     | 24           | D6A1 | A     | Blue Position Sensor Fault     |
| 25     | 25           | P6A1 | A     | Red Pressure Sensor Fault      |
| 26     | 26           | P6B2 | A     | Blue Pressure Sensor Fault     |
| 27     | 27           | D1A1 | D     | Blue Setpoint Not Reached      |
| 28     | 28           | D4A1 | D     | Blue Setpoint Exceeded         |
| 29     | 30           | P4A1 | A     | Red Pressure Shutdown          |
| 30     | 31           | P4B2 | A     | Blue Pressure Shutdown         |
| 31     | 32           | DFA1 | D     | Red Pump Not Parked            |
| 32     | 33           | F7D1 | D     | Blue Pump Failed to Stall      |
| 33     | 34           | WSD0 | D     | Invalid Gel Timer Definition   |
| 34     | 35           | DDA1 | D     | Red Pump Cavitation            |
| 35     | 36           | DDB2 | D     | Blue Pump Cavitation           |
| 36     | 43           | WDF1 | D     | Dispense Valve Open Problem    |
| 37     | 44           | WDF1 | A     | Dispense Valve Failed to Close |
| 38     | 62           | WSC0 | D     | Invalid Setpoint Request       |

| Item # | Error Number | Code | Level | Description                |
|--------|--------------|------|-------|----------------------------|
| 39     | 63           | B9C1 | D     | Small Shot Request         |
| 40     | 69           | P4A1 | A     | Red Pressure Shutdown      |
| 41     | 72           | DDA1 | D     | Red Pump Cavitation        |
| 42     | 73           | T9A6 | A     | Red Blanket Temp. Cutoff   |
| 43     | 74           | T9B5 | A     | Blue Blanket Temp. Cutoff  |
| 44     | 75           | T9A3 | A     | Red Inline Temp. Cutoff    |
| 45     | 76           | T9B1 | A     | Blue Inline Temp. Cutoff   |
| 46     | 77           | A8A6 | D     | No Red Blanket Current     |
| 47     | 78           | A8B5 | D     | No Blue Blanket Current    |
| 48     | 79           | A8A3 | D     | No Red Inline Current      |
| 49     | 80           | A8B1 | D     | No Blue Inline Current     |
| 50     | 81           | A8A2 | D     | No Red Hose Current        |
| 51     | 82           | A8B4 | D     | No Blue Hose Current       |
| 52     | 83           | A8B7 | D     | No Red Chiller Current     |
| 53     | 84           | A8B8 | D     | No Blue Chiller Current    |
| 54     | 85           | A4A6 | A     | Red Blanket Overcurrent    |
| 55     | 86           | A4B5 | A     | Blue Blanket Overcurrent   |
| 56     | 87           | A4A3 | A     | Red Inline                 |
| 57     | 88           | A4B1 |       | Blue Inline Overcurrent    |
| 58     | 89           | A4A2 | A     | Red Hose Overcurrent       |
| 59     | 90           | A4B4 | A     | Blue Hose Overcurrent      |
| 60     | 91           | A4A7 | A     | Red Chiller Overcurrent    |
| 61     | 92           | A4B8 | A     | Blue Chiller Overcurrent   |
| 62     | 93           | A7A6 | A     | Red Blanket Control Fault  |
| 63     | 94           | A7B5 | A     | Blue Blanket Control Fault |

| Item # | Error Number | Code | Level | Description                |
|--------|--------------|------|-------|----------------------------|
| 64     | 95           | A7A3 | A     | Red Inline Control Fault   |
| 65     | 96           | A7B1 | A     | Blue Inline Control Fault  |
| 66     | 97           | A7A2 | A     | Red Hose Control Fault     |
| 67     | 98           | A7B4 | A     | Blue Hose Control Fault    |
| 68     | 99           | A7A7 | A     | Red Chiller Control Fault  |
| 69     | 100          | A7B8 | A     | Blue Chiller Control Fault |
| 70     | 101          | V4A6 | A     | Red Blanket Overvoltage    |
| 71     | 102          | V4B5 | A     | Blue Blanket Overvoltage   |
| 72     | 103          | V4A3 | A     | Red Inline Overvoltage     |
| 73     | 104          | V4B1 | A     | Blue Inline Overvoltage    |
| 74     | 105          | V4A2 | A     | Red Hose Overvoltage       |
| 75     | 106          | V4B4 | A     | Blue Hose Overvoltage      |
| 76     | 107          | V4A7 | A     | Red Chiller Overvoltage    |
| 77     | 108          | V4B8 | A     | Blue Chiller Overvoltage   |
| 78     | 117          | T9C6 | A     | Red Blanket Ctrl Shutdown  |
| 79     | 118          | T9C5 | A     | Blue Blanket Ctrl Shutdown |
| 80     | 119          | T9C3 | A     | Red Inline Ctrl Shutdown   |
| 81     | 120          | T9C1 | A     | Blue Inline Ctrl Shutdown  |
| 82     | 121          | T9C2 | A     | Red Hose Ctrl Shutdown     |
| 83     | 122          | T9C4 | A     | Blue Hose Ctrl Shutdown    |
| 84     | 123          | T9C7 | A     | Red Chiller Ctrl Shutdown  |
| 85     | 124          | T9C8 | A     | Blue Chiller Ctrl Shutdown |

| Item # | Error Number | Code | Level | Description                   |
|--------|--------------|------|-------|-------------------------------|
| 86     | 125          | WMC6 | V     | Red Tank Con. Cutback         |
| 87     | 126          | WMC5 | V     | Blue Tank Con. Cutback        |
| 88     | 127          | WMC3 | V     | Red Inline Con. Cutback       |
| 89     | 128          | WMC1 | V     | Blue Inline Con. Cutback      |
| 90     | 129          | WMC2 | V     | Red Hose Con. Cutback         |
| 91     | 130          | WMC4 | V     | Blue Hose Con. Cutback        |
| 92     | 131          | WMC7 | V     | Red Chiller Con. Cutback      |
| 93     | 132          | WMC8 | V     | Blue Chiller Con. Cutback     |
| 94     | 133          | T4A6 | A     | Red Tank High Fluid Temp.     |
| 95     | 134          | T4B5 | A     | Blue Tank High Fluid Temp.    |
| 96     | 135          | T4A3 | A     | Red Inline High Fluid Temp.   |
| 97     | 136          | T4B1 | A     | Blue Inline High Fluid Temp.  |
| 98     | 137          | T4A2 | A     | Red Hose High Fluid Temp.     |
| 99     | 138          | T4B4 | A     | Blue Hose High Fluid Temp.    |
| 100    | 139          | T4A7 | D     | Red Chiller High Fluid Temp.  |
| 101    | 140          | T4B8 | D     | Blue Chiller High Fluid Temp. |
| 102    | 141          | WMA6 | A     | Red Blanket High Temp.        |
| 103    | 142          | WMB5 | A     | Blue Blanket High Temp.       |
| 104    | 143          | T1A6 | D     | Red Tank Low Fluid Temp.      |
| 105    | 144          | T1B5 | D     | Blue Tank Low Fluid Temp.     |
| 106    | 145          | T1A3 | D     | Red Inline Low Fluid Temp     |
| 107    | 146          | T1B1 | D     | Blue Inline Low Fluid Temp.   |

| Item # | Error Number | Code | Level | Description                     |
|--------|--------------|------|-------|---------------------------------|
| 108    | 147          | T1A2 | D     | Red Hose Low Fluid Temp.        |
| 109    | 148          | T1B4 | D     | Blue Hose Low Fluid Temp.       |
| 110    | 149          | T1A7 | D     | Red Chiller Low Fluid Temp.     |
| 111    | 150          | T1B8 | D     | Blue Chiller Low Fluid Temp.    |
| 112    | 151          | T3AE | D     | Red Tank High Fluid Temp.       |
| 113    | 152          | T3BD | D     | Blue Tank High Fluid Temp.      |
| 114    | 153          | T3AA | D     | Red Hose High Fluid Temp.       |
| 115    | 154          | T3BC | D     | Blue Hose High Fluid Temp.      |
| 116    | 155          | T3AF | D     | Red Chiller High Fluid Temp.    |
| 117    | 156          | T3BG | D     | Blue Chiller High Fluid Temp.   |
| 118    | 157          | T2AE | D     | Red Tank Low Fluid Temp.        |
| 119    | 158          | T2BD | D     | Blue Tank Low Fluid Temp.       |
| 120    | 159          | T2AA | D     | Red Hose Low Fluid Temp.        |
| 121    | 160          | T2BC | D     | Blue Hose Low Fluid Temp.       |
| 122    | 161          | T2AF | D     | Red Chiller Low Fluid Temp.     |
| 123    | 162          | T2BG | D     | Blue Chiller Low Fluid Temp.    |
| 124    | 163          | T30X | V     | Dispensing Disabled: High Temp. |
| 125    | 164          | T20X | V     | Dispensing Disabled: Low Temp.  |
| 126    | 165          | T8A6 | D     | No Heat Red Tank                |
| 127    | 166          | T8B5 | D     | No Heat Blue Tank               |
| 128    | 167          | T8A3 | D     | No Heat Red Inline              |
| 129    | 168          | T8B1 | D     | No Heat Blue Inline             |
| 130    | 169          | T8A2 | D     | No Heat Red Hose                |
| 131    | 170          | T8B4 | D     | No Heat Blue Hose               |
| 132    | 171          | T8A7 | D     | No Cooling Red Chiller          |

| Item # | Error Number | Code | Level | Description                                  |
|--------|--------------|------|-------|--|
| 133    | 172          | T8B8 | D     | No Cooling Blue Chiller                      |
| 134    | 173          | T6A6 | A     | Red Tank RTD Fault                           |
| 135    | 174          | T6B5 | A     | Blue Tank RTD Fault                          |
| 136    | 175          | T6A3 | A     | Red Inline RTD Fault                         |
| 137    | 176          | T6B1 | A     | Blue Inline RTD Fault                        |
| 138    | 177          | T6A2 | A     | Red Hose FTS Fault                           |
| 139    | 178          | T6B4 | A     | Blue Hose FTS Fault                          |
| 140    | 179          | T6A7 | A     | Red Chiller RTD Fault                        |
| 141    | 180          | T6B8 | A     | Blue Chiller RTD Fault                       |
| 142    | 181          | T6C6 | A     | Red Blanket RTD Fault                        |
| 143    | 182          | T6C5 | A     | Blue Blanket RTD Fault                       |
| 144    | 183          | T6C7 | A     | Red Tank Monitor RTD Fault                   |
| 145    | 184          | T6C8 | A     | Blue Tank Monitor RTD Fault                  |
| 146    | 185          | WM06 | A     | Red Tank Con. Fault (High Relay Curr., or I) |
| 147    | 186          | WM05 | A     | Blue Tank Con. Fault (High Relay Curr.)      |
| 148    | 187          | WM03 | A     | Red Inline Con. Fault (High Relay Curr.)     |
| 149    | 188          | WM01 | A     | Blue Inline Con. Fault (High Relay Curr.)    |
| 150    | 189          | WM02 | A     | Red Hose Con. Fault (High Relay Curr.)       |
| 151    | 190          | WM04 | A     | Blue Hose Con. Fault (High Relay Curr.)      |
| 152    | 191          | WM07 | A     | Red Chiller Con. Fault (High Relay Curr.)    |
| 153    | 192          | WM08 | A     | Blue Chiller Con. Fault (High Relay Curr.)   |
| 154    | 193          | WMC6 | A     | Red Tank Con. Fault (Unexpected Relay I)     |
| 155    | 194          | WMC5 | A     | Blue Tank Con. Fault (Unexpected Relay I)    |
| 156    | 195          | WMC3 | A     | Red Inline Con. Fault (Unexpected Relay I)   |
| 157    | 196          | WMC1 | A     | Blue Inline Con. Fault (Unexpected Relay I)  |

| Item # | Error Number | Code | Level | Description                                  |
|--------|--------------|------|-------|--|
| 158    | 197          | WMC2 | A     | Red Hose Con. Fault (Unexpected Relay I)     |
| 159    | 198          | WMC4 | A     | Blue Hose Con. Fault (Unexpected Relay I)    |
| 160    | 199          | WMC7 | A     | Red Chiller Con. Fault (Unexpected Relay I)  |
| 161    | 200          | WMC8 | A     | Blue Chiller Con. Fault (Unexpected Relay I) |
| 162    | 201          | P4H3 | A     | High Accumulator Pressure                    |
| 163    | 202          | P1H3 | A     | Low Accumulator Pressure                     |
| 164    | 203          | T4H3 | A     | High Mix Head Oil Temp.                      |
| 165    | 204          | MBH3 | A     | Low Mix Head Oil Level                       |
| 166    | 205          | DEH3 | A     | Soft Stop Asserted                           |
| 167    | 206          | A4H3 | A     | Mix Head Motor Overload                      |
| 168    | 207          | WDF3 | A     | M1 Material Extend Fault                     |
| 169    | 208          | WDD3 | A     | M1 Cleanout Extend Fault (Cleanout Rod)      |
| 170    | 211          | L111 | D     | Red Low Material Level                       |
| 171    | 212          | L122 | D     | Blue Low Material Level                      |
| 172    | 213          | L311 | D     | Red High Material Level                      |
| 173    | 214          | L322 | D     | Blue High Material Level                     |
| 174    | 215          | L6A1 | D     | Red Auto Refill Timeout                      |
| 175    | 216          | L6B2 | D     | Blue Auto Refill Timeout                     |
| 176    | 217          | L8A1 | D     | Red Fill Sensor Fault                        |
| 177    | 218          | L8B2 | D     | Blue Fill Sensor Fault                       |
| 178    | 220          | MMUX | V     | USB: Logs Full                               |
| 179    | 221          | R4D0 | A     | High Ratio                                   |
| 180    | 222          | R3D0 | D     | High Ratio                                   |
| 181    | 223          | R1D0 | A     | Low Ratio                                    |
| 182    | 224          | R2D0 | D     | Low Ratio                                    |
| 183    | 225          | F4A0 | A     | High Flow Red                                |



| Item # | Error Number | Code | Level | Description               |
|--------|--------------|------|-------|---------------------------|
| 184    | 226          | F3A0 | D     | High Flow Red             |
| 185    | 227          | F4B0 | A     | High Flow Blue            |
| 186    | 228          | F3B0 | D     | High Flow Blue            |
| 187    | 229          | F1A0 | A     | Low Flow Red              |
| 188    | 230          | F2A0 | D     | Low Flow Red              |
| 189    | 231          | F1B0 | A     | Low Flow Blue             |
| 190    | 232          | F2B0 | D     | Low Flow Blue             |
| 191    | 233          | N1D0 | A     | Low Dispense Amount       |
| 192    | 234          | N4D0 | A     | High Dispense Amount      |
| 193    | 235          | N2D0 | D     | Low Dispense Amount       |
| 194    | 236          | N3D0 | D     | High Dispense Amount      |
| 195    | 238          | CAC2 | A     | Comm. Error Blue MCM      |
| 196    | 239          | CAC3 | A     | Comm. Error Red Tank      |
| 197    | 240          | CAC4 | A     | Comm. Error Blue Tank     |
| 198    | 241          | CAC5 | A     | Comm. Error Mix Head      |
| 199    | 243          | CAC7 | A     | Comm. Error Ratio Monitor |
| 200    | 244          | CAA6 | A     | Comm. Error Red Blanket   |
| 201    | 245          | CAB5 | A     | Comm. Error Blue Blanket  |
| 202    | 246          | CAA3 | A     | Comm. Error Red Inline    |
| 203    | 247          | CAB1 | A     | Comm. Error Blue Inline   |
| 204    | 248          | CAA2 | A     | Comm. Error Red Hose      |
| 205    | 249          | CA84 | A     | Comm. Error Blue Hose     |
| 206    | 250          | CAA7 | A     | Comm. Error Red Chiller   |
| 207    | 251          | CAB8 | A     | Comm. Error Blue Chiller  |
| 208    | 252          | CACN | A     | Comm. Error Field Bus     |

| Item # | Error Number | Code | Level | Description                        |
|--------|--------------|------|-------|------------------------------------|
| 209    | 253          | CUCN | A     | Field Bus Heartbeat Failure        |
| 210    | 254          | CACP | A     | Comm. Error Discrete I/O           |
| 211    | 255          | CACR | A     | Comm. Error Pendant                |
| 212    | 260          | W0U0 | A     | USB Update Failed                  |
| 213    | 262          | DR6B | D     | Check Flowmeter Blue               |
| 214    | 263          | DR6A | D     | Check Flowmeter Red                |
| 215    | 265          | L9AX | D     | Red Tank Leak Detected             |
| 216    | 266          | L9BX | D     | Blue Tank Leak Detected            |
| 217    | 267          | L9A0 | A     | Prepoly Refresh Time Expired       |
| 218    | 268          | P3RX | D     | High Recirculation Pressure        |
| 219    | 269          | T8CX | V     | Heater(s) are OFF                  |
| 220    | 270          | CAC9 | A     | Comm. Error Sm. Dispense           |
| 221    | 271          | P6F1 | D     | Red Inlet Pressure Sensor Fault    |
| 222    | 272          | P6F2 | D     | Blue Inlet Pressure Sensor Fault   |
| 223    | 273          | P2F1 | D     | Low Red Pump Input Pressure        |
| 224    | 274          | P2F2 | D     | Low Blue Pump Input Pressure       |
| 225    | 275          | P3F1 | D     | High Red Pump Input Pressure       |
| 226    | 276          | P3F2 | D     | High Blue Pump Input Pressure      |
| 227    | 277          | WMCX | V     | Questionable Shot Recipe Detected  |
| 228    | 278          | WBD1 | D     | Mixer motor fault                  |
| 229    | 279          | CAD1 | A     | Comm. Error Mixer                  |
| 230    | 280          | P9H1 | V     | Accumulator Charges too Frequently |
| 231    | 281          | P6H1 | A     | Power Pack Pressure Sensor Fault   |

# Technical Data


| HFR for NVH Foam  |  |                                    |
|---|--|------------------------------------|
|   | US   | Metric                             |
| Maximum fluid working pressure  | 2000 psi   | 14 MPa, 138 bar                    |
| Maximum Fluid Temperature   | 180°F  | 82°C                               |
| Fluid Inlet Feed Pressure Range   | 50 psi to 100 psi  | 345 kPa, 3.4 bar to 0.7 MPa, 7 bar |
| Fluid Inlet:<br><i>Component A (Red)</i>  | 1/2 npt(f)   |                                    |
| Fluid Inlet:<br><i>Component B (Blue)</i>   | 3/4 npt(f)   |                                    |
| Fluid Outlet:<br><i>Component A (Red)</i>   | #8 (1/2 in.) JIC (3/4-16 unf), with #5 (5/16 in.) JIC adapter  |                                    |
| Fluid Outlet:<br><i>Component B (Blue)</i>  | #10 (5/8 in.) JIC (7/8-14 unf), with #6 (3/8 in.) JIC adapter  |                                    |
| Fluid Circulation Ports   | 1/4 npsm(m), with plastic tubing, 250 psi (1.75 MPa, 17.5 bar) maximum   |                                    |
| Line Voltage Requirement:<br><i>230V / 3 phase Models</i>   | 195-264V, 50/60 Hz   |                                    |
| Line Voltage Requirement:<br><i>400V / 3 phase Models</i>   | 360-440V, 50/60 Hz<br>See <b>400 V Power Requirements</b> on page 5  |                                    |
| Amperage Requirement  | See <b>Models</b> on page 4  |                                    |
| Sound Power   | 93 dB  |                                    |
| Heater Power<br>(A (Red) and B (Blue) heaters total, no hose)   | 10 kW full load<br>(12 kW for 1:1 Models Only)   |                                    |
| Hydraulic reservoir capacity  | 9 gal. (34 liters)   |                                    |
| Recommended hydraulic fluid   | Citgo A/W Hydraulic Oil, ISO Grade 46  |                                    |
| Weight:<br><i>Units with 10 kW Heaters</i>  | 868 lb (394 kg)  |                                    |
| Wetted Part   | Aluminum, stainless steel, zinc-plated carbon steel, brass, carbide, chrome, fluoroelastomer, PTFE, ultra-high molecular weight polyethylene, chemically resistant o-rings |                                    |
| <i>All other brand names or marks are used for identification purposes and are trademarks of their respective owners.</i> |  |                                    |

## Motor Control Module Technical Data

| Motor Control Module   |  |        |
|--|--|--------|
|  | US   | Metric |
| Input Specifications:  |  |        |
| Input Line Voltage   | 0-264 Vac, line-to-line                      |        |
| Input Line Phasing   | Single or Three Phase                        |        |
| Input Line Frequency   | 50/60 Hz                                     |        |
| Input Current per Phase  | 25A (three-phase), 50A (single-phase)        |        |
| Maximum Branch Circuit Protection Rating   | 30A (three-phase), 63A (single-phase)        |        |
| Short Circuit Current Rating   | 5 kA   |        |
| Output Specifications:   |  |        |
| Output Line Voltage  | 0-264 Vac                                    |        |
| Output Line Phasing  | Three Phase                                  |        |
| Output Current   | 0-30A  |        |
| Output Overload  | 200% for 0.2 seconds                         |        |
| DC Power Supply  | 24 Vdc, Class 2, Graco-provided power supply |        |
| Enclosure  | Type 1                                       |        |
| Max Ambient Temperature  | 50°C (122°F)                                 |        |
| <p><i>Overtemperature protection is provided to protect from motor overload.</i></p> <p><i>Current limit, set via the software, is provided as a secondary protection from motor overload.</i></p> <p><i>All installations and wiring must comply with NEC and local electrical codes.</i></p> |  |        |



## Dimensions



| Dimensions |                 |
|------------|-----------------|
| A (Height) | 76 in. (193 cm) |
| B (Width)  | 72 in. (183 cm) |
| C (Length) | 58 in. (147 cm) |

## California Proposition 65

### CALIFORNIA RESIDENTS

**⚠ WARNING:** Cancer and reproductive harm – [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov).

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

## Graco Information

For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

**TO PLACE AN ORDER**, contact your Graco distributor or call to identify the nearest distributor.

**Toll Free Phone Number:** 1-800-328-0211

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A2797

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**

**Copyright 2012, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)

Revision ZAC, February 2025