

E-Flo[®] SP Software

3A6724D

EN

*For use with E-Flo SP electric pumps for sealants and adhesives.
For professional use only.*

Not approved for use in explosive atmospheres or hazardous locations.



Important Safety Instructions

Read all warnings and instructions in this manual and in all related manuals before using the equipment. Save all instructions.

Contents

Related Manuals 2

Warnings	3
Advanced Display Module (ADM)	6
ADM Keys and Indicators	6
ADM Component Identification	7
ADM LED Status Descriptions	7
ADM Display Details	8
ADM Icons	10
ADM Soft Keys	11
Run Screens	12
Setup Screens	23
Pump and Driver Settings	33
Pump Setup Screen 1	33
Pump Setup Screen 2	34
Pump Setup Screen 3	34
Pump Setup Screen 6 (Ram and Tandem Systems Only)	34
Advanced Setup Screen 1	35
Advanced Setup Screen 2	35
Advanced Setup Screen 3	35
Advanced Setup Screen 4	35
System Setup Screen	35
Connect Light Tower Accessory	35
Pump Load Sharing	36
Troubleshooting	37
Error Codes and Troubleshooting	37
Errors	37
Troubleshoot Errors	38
Troubleshoot Error Codes	39
USB Data	48
Download Procedure	48
USB Logs	48
Event Log	48
PumpX Log	49
Cycles Log	49
HeatX log	49
System Configuration Settings	49
Custom Language File	49
Create Custom Language Strings	50
Upload Procedure	50

Communications Gateway Module (CGM)	51
Connection Details	51
Overview	54
E-Flo SP and PLC Connection Setup	54
Available Internal Data	54
Gateway Map: 2008382 for 6 Booster/6Ram/1Tandem	54
Gateway Map: 2008020 for 1 Heated ram/1Tandem	57
Heat Data Exchange	62
Timing Diagrams	64
Error Code Handling	76
Active Alarm Descriptions	77
Active Deviation Descriptions	79
Active Advisories Descriptions	80
AMZ MLZP Board Active Module Alarms	80
AMZ MLZP Board Active Module Deviation ...	81
AMZ MLZP Board Active Module Advisories ..	81
I/O Daughter Board Active Module Alarms ...	81
I/O Daughter Board Active Module Deviation ..	82
I/O Daughter Board Active Module Advisories ..	83
AMZ Active Zone #Z Alarms	83
AMZ Active Zone #Z Deviation	84
I/O Daughter Board Active Module Advisories ..	84
Setup	85
I/O Integration	88
Appendix A - Obsolete E-Flo SP Maps	90
E-Flo SP and PLC Connection Setup	90
California Proposition 65	93
Graco Standard Warranty	94



Related Manuals









Related manuals in English:

Manual	Description
3A6586	E-Flo SP Electric Booster Pumps
3A6331	E-Flo SP Supply Systems Ram/Tandem
3A6321	ADM Token In-System Programming
3A1244	Graco Control Architecture Module
3A6482	APD20 Advanced Precision Driver

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 DANGER	
	<p>SEVERE ELECTRIC SHOCK HAZARD</p> <p>This equipment can be powered by more than 240 V. Contact with this voltage will cause death or serious injury.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment. • This equipment must be grounded. Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.

 WARNING	
    	<p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not point dispensing device at anyone or at any part of the body. • Do not put your hand over the fluid outlet. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow the Pressure Relief Procedure in your system manual when you stop dispensing and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses and couplings daily. Replace worn or damaged parts immediately.
 	<p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure in your system manual and disconnect all power sources.



WARNING



FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:



- Use equipment only in well-ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking).
- Ground all equipment in the work area. See **Grounding** instructions in your system manual.
- Never spray or flush solvent at high pressure.
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are anti-static or conductive.
- **Stop operation immediately** if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.



EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.



- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Specifications** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Specifications** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheets (SDSs) from distributor or retailer.
- Turn off all equipment and follow the **Pressure Relief Procedure** in your system manual when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
- Make sure all equipment is rated and approved for the environment in which you are using it.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.



SPLATTER HAZARD

Hot or toxic fluid can cause serious injury if splashed in the eyes or on skin. During blow off of platen, splatter may occur.

- Use minimum air pressure when removing platen from drum.

WARNING



TOXIC FLUID OR FUMES HAZARD

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read Safety Data Sheets (SDSs) to know the specific hazards of the fluids you are using.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.



PERSONAL PROTECTIVE EQUIPMENT

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. Protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

Advanced Display Module (ADM)










The ADM display shows graphical and text information related to setup operations.


NOTICE

To prevent damage to the buttons, do not press buttons with sharp objects such as pens, plastic cards, or fingernails.

ADM Keys and Indicators


Cause	Solution
 Startup/Shutdown Key and Indicator	Press to startup or shutdown the system.
 Stop	Press to stop all pump and/or heat processes. This is not a safety or emergency stop.
 Soft Keys	Press to select the specific screen or operation shown on the display directly next to each key.
 Navigation Keys	<ul style="list-style-type: none"> • Left/Right Arrows: Use to move from screen to screen. • Up/Down Arrows: Use to move among fields on a screen, items on a drop-down menu, or multiple screens within a function.
Numeric Keypad	Use to input values.
 Cancel	Use to cancel a data entry field.
 Setup	Press to enter or exit Setup mode.
 Enter	Press to choose a field to update, to make a selection, to save a selection or value, to enter a screen, or to acknowledge an event.

ADM Component Identification



Ref.	Description
CJ	Flat Panel Mount (VESA 100)
CK	Model and Serial Number
CL	USB Port and Status LEDs
CM	CAN Cable Connection
CN	Module Status LEDs
CP	Accessory Cable Connection
CR	Token Access Cover
CS	Battery Access Cover

ADM LED Status Descriptions

LED	Conditions	Description
System Status 	Green Solid	Run Mode, System On
	Green Flashing	Setup Mode, System On
	Yellow Solid	Run Mode, System Off
	Yellow Flashing	Setup Mode, System Off
USB Status (CL)	Green Flashing	Data recording in progress
	Yellow Solid	Downloading information to USB
	Green and Yellow Flashing	ADM is busy, USB cannot transfer information when in this mode
ADM Status (CN)	Green Solid	Power applied to module
	Yellow Flashing	Active Communication
	Red Steady Flashing	Software upload from token in progress
	Red Random Flashing or Solid	Module error exists

ADM Display Details

Power Up Screen

The following screen appears when the ADM is powered up. It remains on while the ADM runs through initialization and establishes communication with other modules in the system.



Menu Bar

The menu bar appears at the top of each screen (the following image is only an example).



Date and Time

The date and time are always displayed in one of the following formats. The time is always displayed as a 24-hour clock.

- DD/MM/YY HH:MM
- YY/MM/DD HH:MM
- MM/DD/YY HH:MM

Arrows

The left and right arrows are only visible when screen navigation is allowed.

Screen Menu

The screen menu indicates the currently active screen, which is highlighted. It also indicates the associated screens that are available by scrolling left and right.

System Mode

The current system mode is displayed at the lower left of the menu bar.

Status

The current system status is displayed at the lower right of the menu bar.

Alarm/Deviation

The current system error is displayed in the middle of the menu bar. There are four possibilities.

Icon	Function
No Icon	No information or no error has occurred
	Advisory
	Deviation
	Alarm

Soft Keys

Icons next to the soft keys indicate which mode or action is associated with each soft key. Soft keys that do not have an icon next to them are not active in the current screen.


NOTICE
To prevent damage to the soft key buttons, do not press buttons with sharp objects such as pens, plastic cards, or fingernails.


Navigating the Screens


There are two sets of screens:

The Run screens control operations and display system status and data.

The Setup screens control system parameters and advanced features.

Press  on any Run screen to enter the Setup screens. If the system has a password lock, the Password screen displays. If the system is not locked (password is set to 0000), Pump 1 Setup Screen displays.

Press  on any Setup screen to return to the Run screen.


Press the Enter soft key  to activate the editing function on any screen.

Press the Exit soft key  to exit any screen.


















Use the other soft keys to select the function adjacent to them.








Set Password



Set a password to allow Setup screen access (see **Advanced Setup Screen 1 – Standard ADM Settings** on page 31). Enter any number from 0001 to 9999. To remove the password, enter the current password when prompted and change the password to 0000 in Advanced Setup Screen 1.












ADM Icons










Icon	Function
	Alarm - See Troubleshooting , page 37 for more information.
	Deviation - See Troubleshooting , page 37 for more information.
	Advisory - See Troubleshooting , page 37 for more information.
	Pressure or Pressure Mode
	Flow Rate or Flow Mode
	Target (either pressure or flow)
	<p>Pump status - Indicates whether or not an error is active on this pump and the pump status. The three dots above the driver represent increasing levels of readiness and activity. From left to right:</p> <ul style="list-style-type: none">  Pump enabled/disabled (green if enabled, amber if disabled)  Pump enabled, off, and not moving  Pump enabled and commanded to drive, but pump is not moving (stalled)  Pump enabled, commanded to drive and moving
	Drum level sensors are not activated
	Drum low sensor activated
	Drum empty sensor activated
	Inlet (bottom) and Outlet (top) Pressure Transducers
	Pump Diving
	Fluid Filter















Icon	Function
	Communication Error
	No issues found with parameter or setting value
	Missing or unexpected parameter or setting value
	System is processing request (animated)
	Pump position (animated). The pump coupler will move up and down in real time and indicate the approximate position of the pump. The pump will need to complete one full down stroke upon each power cycle before the position is valid.
	<p>Pressure-Flow Graph</p> <p>Dynamic graph representing the actual pressure, actual flow rate, pressure limit, and flow rate limit.</p> <p>The red line represents the pressure setpoint or limit. The blue line represents the flow rate setpoint or limit.</p> <p>When trending is disabled, a single magenta dot represents the current pressure and flow rate.</p> <p>When trending is enabled, older pressure flow data is kept on the screen and will slowly fade away over the period of about 30 seconds.</p>
	<p><i>Tandem system only:</i></p> <p>Denotes which pump is active.</p>

Icon	Function
	<i>Tandem system only:</i> Drum low/empty sensor indicators. If drum low and or empty sensors are installed, these indicators will appear next to each pump. The top circle represents drum low and the bottom circle represents drum empty. When green, the sensor is not activated (fluid level high). When red, the sensor is activated (fluid level low).
	Dynamic Setpoint Mode. See Pump Setup Screen 6 – Drum Settings , Step 8 for more details. Page 26.



ADM Soft Keys






Icon	Function
Pump Operation Icon	
	<i>Green:</i> Start Pump
	<i>Inverted Green:</i> Stop Pump
	<i>Red with Border (enabled):</i> Indicates that pump cannot be started due to alarm.
	<i>Red with No Border (not enabled):</i> Indicates that system is not enabled and pump cannot be started.
	<i>Yellow:</i> Indicates that pump has an active alarm due to not being primed. Pump can be enabled via prime mode only.
	Local / Remote control toggle
	Pump is locked in remote control via fieldbus interface.
	Enable or disable pressure control (limiting) mode
	Enable or disable flow control (limiting) mode






Icon	Function
	<i>Ram and Tandem systems only</i> Enter or exit pump priming mode. An “1” or “2” will be present in Tandem systems to indicate which pump will be primed.
	<i>Ram and Tandem systems only (if equipped with optional fluid solenoid)</i> Enter or exit drum recirculation mode.
	<i>Ram and Tandem systems only (if equipped with optional fluid solenoid)</i> Enter or exit depressurization mode.
	<i>Tandem systems only</i> View and toggle the active pump.
	Enable or disable trending on the pressure / flow graph.
	Move to the top
	Move upward
	Move downward
	Move to the bottom










Icon	Function
	Search
	Troubleshoot selected error
	Previous screen
	Continue
	Calibrate
	Enter or exit manual pump movement mode.
	Reset Cycle Counter
	Toggle between lifetime and resettable
	Enter or exit edit mode for a particular screen
	Globalize selection. Apply a heat setting to all of the heat zones in Heat Settings.
	Confirm globalizing a setting.
	Cancel globalizing a setting.
	Turn heat zones on and off.
	Place all heat zones into setback and out of setback.


Run Screens






Screen	Description									
 <p>02/08/19 12:05 Troubleshooting Home Pump 1</p> <p>Pumps Active No Active Errors</p> <table border="1"> <tr> <td>psi</td> <td>0</td> <td>0</td> </tr> <tr> <td>CPM</td> <td>0.0</td> <td>0.0</td> </tr> <tr> <td>cc</td> <td>290</td> <td>145</td> </tr> </table>	psi	0	0	CPM	0.0	0.0	cc	290	145	<p>Home Screen 1 (if more than one pump is installed in booster or ram type systems)</p> <p>The status of each pump is visible along with the maximum allowable pressure, pump cycle rate, and pump lower size. If multiple pumps are installed, the system setup screen must list the correct number of pumps as “installed”.</p>
psi	0	0								
CPM	0.0	0.0								
cc	290	145								
 <p>02/08/19 12:06 Troubleshooting Home Pump 1</p> <p>Pumps Active No Active Errors</p> <p>17 psi 0</p> <p>33 psi 0</p>	<p>Home Screen 2 (if more than one pump is installed in booster or ram type systems)</p> <p>The current pressures and flow rates are visible for each pump. Pressure and flow rate units can be selected in the advanced setup screen 2.</p>									





Screen	Description
	<h3>Pump 1 Run Screen (booster)</h3> <p>Home screen for a single pump system. The booster system option can be selected on the system setup screen.</p> <p>A “Pump X” screen will be present for each pump that is installed.</p> <p>When this soft key  is displayed, the pump can be controlled locally through the display. When this soft key  is displayed the pump is controlled through discrete I/O or fieldbus protocols.</p> <p>Information Displayed:</p> <p>A dynamic graph of target and actual performance for pump outlet pressure and flow. Target pressure and flow are represented by red and blue lines respectively. The actual outlet pressure and flow is shown by the magenta dot.</p> <p>The points will be updated at all times when running, stalled, active, inactive, etc.</p> <p>Trending icon . When not enabled, only the current pressure and flow targets are shown along with the current operating point. When enabled, one can see where the pump has been operating over time.</p> <p>Max pressure achievable with the selected pump is shown at the top of the vertical axis. The minimum pressure is zero.</p> <p>Outlet Pressure target is shown next to the target icon on the vertical axis. It is restricted to values below the max achievable pressure. Pressure is displayed in psi, bar, or MPa. Select options in advanced setup screen 2.</p> <p>Actual outlet pressure is shown below the pressure icon and can be displayed in the same units described under the target pressure.</p> <p>Max flow rate achievable with the selected pump is shown at the end of the horizontal axis. The minimum flow is zero.</p> <p>Outlet flow rate target is shown next to the target icon on the horizontal axis. It is restricted to values below the max achievable flow. Flow rate can be displayed in cc, gal(US), gal(UK), oz(US), oz(UK), Liters, or cycles per minute or second. These options can be selected in the advanced setup screen 2.</p> <p>Actual outlet flow rate is shown below the flow rate icon, and can be displayed in the same units described under the flow rate target. All flow rates are calculated from the specified pump size and assume 100% volume efficiency.</p> <p>Pump Size is shown below the pressure target in cc.</p> <p>Inlet pressure is shown below the pump size in the same units as the outlet pressure. Pressure is only displayed if the inlet pressure sensor is installed (otherwise, it will display as 0).</p> <p>Cycle Rate is shown below the inlet pressure in CPM (cycles per minute).</p> <p>Pump operation icon . See ADM Soft Keys on page 11 for a description of this icon.</p> <p>Approximate position of pump / driver rod: The pump coupler moves up and down on the screen as the actual pump coupler does in the physical system based on driver rod position. This can be used to determine whether the pump is moving or stalled.</p> <p>Status of pump / driver is shown above the animated pump / driver icon and is depicted with three dots. The three dots represent increasing levels of readiness / activity from left to right. See the Icons section for description of the status lights.</p> <p>An alarm, deviation, or advisory bell will be shown above the driver if such an event is active. See Icons section.</p>




























Screen	Description
	<h3>Pump 1 Run Screen in Edit Mode (Booster)</h3> <p>This screen is used to set the desired pressure and flow rates and enable/disable the pump.</p> <p>The pressure and flow rate targets are set using the numeric entry boxes. Use the arrow keys to navigate between pressure and flow rate targets. Pressure and/or Flow mode are selected using soft keys on the right edge of the screen. In pressure mode , the maximum flow rate for a given pressure will be maintained. In flow mode , the maximum pressure for a given flow rate will be maintained. In pressure and flow mode (both soft keys selected), the pressure and flow can be set as desired.</p> <p>NOTE: The restriction of the down stream fluid system determines the achievable levels of pressure and flow rate.</p> <p>In this example, the pump is in pressure and flow control modes with targets of 1200 psi and 1500 cc/min.</p>
	<h3>Pump 1 Run Screen (Booster) – Pump On</h3> <p>When the pump operation icon  is selected, the pump is commanded to run and there are no active errors. Press the upper right soft key to turn off the pump.</p> <p>Trending is enabled.</p> <p>The magenta dot is continuously placed on the screen, but fades over time.</p> <p>The coupling connecting the driver and pump rods will move up and down on the animation to represent the physical position of the coupling.</p>




Screen	Description
 <p>02/08/19 12:07 Home Pump 1 Pump 2 Events </p> <p>Pumps Active No Active Errors</p> <p>2610</p> <p>40 psi 1200 290 cc 0 psi 6.0 CPM</p> <p>151.3 Liters</p> <p>0 cc/min 1500</p> <p>6980</p>	<h3>Pump 1 Run Screen (Ram)</h3> <p>See Pump 1 Run Screen (Booster) section for previously described information available on this screen. The ram system option can be selected on the system setup screen.</p> <p>The  soft key on the right can be pressed to enter or exit depressurization mode. This option is only available when a fluid solenoid is installed. Selecting the button in the state shown would enter depressurization mode.</p> <p>The  soft key on the right can be pressed to enter or exit drum recirculation mode. This option is only available when a fluid solenoid is installed. Selecting the button in the state shown would enter recirculation mode.</p> <p>The  soft key on the right can be pressed to enter or exit priming mode. Selecting the button in the state shown would enter priming mode.</p> <p>The drum animation  alerts you when the drum is low or empty if the respective fluid level sensors are installed. The remaining volume in the drum, shown to the right of the drum, is an estimated quantity and not guaranteed to be correct. This is a rough estimate that can be used predict about when the drums should be changed out. See the Icons section for a description of the drum animation.</p> <p>Dynamic setpoint mode percentage  is shown above the actual out flow rate. This setting is only shown when enabled in Pump Setup Screen 6 – Drum Settings. NOTE: by enabling the Dynamic Setpoint Mode, you lose the depressurization and recirculation opinions.</p>
 <p>08/12/24 10:26 Pump 1 Heat 1 </p> <p>Pumps Active No Active Errors</p> <p>190.0</p> <p>6.5 bar 0.0 220 cc 0.0</p> <p>0.0 CPM</p> <p>199821 cc</p> <p>25 %   5300</p> <p>0 cc/min 0</p>	<h3>Pump 1 Run Screen in Edit Mode (Ram)</h3> <p>This screen is similar to the Pump 1 Run Screen in Edit Mode (Booster) except the drum icon and dynamic setpoint mode percentage as described in the Pump 1 Run Screen (ram) section are included.</p>





Screen	Description
	<p>Pump 1 Run Screen (Ram) – Pump On</p> <p>This screen is similar to the Pump 1 Run Screen (Booster) – Pump On except the drum icon and dynamic setpoint mode percentage as described in the Pump 1 Run Screen (ram) section are included.</p> <p>The depressurization, recirculation, and priming modes are inactive while the pump is on or the dynamic setpoint is enabled.</p>

Screen	Description
	<h3>Tandem Run Screen</h3> <p>See the Pump 1 Run Screen (Ram) section on page 16 section for previously described information available on this screen. The tandem system option can be selected on the system setup screen.</p> <p>In order for the tandem system to operate properly, two pumps must be installed and operational.</p> <p>The  soft key on the left is used to switch which pump is “active” (crossover). The 1 or 2 pump must be listed as the active pump before running. The green box around the 1 or 2 pump designations denotes the active pump. The active pump pressure and flow graph will be shown on the bottom half of the screen.</p> <p>The pump lower size, cycles per minute, and estimated remaining drum volume are shown for each pump.</p> <p>Status icons for alarms, deviations, and advisories will display next to the pump that generated the error. See ADM Icons on page 10 for description.</p> <p>Indicator lights can appear next to each pump to describe the state of the drum low or empty sensors. See the drum low/empty sensors section in the Icons table for more information. In this example, Pump 1 has the drum low and empty sensor option selected on Pump 1 setup screen 6, but they are not active (drum level high). Pump 2 does not have this option selected on the Pump 2 setup screen 6.</p> <p>NOTE: The drum low and empty sensors must be installed for this function to work properly. This option can be selected if they are not installed, but will not function correctly.</p> <p>The maximum allowable pressure and flow rates are not shown on the dynamic pressure and flow graph. The system will still limit entered pressure and flow rate values to their maximum.</p> <p>If a fluid filter is installed and the option is selected in the system setup screen,  will appear next to the pressure and flow graph as shown. The fluid pressure before and after the filter is shown above the icon. The higher pressure reading from connector 6 of either driver is assumed to be upstream of the filter and the lower pressure reading is assumed to be downstream. The difference between the two is shown below the icon and is only valid when both zones are powered up. See System Setup Screen – Tandem Systems, page 31, for setting the high and low filter pressure boundaries that will generate an advisory.</p> <p>Depressurization, recirculation, and priming modes can be entered for either Pump 1 or 2. Press the  soft key to switch between these options for Pump 1 or 2.</p> <p>A crossover cannot be completed while priming is active on either pump. Only one pump can be in priming mode at a time.</p> <p>NOTE: Pump priming can be initiated and controlled through the display even when the system is being controlled through automation.</p> <p>Dynamic setpoint mode percentage  is to the left the actual out flow rate. The setting is only shown when enabled in pump setup screen 6 - drum settings.</p> <p>NOTE: By enabling the dynamic setpoint mode, you loose the depressurization and recirculation options.</p>







Screen	Description
	<p>Tandem Run Screen in Edit Mode</p> <p>See Pump 1 Run Screen in Edit Mode (Ram) for previously described information available on this screen.</p> <p>The main difference from the ram screen is the  soft key can be pressed to crossover between pumps. The pressure and flow targets for each pump can be set on this screen. The entered values will be limited to their achievable maximums.</p> <p>The fluid filter is shown to the right of the pressure and flow graph if installed and selected in the system setup screen.</p>
	<p>Tandem Run Screen – Pump On</p> <p>See Pump 1 Run Screen (Ram) on page 16 for information available on this screen.</p> <p>Pressing the  soft key causes crossover between pumps.</p> <p>The system will automatically crossover while running if the active pump produces an alarm. A crossover error will occur if the inactive pump cannot be activated due to an alarm of its own.</p> <p>Depressurization and recirculation mode are not available while the pump is on, but the non-active pump can be primed while the active pump is running.</p> <p>The fluid filter is shown to the right of the pressure and flow graph if installed and selected in the system setup screen.</p>










Screen	Description																																		
	<h3 data-bbox="617 273 876 304">Heat Run Screen</h3> <p data-bbox="617 325 1299 357">This screen shows the temperature readouts for each heat zone.</p> <p data-bbox="617 367 1364 441">The  soft key on the left is pressed to turn heat zones on and off.</p> <p data-bbox="617 451 1388 556">The  soft key on the right is pressed to put the system into setback mode.</p> <p data-bbox="617 567 1437 630">The Zone Heat Symbols in the middle column correspond to the current type to which the zone is set.</p> <table border="1" data-bbox="868 646 1193 1018"> <thead> <tr> <th colspan="2">Zone Heat Symbol</th> </tr> </thead> <tbody> <tr> <td></td> <td>Hose</td> </tr> <tr> <td></td> <td>Valve</td> </tr> <tr> <td></td> <td>Manifold</td> </tr> <tr> <td></td> <td>PGM</td> </tr> <tr> <td></td> <td>Flowmeter</td> </tr> <tr> <td></td> <td>Press Regulator</td> </tr> <tr> <td>...</td> <td>Other</td> </tr> <tr> <td></td> <td>Pump</td> </tr> <tr> <td></td> <td>Platen</td> </tr> </tbody> </table> <p data-bbox="617 1060 1429 1155">The number to the right of the Zone Heat Symbol is the zone's actual temperature. The temperature unit is the same as the zone setpoint/setback temperature unit.</p> <p data-bbox="617 1176 1404 1239">The zone heat state is the circle next to the temperature unit. There are six different colors used in the indicators for the heat zone</p> <table border="1" data-bbox="722 1249 1307 1585"> <thead> <tr> <th colspan="2">Zone Current State Color Table</th> </tr> </thead> <tbody> <tr> <td>Green</td> <td>Heat Zone is at temperature.</td> </tr> <tr> <td>Yellow</td> <td>Heat Zone is in setback</td> </tr> <tr> <td>Yellow to Green</td> <td>Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero</td> </tr> <tr> <td>Green to Red</td> <td>Heat zone has a deviation/advisory.</td> </tr> <tr> <td>Red</td> <td>Heat zone has an alarm.</td> </tr> <tr> <td>White</td> <td>Heat zone is turned off.</td> </tr> </tbody> </table>	Zone Heat Symbol			Hose		Valve		Manifold		PGM		Flowmeter		Press Regulator	...	Other		Pump		Platen	Zone Current State Color Table		Green	Heat Zone is at temperature.	Yellow	Heat Zone is in setback	Yellow to Green	Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero	Green to Red	Heat zone has a deviation/advisory.	Red	Heat zone has an alarm.	White	Heat zone is turned off.
Zone Heat Symbol																																			
	Hose																																		
	Valve																																		
	Manifold																																		
	PGM																																		
	Flowmeter																																		
	Press Regulator																																		
...	Other																																		
	Pump																																		
	Platen																																		
Zone Current State Color Table																																			
Green	Heat Zone is at temperature.																																		
Yellow	Heat Zone is in setback																																		
Yellow to Green	Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero																																		
Green to Red	Heat zone has a deviation/advisory.																																		
Red	Heat zone has an alarm.																																		
White	Heat zone is turned off.																																		










Screen	Description
	<h3>Heat Run Screen in Edit Mode</h3> <p>This screen is accessible when the “Enabled Temp Adjustments” option is enabled in Advanced Setup Screen 3.</p> <p>This screen allows you to change the temperature setpoint/setback values while in the run screen.</p> <p>To change setpoint values put the system in normal heat operation and use the ADM keypad to enter values.</p> <p>To change setback values put the system in heat setback operation and use the ADM keypad to enter values.</p>
	<h3>Events Log Screen</h3> <p>This screen shows the date, time, event code, and description of all events that have occurred on the system. There are 20 pages, each holding 10 events. The 200 most recent events are shown.</p> <p>See Troubleshoot Errors page 38, for instructions on viewing event code descriptions.</p> <p>All events listed on this screen can be downloaded on a USB flash drive. To download logs, see the Download Procedure on page 48.</p>
	<h3>Errors Log Screen</h3> <p>This screen shows the date, time, error code, and description of all errors that have occurred on the system. The 200 most recent errors are shown.</p> <p>See Troubleshoot Errors page 38, for instructions on viewing event code descriptions.</p> <p>All errors listed on this screen can be downloaded on a USB flash drive. To download logs, see the Download Procedure on page 48.</p>





Screen	Description
	<h3>Troubleshooting Screen</h3> <p>This screen displays the last ten errors that occurred on the system. Use the up and down arrows to select an error and press  to view the QR code for the selected error. Press  to access the QR code screen for an error code that is not listed on this screen.</p> <p>See Troubleshoot Error Codes on page 39 for more information on error codes.</p>
	<h3>Troubleshooting Screen – QR Codes</h3> <p>To quickly view online help for a given error code, scan the displayed QR code with your smart phone. Alternately, to view online help, search for your error code by visiting: help.graco.com/e-flo-sp-system/</p> <p>See Troubleshoot Error Codes on page 39 for a list of errors and troubleshooting ideas.</p>







Setup Screens







Screen	Description
	<h2>Pump Setup Screen 1 – Pump Settings</h2> <p>NOTE: There is a pump tab for every installed pump in the system. The following errors can be configured and applied depending upon which mode the unit is operating. The errors will be triggered if the limit is exceeded for approximately 5 seconds. Press the  soft key to enter Edit mode prior to changing screens.</p> <p>Pressure Mode  : The specified error type (alarm [shutdown], deviation [warn], or none) will be triggered if the pressure is outside of the set-point pressure +/- tolerance range for approximately 5 seconds. For example: With a 5% tolerance, the pressure must be within 95 - 105% of the target pressure. If the pressure was outside of this range for 5 seconds or longer, an error could be triggered.</p> <p>Flow Mode  : The specified error type (alarm [shutdown], deviation [warn], or none) will be triggered if the flow rate is outside of the set-point flow +/- tolerance range for approximately 5 seconds. For example: With a 10% tolerance, the flow rate must be within 90 - 110% of the target flow rate. Tolerances have a range of 0 - 99% (0 disables the error). Tolerance is set to 0% and “None” by default.</p> <p>Pump Diving Sensitivity  : The specified error type (alarm [shutdown], deviation [warn], or none) will be triggered if pump diving is detected. The sensitivity value ranges from 0 – 99 with 99 being extremely sensitive to pump diving. Set the pump diving sensitivity lower if an unusual number of pump diving errors are generated.</p> <p>Pump Type: Select the pump lower type from the drop down menu options.</p> <p>Pump Volume: Enter the volume of the pump lower in cc.</p> <p>Pressure Transducer Type: Select this box if a flush-mount transducer is installed. If a standard issue pressure transducer is installed, leave this box unchecked.</p> <p>Pressure Transducer Offsets  : Allows for the inlet (bottom) and outlet (top) transducers to be zeroed out. In edit mode, the  soft key appears and automatically zeros out the readings +/- 145 psi (10 bar, 0.1 MPa) only. See step 5 of Pump Setup Screen 1 on page 33 for more detail on setting pressure transducer offsets.</p>

Screen	Description
	<p>Pump Setup Screen 2 – Maintenance and Pump Position</p> <p>This screen shows the number of cycles and maintenance limit for the driver and pump. An advisory event will notify the user/robot that maintenance is due when the number of cycles exceeds the limit. This could be used for tracking oil or gear life.</p> <p>For ram and tandem systems, the number of drum changes and limit is shown. An advisory event will notify the user/robot to change the platen seals when the number of cycles exceeds the limit.</p> <p>Setting the limit to zero disables the specific maintenance reminder.</p>
	<p>Pump Setup Screen 2 – Edit Mode</p> <p>Pressing the soft key next to the corresponding cycle reset counter  icon resets the cycle count for the driver, pump, and/or platen. Reset the counter after maintenance is completed.</p>
	<p>Pump Setup Screen 2 – Manual Pump Movement Mode</p> <p>The soft keys on the right move the driver rod. A “medium” force and relatively slow speed will be used, similar to what is used during the calibration sequence. Pressing the  soft key enters manual pump movement mode.</p> <p>Pressing and releasing the  soft key moves the driver rod to the top.</p> <p>Pressing and holding the  soft key moves the driver rod up. The driver rod will move up as long as the button is held.</p> <p>Pressing and holding the  soft key moves the driver rod down. The driver rod will move down as long as the button is held.</p> <p>Pressing and releasing the  soft key moves the driver rod all the way to the bottom.</p> <p>NOTE: The soft keys on the right are only available if the driver is calibrated and not already in use.</p>


Screen	Description
	<h3>Pump Setup Screen 3 – Driver Calibration and Usage Histogram</h3> <p>This screen shows the driver calibration status and the driver usage histogram.</p> <p>A  denotes the driver is calibrated and ready to operate. A  means the driver must be calibrated before operation. See Pump Setup Screen 3 – Driver Calibration on page 25 for instructions on driver calibration.</p> <p>The histogram shows the driver cycles in several bins of output force as a percentage of maximum force. This visualizes how hard the driver has been run in its lifetime. Cycles in bins toward the 100% end of the horizontal axis denote cycles that occurred when the output force of the driver was high.</p> <p>Pressing the  soft key switches between a histogram displaying the total lifetime cycles and the cycles since last reset. When in edit mode, pressing the  soft key on the right resets the histogram.</p>
	<h3>Pump Setup Screen 3 – Driver Calibration</h3> <p>When in edit mode, pressing the  soft key displays the driver calibration screen.</p> <p>Pressing the  soft key will begin driver calibration. See your driver manual for calibration instructions.</p>
	<h3>Pump Setup Screen 4 - Diagnostic</h3> <p>The diagnostic screen displays the values of key parameters that can be useful in troubleshooting issues.</p> <p>Pressure Set-point: Percentage of target driver thrust.</p> <p>Pressure Feedback: Percentage of actual driver thrust.</p> <p>Motor Temperature: This is the temperature of the motor. If this value is too high, it will generate an alarm and shut down the pump.</p> <p>IGBT Temperature: This is the temperature inside the driver casing on the control board. If this value is too high, it will generate an alarm and shut down the pump.</p> <p>Bus Voltage: This is the DC voltage of the driver bus</p>




Screen	Description
	<p>Pump Setup Screen 5 – Automation Inputs/Outputs</p> <p>This screen shows automation inputs/outputs.</p> <p>The robot outputs section shows the commands that can be sent by the robot. The  icon means the robot has not sent that specific command. The  icon means the robot has sent the command</p> <p>The robot inputs section shows the values that are being sent from the pump to the robot. This can be used for troubleshooting to identify what the robot is seeing.</p>
	<p>Pump Setup Screen 6 – Drum Settings</p> <p>Ram and tandem systems only.</p> <p>Must be in edit mode to change any of the settings.</p> <p>Not Primed Event: The specified error type (alarm [shutdown], deviation [warn], or none) is triggered when a drum is replaced and the pump has not yet been primed. If alarm is selected, the pump must be primed after replacing a drum before returning to normal operation.</p> <p>Prime Timer: Enter the length of the pump priming. Between 1 - 9 minutes.</p> <p>Low Sensor: Enables/disables the drum low deviation. The drum low level sensor must be installed to function properly.</p> <p>Empty Sensor: Enables/disables the drum empty alarm. The drum empty sensor must be installed to function properly.</p> <p>Smart Empty: Enables/disables the “smart” drum empty alarm. Incorporates multiple events to determine when the drum is empty to minimize material waste. The drum empty sensor must be installed to function properly. Pump diving sensitivity is critical to the Smart Empty function. If an empty drum is being detected early, decrease pump diving sensitivity. If empty drum detection is late, increase pump diving sensitivity.</p> <p>Fluid Solenoid: Enables/disables additional features that require a fluid solenoid. The fluid solenoid must be installed to function properly. This option disables dynamic setpoint mode as only one option can be installed.</p> <p>Drum Volume: Enter the average volume of material available in drums. This will provide an estimate to how much material is left in drums based on pump lower size and cycle rate (estimate shown on run screen).</p> <p>Dynamic Setpoint Mode: Enables/disables the dynamic setpoint option. This option disables Fluid Solenoid as only one can be installed.</p>




Screen	Description																																																												
 <table border="1" data-bbox="175 281 669 709"> <thead> <tr> <th>Zone</th> <th>Zone Type</th> <th>Setpoint (°C)</th> <th>Setback (°C)</th> <th>P1</th> <th>P2</th> </tr> </thead> <tbody> <tr><td>1-1:</td><td>Hose</td><td>25</td><td>20</td><td><input checked="" type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>1-2:</td><td>Valve</td><td>25</td><td>20</td><td><input checked="" type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>2-3:</td><td>Hose</td><td>25</td><td>20</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>2-4:</td><td>Manifold</td><td>25</td><td>20</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>3-5:</td><td>Hose</td><td>25</td><td>20</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>3-6:</td><td>Manifold</td><td>25</td><td>20</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>4-7:</td><td>Hose</td><td>25</td><td>20</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>4-8:</td><td>Pump</td><td>25</td><td>20</td><td><input checked="" type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr> <tr><td>5-9:</td><td>Platen - 20L</td><td>25</td><td>20</td><td><input checked="" type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr> </tbody> </table>	Zone	Zone Type	Setpoint (°C)	Setback (°C)	P1	P2	1-1:	Hose	25	20	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1-2:	Valve	25	20	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2-3:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>	2-4:	Manifold	25	20	<input type="checkbox"/>	<input type="checkbox"/>	3-5:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>	3-6:	Manifold	25	20	<input type="checkbox"/>	<input type="checkbox"/>	4-7:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>	4-8:	Pump	25	20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	5-9:	Platen - 20L	25	20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<h3>Heat Setup Screen 1 – Heat Setpoints</h3> <p>This screen allows the user to define zone type, zone setpoint, zone setback and enable the zone.</p> <p>1st column corresponds to the connector and zone number. The first number corresponds to heat connector and the second number corresponds to the heat zone on the Automatic Multi-Zone (AMZ). For example, heat zone number 3-5 corresponds to connector 3 and heat zone 5.</p> <p>Press the  soft key to enter edit mode.</p> <p>2nd column, corresponds to the zone type. The opinions are as follows:</p> <ul style="list-style-type: none"> • Hose • Valve • Manifold • PGM • Flowmeter • Press Regulator <p>3rd column, corresponds to the heat setpoint temperature, this is the temperature that the controller will control to when the heat is on.</p> <p>4th column, corresponds to the heat setback temperature, this is the temperature that the controller will control to when the system is in setback.</p> <p>5th column, corresponds to the zone enable/disable. When checked, the zone will be controlled to the temperature setpoint or setback depending the state of the controller. If the zone is not used, unchecked the box.</p> <p>6th column, corresponds to the tandem systems heat zones and is only visible when a tandem system is enabled. When checked, the zone will be controlled by the unit it is under. For example, checking a box under the P2 column when in unit 1's heat setup screen will cause that P2 zone to be activated when unit 1's systems heat goes online.</p> <p>Applying Heat Global Setting: While still in Heat Setup Screen and in edit mode, when a setpoint or setback field is highlighted, the globalize  soft key will be shown on the bottom left softkey.</p> <p>Press the globalize  soft key to apply global setting to all heat zones for that particular setting.</p> <p>Press the  soft key to complete applying the selected parameter.</p> <p>Press the  soft key to cancel the globalization.</p>
Zone	Zone Type	Setpoint (°C)	Setback (°C)	P1	P2																																																								
1-1:	Hose	25	20	<input checked="" type="checkbox"/>	<input type="checkbox"/>																																																								
1-2:	Valve	25	20	<input checked="" type="checkbox"/>	<input type="checkbox"/>																																																								
2-3:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>																																																								
2-4:	Manifold	25	20	<input type="checkbox"/>	<input type="checkbox"/>																																																								
3-5:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>																																																								
3-6:	Manifold	25	20	<input type="checkbox"/>	<input type="checkbox"/>																																																								
4-7:	Hose	25	20	<input type="checkbox"/>	<input type="checkbox"/>																																																								
4-8:	Pump	25	20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>																																																								
5-9:	Platen - 20L	25	20	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>																																																								

Screen	Description
	<h3>Heat Setup Screen 2 – Heat Soak</h3> <p>This screen allows the user to define zone heat soak.</p> <p>The heat soak time in the far-right column is the amount of additional time that the heat zone needs to ensure that the material is heated evenly throughout after the zone is up to temperature. Enter a time in minutes. A value of 0 will disable the heat soak timer.</p> <p>While in the edit mode, the globalize  soft key can be used to globalize the heat soak setting.</p>
	<h3>Heat Setup Screen 3 – Heat Rate Option</h3> <p>The heat rate of each zone can be configured in this screen. The heat rate is the speed that a zone takes to reach its setpoint temperature.</p> <p>The heat rate in the far-right column is the rate that the zone will heat up at. There are three opinions:</p> <ul style="list-style-type: none"> • Normal • Slow • Fast <p>While in the edit mode, the globalize  soft key can be used to globalize the heat rate setting.</p> <p>NOTE: Normal heat rate is recommended, however if a zone is not warming up to the setpoint quick enough, then select fast rate opinion for that zone. However, please note, when selecting the fast rate opinion, there is a great risk of overshooting the setpoint temperature. Furthermore, when in normal rate and the temperature is overshooting the setpoint, then select the slow rate opinion. However, please note, it will take a longer time for the temperature to reach setpoint</p>
	<h3>Heat Setup Screen 4 – Heat Error Bounds</h3> <p>Each column on the screen specifies the allowable temperature difference in degrees from a zone operating temperature before triggering an error. The red bell icon indicates an alarm, and the white bell icon indicates an advisory. The plus symbol (+) indicates a high level error, and the minus symbol (-) indicates a low level error. NOTE: The default values are 15°C for an advisory, and 25°C for an alarm, but different temperature values can be entered for each zone. For example: If the zone temperature is set to 50°C, and the user sets +15°C for a high advisory and +25°C for a high alarm, the advisory will occur when the temperature reaches 65°C (50°C + 15°C), and an alarm will occur when the temperature reaches 75°C (50°C + 25°C). The same applies to the low alarm and low advisory settings. Using the same example with a zone temperature of 50°C with a low advisory of -15°C and a low alarm of -25°C, an advisory will occur when the temperature reaches 35°C (50°C - 15°C), and an alarm will occur when the temperature reaches 25°C (50°C - 25°C). While in the edit mode, the globalize  soft key can be used to globalize the heat error bounds.</p>




Screen	Description																														
	<h3>Heat Setup Screen - 5 Heat Diagnostics</h3> <p>This screen will display the heat diagnostics for the AMZ module. The diagnostics display on the screen are the current heat state, setpoint temperature, actual temperature, current, and PWM, Pulse Width Modulation at which the zone is currently running, along with the heat soak timer. Line voltage coming into the AMZ, Heat Idle Countdown timer is also shown on the screen.</p> <ol style="list-style-type: none"> The zone heat symbol in the 1st column corresponds to the current type to which the zone is set. The following zone heat symbols can be displayed.. <table border="1" data-bbox="943 653 1265 1016" style="margin: 10px auto;"> <caption>Zone Heat Symbol</caption> <tr><td></td><td>Hose</td></tr> <tr><td></td><td>Valve</td></tr> <tr><td></td><td>Manifold</td></tr> <tr><td></td><td>PGM</td></tr> <tr><td></td><td>Flowmeter</td></tr> <tr><td></td><td>Press Regulator</td></tr> <tr><td></td><td>Other</td></tr> <tr><td></td><td>Pump</td></tr> <tr><td></td><td>Platen</td></tr> </table> <p>The circle with the two numbers inside of it in the 1st column corresponds to the connector and zone. The fill color of the circle corresponds to the current heat state that zone is in. There are six different color indicators for the heat zone current state.</p> <table border="1" data-bbox="797 1173 1375 1503" style="margin: 10px auto;"> <caption>Zone Current State Color Table</caption> <tr><td>Green</td><td>Heat Zone is at temperature.</td></tr> <tr><td>Yellow</td><td>Heat Zone is in setback</td></tr> <tr><td>Yellow to Green</td><td>Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero</td></tr> <tr><td>Green to Red</td><td>Heat zone has a deviation/advisory.</td></tr> <tr><td>Red</td><td>Heat zone has an alarm.</td></tr> <tr><td>White</td><td>Heat zone is turned off.</td></tr> </table> The 2nd column corresponds to the zone setpoint. Depending on the state of the zone, either the setpoint or the setback temperature that the controller is controlling will be shown. The temperature units can be changed by the Advanced Setup Screen 2 – Unit Settings page 31. The 3rd column corresponds to the zone actual current temperature. The temperature units can be changed by the Advanced Setup Screen 2 – Unit Settings page 31. The 4th column corresponds to the actual current use by the zone. The current is shown in units of Amps (A). The 5th column corresponds to the actual PWM, Pulse Width Modulation that the zone is currently running at. The PWM is nothing more than duty cycle. The duty cycle is defined as the amount of time that the controller is providing current to the heat element over a period of time. The PWM is in units of percentage (%).		Hose		Valve		Manifold		PGM		Flowmeter		Press Regulator		Other		Pump		Platen	Green	Heat Zone is at temperature.	Yellow	Heat Zone is in setback	Yellow to Green	Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero	Green to Red	Heat zone has a deviation/advisory.	Red	Heat zone has an alarm.	White	Heat zone is turned off.
	Hose																														
	Valve																														
	Manifold																														
	PGM																														
	Flowmeter																														
	Press Regulator																														
	Other																														
	Pump																														
	Platen																														
Green	Heat Zone is at temperature.																														
Yellow	Heat Zone is in setback																														
Yellow to Green	Heat Zone is warming up. Note: Heat Zone is in heat soak, when the circle status starts as yellow then progresses clockwise to green as the heat soak timer counts down to zero																														
Green to Red	Heat zone has a deviation/advisory.																														
Red	Heat zone has an alarm.																														
White	Heat zone is turned off.																														

Screen	Description																												
	<p>6. The 6th column is the heat soak countdown timer, which will display the remaining time that the zone will be in heat soak.</p> <p>7. To the right of the divider is the:</p> <ul style="list-style-type: none"> a. The Line Voltage, which corresponds to the current voltage that is seen by the AMZ. b. Heat Idle, which corresponds to the amount of time remaining before the system automatically changes heat state. See Advanced Setup Screen 2 – Unit Settings page 31. 																												
 <table border="1" data-bbox="99 548 602 898"> <thead> <tr> <th></th> <th>Pump</th> <th>Serial Number</th> <th>Heat</th> </tr> </thead> <tbody> <tr> <td>1:</td> <td>Installed</td> <td>20520239</td> <td>Uninstalled</td> </tr> <tr> <td>2:</td> <td>Installed</td> <td>A0479</td> <td>Uninstalled</td> </tr> <tr> <td>3:</td> <td>Uninstalled</td> <td></td> <td></td> </tr> <tr> <td>4:</td> <td>Uninstalled</td> <td></td> <td></td> </tr> <tr> <td>5:</td> <td>Uninstalled</td> <td></td> <td></td> </tr> <tr> <td>6:</td> <td>Uninstalled</td> <td></td> <td></td> </tr> </tbody> </table>		Pump	Serial Number	Heat	1:	Installed	20520239	Uninstalled	2:	Installed	A0479	Uninstalled	3:	Uninstalled			4:	Uninstalled			5:	Uninstalled			6:	Uninstalled			<p>System Setup Screen – Booster and Ram Systems</p> <p>System: Select which type of system (booster, ram, or tandem) to configure. Changing the system type will reset all of the pumps in the system.</p> <p>Automation: Select how the pump will be controlled (via the fieldbus, or discrete I/O).</p> <p>You can configure up to 6 different pumps and select the zone to which they are configured. The serial number for each pump will be listed as the serial number printed on the driver ID tag. By default, the pumps will configure themselves in ascending alphanumeric order based on the serial number. As a backup to the driver serial number, the serial number of the control board will be displayed instead. The serial numbers for the control boards are also displayed in the detailed software status screens.</p> <p>You must configure the zones where heat is installed. By default, the heat setting is set to uninstalled and can be configured to have heat installed and heat installed with expansion.</p> <p>NOTE: when the system is configured as a booster, heat will be hidden as heat boosters are not offered. When the system is configured as a ram, only zone 1 ram can be figured with heat and will uninstall the rest of the pump zones.</p>
	Pump	Serial Number	Heat																										
1:	Installed	20520239	Uninstalled																										
2:	Installed	A0479	Uninstalled																										
3:	Uninstalled																												
4:	Uninstalled																												
5:	Uninstalled																												
6:	Uninstalled																												

Screen	Description
	<p>System Setup Screen – Tandem Systems</p> <p>System: Select which type of system (booster, ram, or tandem) to configure.</p> <p>You must configure two different pumps and select the zone to which they are configured. The serial number for each pump will be listed as the serial number printed on the driver ID tag. By default, the pumps will configure themselves in ascending alphanumeric order based on the serial number. As a backup to the driver serial number, the serial number of the control board will be displayed instead. The serial numbers for the control boards are also displayed in the detailed software status screens.</p> <p>You must configure the zones where heat is installed. By default, the heat setting is set to uninstalled and can be configured to have heat installed and heat installed with expansion.</p> <p>Fluid Filter: Enables/disables additional features that require a fluid filter. The fluid filter must be installed for proper function. Set the bounds for when the low and high filter pressure advisory events will be generated. Setting bounds to 0 disables low and high filter advisory events.</p> <p>Heat Idle Timeout: When heat is installed in the system, the heat idle timeout feature automatically disables heat when the pump remains inactive for a selected amount of time. Setting the timer to 0 disables this feature, while setting a value of 1 or higher configures the timer to that duration in minutes. Once the timer runs out, the heat enters setback mode and subsequently turns off once the timer restarts again. Whenever the system detects pump movement, the heat idle timeout will be reset. If no pump movement is detected, the heat idle timeout will continue counting down.</p>
	<p>Advanced Setup Screen 1 – Standard ADM Settings</p> <p>Set the language, date format, date, time, screen saver time, and password in edit mode as necessary.</p> <p>Set “Display Control Password” to enable while a password is also set, to prevent switching into local/display control mode without first entering a password.</p> <p>Setting the password to “0000” disables the password feature.</p>
	<p>Advanced Setup Screen 2 – Unit Settings</p> <p>Must be in edit mode to change unit settings.</p> <p>Pressure units: Choose between psi, bar, and MPa.</p> <p>Rate units: Choose between rates of x/min and x/sec.</p> <p>Flow Rate units: Choose between cc, gal(US), gal(UK), oz(US), oz(UK), liters, cycles.</p> <p>Drum Volume units: Choose between cc, gal(US), gal(UK), oz(US), oz(UK), liters, cycles.</p> <p>Temperature units: Choose between Fahrenheit and Celsius.</p> <p>Note: When heat is not installed, temperature units will be hidden.</p>

Screen	Description
 <p>07/26/24 09:37 ← Fieldbus Advanced Pump 1 → Heat at Temp No Active Errors</p> <ul style="list-style-type: none"> <input type="checkbox"/> Disable Power Saving Mode <input type="checkbox"/> Enabled Temp Adjustments <input type="checkbox"/> Disable Pump if Heat is Not Ready <input checked="" type="checkbox"/> Disable Load Sharing 	<p>Advanced Setup Screen 3 – Options</p> <p>Must be in edit mode to change options settings.</p> <p>Disable Power Saving Mode: Enables/disables option to turn off power saving mode.</p> <p>Enabled Temp Adjustments: Enables/disables option to disable any USB log errors from appearing on the ADM.</p> <p>Disable Pump if Heat is Not Ready Enter the number of days included in USB data log downloads. USB data is overwritten when the logs fill.</p> <p>Disable Load Sharing: Enables/disables the booster load sharing opinion from running. NOTE: Disable Load Sharing checkbox only available on booster systems.</p>
 <p>08/12/24 10:11 ← Fieldbus Advanced Pump 1 → Pumps Active No Active Errors</p> <ul style="list-style-type: none"> Disable USB Downloads/Uploads: <input type="checkbox"/> Disable USB Log Errors: <input type="checkbox"/> Download Depth: Last <input type="text" value="32"/> Days Date Range Prompt Enable: <input type="checkbox"/> 	<p>Advanced Setup Screen 4 – USB Log Settings</p> <p>Must be in edit mode to change USB log settings.</p> <p>Disable USB Downloads/Uploads: Enables/disables option to disable automatic USB downloads/uploads upon insertion of a USB drive.</p> <p>Disable USB Log Errors: Enables/disables option to disable any USB log errors from appearing on the ADM.</p> <p>Download Depth: Enter the number of days included in USB data log downloads. USB data is overwritten when the logs fill.</p> <p>Date Range Prompt Enable: Enables/disables option to be prompted a time frame to download data from when the USB download is enabled and a USB drive is inserted.</p>
 <p>08/12/24 10:00 ← Fieldbus Advanced Pump 1 → Pumps Active No Active Errors</p> <p>Software Part #: 17X093 Software Version: 1.02.018 ✓</p>	<p>Advanced Setup Screen 5 – Software</p> <p>This screen can be used to view the version of software used in the system. Additionally, this screen is used to update the system software using a USB drive with the latest software and a Graco black token.</p> <p>See Graco ADM Token In-System Programming manual for a detailed description of this screen.</p>

Pump and Driver Settings

				
---	---	---	--	--

To prevent personal injury from pressurized fluid such as skin injection or splashing fluid, make sure that all components in your system are rated to the maximum pressure the system is capable of attaining. All components must be rated for maximum pressure even if the pump is operated below maximum pressure.

NOTICE

To prevent damage to buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.


NOTICE

To prevent damage to components in the system, all components must be rated to the maximum pressure the system is capable of attaining.

The ADM setup screen provides settings that help to ensure proper operation and maintenance of the system. These functions can be performed when the ADM is either in Active or System OFF mode. The settings in the pump setup screens are specific to each pump and must be enabled for each pump individually.


1. Provide power to the system to turn on the ADM.
2. While at the Run Home screen, press the ADM lock/setup button to access the setup screens. If necessary, use the left and right arrow keys on the directional keypad to navigate to Pump 1 on the menu bar.

Pump Setup Screen 1

Select the soft key next to the  icon to enable the functions on the screen.



Use the directional keypad to move between selections, the numeric keypad to enter values and the enter key to open drop down menus and confirm selections.


The settings available of this screen can be set for each pump installed in the system.

1. Navigate to the pressure mode  percentage box using the arrow keys. This percentage sets the

level at which a high or low pressure alarm or deviation will be generated. For example, setting this value to 10% means a high or low pressure alarm or deviation will occur if the pressure rises or falls 10% above or below the target pressure set on the run screen. Enter the desired percentage and press the enter key (setting the percentage to 0% disables the event). Set the error type to alarm, deviation, or none (disables the event). Use the right arrow key to get to the error type box. Press the enter key to display the available error types, select the desired type using the arrow keys, and press the enter key once the correct type is highlighted.

NOTE: Alarm will send an error message and shutdown the system. Deviation sends a warning message but the system continues to operate. If Alarm or Deviation is selected, an error message is sent when the pressure is outside of the designated tolerance range for five seconds or longer.

2. Use the arrow keys to highlight the flow mode  percentage box. The percentage sets the level at which a high or low flow alarm or deviation will be generated. Enter the desired percentage and select the error type following the same instructions mentioned in Step 1.
3. Use the arrow key to highlight the pump diving  sensitivity box. This value dictates how sensitive the pump is to detecting a pump diving error. Increase or decrease this value as desired and select the error type following the same instructions mentioned in Step 1. The default setting should be appropriate for most applications.
4. Verify the pump type is correct. If needed, select the correct pump type from the drop down menu.
5. Verify the pump volume is correct. If needed, enter the correct pump size in cc.
6. Verify the pressure transducer type is correct. If a standard pressure transducer is installed, the box should NOT be checked. If a flush-mount pressure transducer is installed, the box should be checked.
7. Pressure transducers are calibrated at the factory, but calibration may be necessary after extended use. The outlet transducer offset is listed above the inlet transducer offset. Ideally, the pressure transducers should be removed, clear of any material, and in air when attempting calibration. Any residual pressure can throw off the calibration.

Pressing the  soft key will automatically set the offsets to the negative of the value being read by the pressure transducers.

The offsets can also be set manually by selecting “+” or “-” from the Offset drop down boxes and then entering the appropriate offset pressure rating. This can be used to adjust the pressure transducer to a non-zero value. For example, if the outlet pressure is known to be 1000 psi, but the transducer is reading 1010 psi. The offset can be set to -10 and the reading will be adjusted to show 1000 psi instead of 1010 psi.

Pump Setup Screen 2

1. Use the arrow and enter keys to set the driver maintenance limit to a desired number of cycles. The pump will produce an advisory to complete scheduled maintenance when the driver exceeds this number of cycles. Remember to press the






soft key to reset the cycle count after maintenance is performed.


2. Repeat step one for the pump and platen maintenance limits as desired.


Pump Setup Screen 3



1. If the  icon appears next to calibration status, the driver must be calibrated. In edit mode, press the  soft key.
2. See your driver manual for calibration instructions.
Pressing  will begin calibration.

Pump Setup Screen 6 (Ram and Tandem Systems Only)

1. Navigate to the Not Primed Event select box. Use the enter key to select the desired error type as alarm, deviation, or none. This determines the error type generated after a drum is changed. If set to alarm, the pump must be primed before continuing normal operation.
2. Enter the desired priming length in minutes in the Prime Timer box.
3. If a low drum level sensor is installed, press the enter key over the Low Sensor box to place an “X” in the box. An “X” denotes the sensor is installed and a low level deviation will be generated when the sensor is triggered. Leave the box empty if no low level deviation is desired.
4. If an empty drum sensor is installed, press the enter key over the Empty Sensor box to place an “X” in the box. An “X” denotes the sensor is installed and an empty alarm will be generated when the sensor is triggered. Leave the box empty if no empty alarm is desired.
5. If an empty drum sensor is installed, the Smart Empty feature can be enabled. This alarm is generated from multiple indicators to better determine when the drum is empty and reduce material waste from changing a drum too early. If desired, use the enter key to place an “X” in the Smart Empty box. **NOTE:** See **Pump Setup Screen 6 – Drum Settings** on page 26 for comments on the pump diving sensitivity.
6. If a fluid solenoid is installed, use the enter key to place an “X” in the Fluid Solenoid box. **NOTE:** The pressure target will be capped at a maximum of 5000 psi (34.4 MPa, 344 bar) if this setting is enabled.
7. Enter the average volume of material contained within drums in the Drum Volume box using the keypad and enter button. This will provide an estimate of remaining drum volume on the run screen.
8. When enabled, the Dynamic Setpoint Mode percentage will be shown on the run screen and will look like **100 %** . When in local or remote discrete mode, the percentage will be able to be adjusted by the ADM. When the mode is fieldbus remote, the percentage must come from the

external source. The input signal status  indicates the state that E-Flo SP will be running in. When the input signal is low, the E-Flo SP runs at the reduced normal operating setpoint percentage, and when the input is high, it runs at the normal operating setpoint. See **Pump Setup Screen 6 – Drum Settings** page 26.

Advanced Setup Screen 1

1. Set the Language, Date Format, Date, Time, and Screen Saver time as desired.
2. Enable a password if desired. If the Display Control Password is enabled, a password will be required to switch from remote to local control of the system on the run screen. Note, a password of 0000 means the password function is disabled.

Advanced Setup Screen 2

1. Select desired units for Pressure, Rate, Flow Rate, Drum Volume, and Temperature.
2. To enable Discrete Display Control, press the enter key over the check box to mark it with an X. Leave the box empty if Discrete Display Control will not be used.

Advanced Setup Screen 3

1. Enable or disable the desired options for Power Saving Mode, Temp adjustments, or disabling pump if the heat is not ready.
2. To Enable an option use the enter key to place an (X) in the box next to the option while the screen is in edit mode.

Advanced Setup Screen 4

1. USB downloads automatically begin when a USB drive is inserted. To disable this feature, use the enter key to place an “X” in the Disable USB Downloads/Uploads box.
2. If you do not want USB log errors to be generated on the ADM, use the enter key to place an “X” in the Disable USB Log Errors box.
3. Set the desired download depth using the keypad and enter key to enter the desired number of days. This specifies how many days’ worth of pump data will be kept in the USB logs. Once the logs fill up, the oldest recording will be overwritten.

4. To enable a date range of data to download upon insertion of a USB drive, use the enter key to place an “X” in the Date Range Prompt Enable box

System Setup Screen

1. Use the enter key to select the desired system type in the System box if needed.
2. If using external discrete I/O to control the pump, change the setting in the Automation box to Discrete using the Enter key.
3. Verify the pumps in the system are installed and the proper serial number is listed.
4. If a using a Tandem system and a fluid filter is installed, use the enter key to place an “X” in the Fluid Filter box. Use the keypad and enter key to enter the desired high and low filter pressure differences at which to generate a high or low filter pressure advisory.
5. If using a heated system, then an option for heat will appear as a third column when in Ram and tandem. This column will have an option to install heat for the system for one pump in a Ram system and for both pumps in a Tandem system. A Heat Idle Timer will also be configurable where the timer length in minutes can be entered using the ADM keypad. If the Heat Idle Timer expires will the pump is not moving, the system will place the heat into setback, if it expires again, it will turn off the heat. If the pump moves, the Heat Idle Timer, will be reset.

NOTE: The pressure target will be capped at a maximum of 5000 psi (34.4 MPa, 344 bar) if this setting is enabled.

Connect Light Tower Accessory

1. Order the 255468 Light Tower Accessory as a diagnostic indicator for the E-Flo SP system.
2. Connect the cable from the light tower to the digital I/O port on the ADM.

Signal	Description
Green	No errors
Yellow	An advisory exists
Yellow flashing	A deviation exists
Red solid	An alarm exists.

NOTE: See **Troubleshooting**, page 37, for error definitions.

Pump Load Sharing

Please note the following load sharing restrictions:

- Load sharing is enabled only after software version 1.10.005. Please update the software from [help.graco.com](https://help.graco.com/en/software-history/e-flo-sp-software-change-history.html#root-responsivegrid-slab-slab-parsys-accordionlist_1046909021-accordion1648841610051-par-accordionlist-accordion1648841726085). See the specific link below.
https://help.graco.com/en/software-history/e-flo-sp-software-change-history.html#root-responsivegrid-slab-slab-parsys-accordionlist_1046909021-accordion1648841610051-par-accordionlist-accordion1648841726085
- Load sharing only works in pressure mode. It does not work in combined mode or flow mode.
- Load sharing is only available on a group of two or more booster pumps, with a maximum of six.
- Load sharing is not available on rams.

What It Is

The Load Sharing feature within the E-Flo SP Booster pump is a feature to ensure the sharing of the work (pump pressure) between the available E-Flo SP pumps within the connected to the system of pumps. The purpose is for E-Flo SP booster pumps within a system to work (pump) at a similar level while maintaining a specified system pressure. The Load Sharing feature controls all pumps within the system to do the same amount of work. The Load Sharing feature will overcome common situations that would prevent a pneumatic pump from working evenly, situations such as tight packings, hose restriction and piping layouts.

How It Works

Each E-Flo SP booster pump communicates to the system of booster pumps (up to 6). Each E-Flo SP booster knows how all others are performing. When one pump is doing less work or more work, the entire system compensates through a closed loop control algorithm. The pumps sense if one has been taken off line or if one is added to the system and adjusts real time accordingly. The adjustment of each pump on the system happens slowly in order to maintain stability to

the process, each added or removed E-Flo SP booster will take a few seconds to catch up to the other pumps.

Benefits

Maintenance:

- By sharing the load of the sealer system, all pumps do the same amount of work. This allows pumps to be rebuilt on a set schedule/downturn since they will all have the same amount of usage.

Higher system flow rate:

- Sharing the load allows all of the pumps online to do work toward maximum system flow rate. When pneumatics are used, one pump will always run faster than the others, due to improper loading. Load sharing effectively allows all pumps to hit the maximum cycle rate simultaneously.

Ability to change out pumps:

- Load sharing grants the ability to swap out a worn pump while all others are running. Example: In a three-pump booster system, removing one pump will cause the other two pumps to pick up the load, provided there is enough headroom on the cycle rate.

Greater performance than pneumatic pumps:

- Able to integrate with the PLC or robot to monitor and control.
- Much more efficient than pneumatics.
- Easier to size the booster system.
- Ability to monitor the number of cycles on a pump in order to perform downturn maintenance.

Troubleshooting

<p>REMOTE SYSTEM ACTIVATION HAZARD</p> <p>To avoid injury due to remote machine operation, perform the steps below before troubleshooting. This will prevent commands sent from the fieldbus or display module from actuating the driver/pump.</p>				

1. Relieve pressure for pump or ram in need of service. Perform the Pressure Relief Procedure in your system manual.
2. Disconnect power to the pump or ram in need of service. See your system manual for complete instructions.

Error Codes and Troubleshooting

See **Troubleshoot Error Codes** table on page 39, or visit help.graco.com/e-flo-sp-system/ for causes and solutions to each error code.

Errors

View Errors

When an error occurs, the error information screen displays the active error code and description.

The error code, alarm bell, and active errors will scroll in the status bar. Error codes are stored in the error log and displayed on the Error and Troubleshooting screens on the ADM.



There are three types of errors that can occur. Errors are indicated on the display as well as by the light tower (optional).

Alarms are indicated by . This condition indicates a parameter critical to the process has reached a level requiring the system to stop. The alarm needs to be addressed immediately.

Deviations are indicated by . This condition indicates a parameter critical to the process has reached a level requiring attention, but not sufficient enough to stop the system at this time.

Advisories are indicated by . This condition indicates a parameter that is not immediately critical to the process. The advisory needs attention to prevent more serious issues in the future.



To diagnose the active error, see **Troubleshoot Errors** on page 38.

Troubleshoot Errors

To troubleshoot the error:

1. Press the soft key next to “Help With This Error” for help with the active error.



NOTE: Press  or  to return to the previously displayed screen.

2. The QR code screen will be displayed. Scan the QR code with your smart phone to be sent directly to online troubleshooting for the active error code. You can also navigate to help.graco.com/e-flo-sp-system/ for causes and solutions to each error code.



3. If no internet connection is available, call Graco Technical Assistance.

Troubleshoot Error Codes

Error	Location	Type	Error Name	Error Description	Cause	Solution
A1_	AMZ	Alarm	Low Current H_Z_	Heater current is below the minimum allowed value.	Fault heater element	Check heater resistance and resistance to ground. Replace faulty heater
A2_	AMZ	Advisory	Low Current H_Z_	Heater current is below the minimum allowed value	Fault heater element	Check heater resistance and resistance to ground. Replace faulty heater
A3_	AMZ	Alarm	High Current H_Z	Heater current exceeds maximum allowed value	Heater element is defective	Replace heater element
					Heater element is shorted	Check wiring to the heater element to ensure no bare wires are touching and that no wires are shorted to ground
A4_	AMZ	Alarm	High Current H_Z	Heater current exceeds maximum allowed value	Heater element is defective	Replace heater element
					Heater element is shorted	Check wiring to the heater element to ensure no bare wires are touching and that no wires are shorted to ground
A4D_	Driver	Alarm	High Motor Current P_	Motor current exceeds maximum allowed value	Encoder malfunction	Calibrate encoder. If this fails, then replace encoders.
					Pump Diving: A pressure imbalance between the up and down stroke of the pump is causing the pump to dive with excessive speed.	Pump diving may occur when the pump runs out of material while spraying at high pressure. Verify that material is being properly fed to the pump. Pressure from the hose could flow back into the pump on the down stroke. Verify that the check valve is installed and is properly working.
					Motor not able to rotate	Check that motor shaft rotates freely.
A4N_	Driver	Alarm	High Motor Current P_	Motor current exceeds maximum allowed value	Encoder malfunction	Calibrate encoder. If this fails, then replace encoders.
					Pump Diving: A pressure imbalance between the up and down stroke of the pump is causing the pump to dive with excessive speed.	Pump diving may occur when the pump runs out of material while spraying at high pressure. Verify that material is being properly fed to the pump. Pressure from the hose could flow back into the pump on the down stroke. Verify that the check valve is installed and is properly working.
					Motor not able to rotate	Check that motor shaft rotates freely.

Error	Location	Type	Error Name	Error Description	Cause	Solution
A7_	AMZ	Alarm	Unexpected Current H_Z_	Heat current has an unexpected current flow	Unexpected Current flow to the heat element	Fault heater element. Check heater resistance and resistance to ground. Replace heater element Faulty AMZ; replace AMZ
A8_	AMZ	Alarm	No Current H_Z_	Power is not getting to heating element	Power not getting to heating element	Check fuse on the AMZ that the error element is connected to. Check that electrical connector on the heated hose is plugged into the AMZ Check continuity of pins C and D on electrical connector at AMZ end of heated element. See heated element manual for impedance measurements. Replace hose if readings are too high.
CAC_	ADM	Alarm	Communication Error P_	Communication lost between ADM and pump	No 24 VDC power supply to ADM Cross threaded CAN cable.	Reconnect or replace CAN cable connecting driver and ADM. If CAN connection good, check 24V power supply wiring in driver. Disconnect AC power to pump before checking power supply. Yellow LED on driver connector board should be flashing. CAN cables carry 24 V DC power and communication between modules. A cross threaded CAN cable connector may cause problems with communication and/or power to modules. Carefully check for cross threaded CAN connections on the ADM and driver. Yellow LED on driver connector board should be flashing.
CBD_	Driver	Alarm	Communication Error P_	Communication lost between pump and ADM	No AC power to driver.	Verify pump is turned on by confirming disconnect switch is in the ON position. Yellow LED on driver connector board should be flashing.
					AC disconnect switch broken	Disconnect pump from AC power. Check wiring to switch. If wiring is good, replace the AC disconnect switch.
					Faulty driver control board	Replace driver electronics cover.

Error	Location	Type	Error Name	Error Description	Cause	Solution
CBT_	AMZ	Alarm	Communication Error H_	Communication lost between AMZ MZLP4 and ADM	No AC power to the AMZ MZLP4	Verify AMZ MZLP4 is turned on by confirming disconnect switch of the heat box is in the ON position.
					AC disconnect switch broken	Disconnect AMZ MZLP4 from AC power. Check wiring to switch. If wiring is good, replace the AC disconnect switch of the heat box.
					Faulty AMZ MZLP4 control board	Replace AMZ MZLP4 control board.
CBV_	AMZ	Alarm	Communication Error H_	Communication lost between AMZ DB and ADM	No AC power to the AMZ DB	Verify AMZ DB is turned on by confirming disconnect switch of the heat box is in the ON position
					AC disconnect switch broken	Disconnect AMZ DB from AC power. Check wiring to switch. If wiring is good, replace the AC disconnect switch of the heat box
					Faulty AMZ DB control board	Replace AMZ DB control board
CCD_	Driver	Alarm	Duplicate Module P_	Multiple pumps using same pump ID	Two or more pumps have the same pump ID	Update the pumps displaying the error to the latest software available on help.graco.com.
CCH_	Gateway	Alarm	Fieldbus Comm. Error H_	No communication with the fieldbus	The automation gateway lost communication with the heat automation controller	Restore communication
CCG_	Gateway	Alarm	Fieldbus Comm. Error P_	No communication with the fieldbus	The automation gateway lost communication with the automation controller	Restore communications.
CCN_	Driver	Alarm	Control Board P_	Communication lost between driver hot and cold boards	Software update failure	If software updates to the hot or cold driver boards fail before completion, then they will not be able to communicate. Update software to the latest available on help.graco.com.
					Cold board disconnected from hot board	Disconnect pump from AC power. Verify the cold board is securely fastened on the spacers above the hot board.
					Faulty driver control board	Replace driver electronics cover.
CCT_	AMZ	Alarm	Duplicate Module H	Multiple AMZ MZLP4s using same module ID	Two or more AMZ MZLP4s have the same module ID	Turn dial on AMZ to a non-used module ID
CCV_	AMZ	Alarm	Duplicate Module H	Multiple AMZ DBs using same module ID		Turn dial on AMZ to a non-used module ID

Error	Location	Type	Error Name	Error Description	Cause	Solution
DB1_ DB2_	Pump	Alarm or Deviation (user selectable)	Pump Not Primed P_	Pump has not been primed since last empty drum	Replacing an empty drum with a new one	After replacing an empty drum, the pump must be primed before returning to operation (if alarm selected). Go to the pump run screen and push the lower right soft key to begin the priming sequence, then press the upper right soft key. Set the priming time in the setup screens. If deviation selected, prime pump if desired or clear deviation and return to normal pump operation.
DD3_ DD4_	Pump	Alarm or Deviation (user selectable)	Pump Diving P_	Pump diving detected	Flow to pump inlet restricted	Check inlet valve is open or check inlet supply system for clogs
DKC_	Pump	Alarm	Crossover Error P_	Crossover error in tandem system	Second pump is in error state when crossover takes place	Clear the error on the second pump.
EAUX	ADM	Advisory	Download to USB In Process	Information is currently being downloaded to USB	Download to USB initiated	No action necessary. Self-clearing
EAW	AMZ	Record Only	Heat_ Module Warming Up	All zones on heat module are in warming up state	All zones on heat module were successfully placed into warm up	No action necessary
EBH_	AMZ	Record Only	Heat_ Module Off	All zones on heat module are turn off	All zones on heat module were successfully turned off	No action necessary
EBUX	ADM	Advisory	Download to USB Complete	Download to USB is complete	All requested information has finished downloading to USB	No action necessary. Self-clearing
EC0X	ADM	Record Only	Setup Values Changed	A setting in the setup screen was changed	A setting in the setup screens was changed	No action necessary if changes were desired.
EDF_	AMZ	Record Only	Heat_ Module Placed into Heat Soak	All zones on heat module are in heat soak state	All zones on heat module were successfully placed into heat soak	No action necessary
EDS_	AMZ	Record Only	Heat_ Module Placed into Setback	All zone on heat module are in setback state	All zones on heat module were successfully placed into setback	No action necessary

Error	Location	Type	Error Name	Error Description	Cause	Solution
EDT_	AMZ	Record only	Heat_ Module is at desired temperature	All zone on heat module are at desired temperature	All zones on heat module have successfully reached the desired temperature	No action necessary if the desired temperature was reached.
ELOX	ADM	Record Only	Power On	The ADM was powered on	The ADM was powered on	No action necessary.
EM0X	ADM	Record Only	Power Off	The ADM was powered off	The ADM was powered off	No action necessary.
EUH_	AMZ	Record Only	Heat Idle Timeout	Automatically turns off heat after the pump has not moved for the designated amount of time	All zones on heat module were successfully turned off	No action necessary
EVUX	ADM	Advisory	USB Disabled	USB downloads/uploads are disabled	USB download/upload was attempted, but USB activity is disabled within the setup screen	Advisory will clear when USB drive is removed. Enable USB downloads/uploads in setup screen if desired and reinsert USB drive.
F1D_ F2D_	Pump	Alarm or Deviation (user selectable)	Low Flow Rate P_	Measured flow rate less than desired flow rate minus tolerance	Fluid supply too low to achieve desired flow rate	Increase fluid pressure to reach desired rate.
					Clog in fluid supply system	Check hose and other components in fluid supply system for clogs.
					No material supply	Replace drum and prime pump if desired.
					Incorrect flow tolerance	Enter correct flow tolerance percentage in setup screen.
F3D_ F4D_	Pump	Alarm or Deviation (user selectable)	High Flow Rate P_	Measured flow rate greater than desired flow rate plus tolerance	Incorrect flow tolerance	Enter correct flow tolerance percentage in setup screen.
L1C_	Pump	Alarm	Drum Empty P_	Drum is empty	Drum is empty and needs to be replaced	Replace drum and prime pump if desired.
					Drum level sensor is disconnected	Verify level sensor is connected. Replace sensor if connection is good.
L2C_	Pump	Deviation	Drum Empty P_	Drum level is low	Fluid level in drum is low. Consider replacing soon	Clear deviation and return to normal pump operation.
					Drum level sensor is disconnected	Verify level sensor is connected. Replace sensor if connection is good.
MMUX	ADM	Advisory	USB Log 90% Full	One or more USB log is 90% full.	Data in the jobs or events log has not been downloaded recently and logs are nearly full.	Download the data or disable USB errors.

Error	Location	Type	Error Name	Error Description	Cause	Solution
MAD_	Pump	Advisory	Maint. Due Pump P_	Maintenance due for pump	The number of pump cycles since last reset has exceeded the maintenance limit set	Perform desired maintenance and reset the pump cycles in the setup screen.
MBD_	Pump	Advisory	Maint. Due Driver P_	Maintenance due for driver	The number of driver cycles since last reset has exceeded the maintenance limit set	Perform desired maintenance and reset the driver cycles in the setup screen.
MLC_	Pump	Advisory	Rebuild Platen Seals P_	Maintenance due for platen seals	The number of replaced drums since last cycles reset has exceeded the maintenance limit set	Rebuild the platen seals if desired and reset the platen cycles in the setup screen.
MG2_	Pump	Advisory	Low Filter Pressure P_	Low filter pressure drop detected	The filter has an opening in it	Replace the fluid filter.
MG3_	Pump	Advisory	High Filter Pressure P_	High filter pressure drop detected	There is a clog in the manifold	Clean out the manifold to reduce the pressure.
P1C_ P2C_	Pump	Alarm or Deviation (user selectable)	Low Pressure P_	Measured outlet pressure less than desired outlet pressure minus tolerance	Incorrect pressure tolerance	Enter correct pressure tolerance percentage in setup screen.
					Failed pressure transducer	Check transducer, replace if failed
					No or insufficient material flow	Increase material flow
P4C_ P3C_	Pump	Alarm or Deviation (user selectable)	High Pressure P_	Measured outlet pressure greater than desired outlet pressure plus tolerance	Incorrect pressure tolerance	Enter correct pressure tolerance percentage in setup screen.
					Failed pressure transducer	Check transducer, replace if failed
					Clog in fluid supply system	Check hose and other components in fluid supply system for clogs.
P6D_	Pump	Deviation	Outlet Pressure Sensor P_	Outlet pressure transducer not connected	The outlet pressure transducer is not connected or faulty	Verify outlet pressure transducer is installed and/or connected correctly. Replace if necessary.
TA_	AMZ	Alarm	Heat Zone Offline Z_H_	The heat zone is offline	The AMZ lost communication with the other Tandem AMZ	Restore communication.
T1_	AMZ	Alarm	Low Temperature H_Z_	Temperature of the zone is below the setpoint	Zone has reached setpoint but dropped below setpoint and cannot recover	Check resistance of heater rods. Refer to manual for resistance
						Adjust the temp offset errors in the Heat Setup screen.

Error	Location	Type	Error Name	Error Description	Cause	Solution
T2_	AMZ	Advisory	Low Temperature H_Z_	Temperature of the zone is below the setpoint	Zone has reached setpoint but dropped below setpoint and cannot recover	Check resistance of heater rods. Refer to manual for resistance
						Adjust the temp offset errors in the Heat Setup screen
T3_	AMZ	Advisory	High Temperature H_Z_	The zone temperature has exceeded the setpoint	Element continues to raise above the setpoint	Defective RTD. Replace
					Element continues to raise above the setpoint	See manual to find correct location of RTD on element
					Temperature reading has risen too high	Adjust the temp offset errors in the Heat Setup screen
T4_	AMZ	Alarm	High Temperature H_Z_	The zone temperature has exceeded the setpoint	Element continues to raise above the setpoint	Defective RTD. Replace
					RTD not in correct location on element	See manual to find correct location of RTD on element
T6_	AMZ	Alarm	Sensor Error H_Z_	The zone has no reading from RTD	No reading from the RTD of the heat zone	Check the wired connections to make sure that RTD is wired correctly
						Defective RTD. Replace
T7C_	Driver	Alarm	Heat Not Ready H_Z_	One or more zones have not reached the desired setpoint for the pump	The heat module is not up to temperature	Wait for the heat zone to reach temperature
						Turn on the heat to increase the heat rate for that zone
T8_	AMZ	Alarm	No Temperature Rise H_Z_	The zone temperature has not changed	The zone temperature has not changed	Check fuse on the AMZ that the error element is connected to
						Check that electrical connector on the heated hose is plugged into the AMZ
						Plug the zones wires back in

Error	Location	Type	Error Name	Error Description	Cause	Solution
T9_	AMZ	Alarm	Over Temperature Switch Error Z_	The zones switch has an over temperature reading	The zones over temperature switch's wires are unplugged	Plug the zones wires back in
					The zone temperature is too high	Cool pump down
					Fault over temperature switch	Replace over temperature switch
T2D1	Driver	Deviation	Motor Temperature Sensor P_	Motor temperature thermistor disconnected	The motor temperature thermistor is not connected or faulty	Verify motor temperature thermistor is installed and/or connected correctly. Replace if necessary.
T3D1	Driver	Deviation	Temperature Cutback P_	Current supplied to motor is being reduced in order to lower driver temperature	The control board temperature inside the driver is too high	Ensure ambient temperature is below 120F (48C). Ensure the enclosure fans are working properly.
					Enclosure fan not operating	Verify fan is spinning. If it is not, disconnect pump from AC power and check fan wiring or replace fan.
T4C1	Driver	Alarm	High Controls Temperature P_	Temperature of the control board is too hot	The control board temperature inside the driver is too high	Ensure ambient temperature is below 120F (48C).
					Enclosure fan not operating	Verify fan is spinning. If it is not, disconnect pump from AC power and check fan wiring or replace fan.
T4C1	Driver	Alarm	High Motor Temperature P_	Temperature of the motor is too hot	The motor temperature inside the driver is too high	Ensure ambient temperature is below 120F (48C).
					Enclosure fan not operating	Verify fan is spinning. If it is not, disconnect pump from AC power and check fan wiring or replace fan.
V1M_	Driver	Alarm	Low Voltage P_	Supplied bus voltage is below minimum acceptable limit	Transformer faulty	Check output voltage of transformer to verify it is within acceptable input limits.
					Incorrect line voltage	Check line voltage to verify it is as expected (230V, 480V, etc.)
V2H_	AMZ	Deviation	Low Voltage H_	The incoming power is below minimum acceptable limit	Incoming line to line voltage has dropped below 175V	Verify incoming power is correct gauge for current draw and verify incoming power lines are securely attached to disconnect.

Error	Location	Type	Error Name	Error Description	Cause	Solution
V4H_	AMZ	Alarm	High Voltage H_	The incoming power is above maximum acceptable limit	Incoming line to line voltage has increased above 265V	Verify incoming power is correct gauge for current draw and verify incoming power lines are securely attached to disconnect.
V4M_	Driver	Alarm	High Voltage P_	Supplied bus voltage is above maximum acceptable limit	Transformer faulty	Check output voltage of transformer to verify it is within acceptable input limits.
					Incorrect line voltage	Check line voltage to verify it is as expected (230V, 480V, etc.)
V6H_	AMZ	Alarm	Wiring Error H_	The wiring is invalidated from what the AMZ is expecting	Wrong wiring of the power source to the AMZ	Verify incoming power is wired to the disconnect correctly per the manual.
WBD_	Driver	Alarm	Encoder Hardware P_	Encoder or hall sensor disconnected or failed to commutate motor	Encoder disconnected or faulty	Disconnect pump from AC power. Verify encoder cable is properly connected. If so, recalibrate encoder. If this fails, replace encoder.
WMC_	Driver	Alarm	Control Board P_	Control board reset due to an exception in software	Invalid software state	Cycle the power to the pump to reset the driver software. If this doesn't work, update software to the latest available on help.graco.com.
WMG0	Gateway	Alarm	Gateway Error Detected	Gateway error detected; includes any error not covered by a more specific error	---	---
WMN_	Driver	Alarm	Software Mismatch P_	Software mismatch detected in the motor control board	Hot board and cold board have different software versions	Update the driver control board software to the latest available on help.graco.com.
WNG0	Gateway	Alarm	Gateway Map Error	Missing or invalid gateway map	Missing or invalid gateway map	Install map in gateway.
WSC_	Driver	Deviation	Encoder Calibration P_	Encoder calibration information not found	Encoder not calibrated before or calibration information deleted	Perform encoder calibration through the setup screens of the ADM.
WSU0	ADM	Alarm	USB Configuration Error	USB configuration file not detected	USB configuration file not loaded or was deleted	Update software to the latest available on help.graco.com.

USB Data

Download Procedure

NOTE: If log files are not correctly saving to the USB flash drive (for example, missing or empty log files), save the desired data off of the USB flash drive and reformat it before repeating the download procedure.

NOTE: System configuration setting files and custom language files can be modified if the files are in the UPLOAD folder of the USB flash drive. See **System Configuration Settings**, page 49, **Custom Language File**, page 49, and **Upload Procedure** on page 50.

1. Insert the USB flash drive into the USB port.
2. The menu bar and USB indicator lights indicate that the USB is downloading files. Wait for USB activity to complete.
3. Remove the USB flash drive from the USB port.
4. Re-insert the USB flash drive into the USB port of computer.
5. The USB flash drive window automatically opens. If it does not, open USB flash drive from within Windows[®] Explorer.
6. Open the GRACO folder.
7. Open the system folder. If downloading data from more than one system, there will be more than one folder. Each folder is labeled with the corresponding serial number of the ADM
NOTE: The serial number is on back of the ADM.
8. Open the DOWNLOAD folder.
9. Open the DATAxxxx folder.
10. Open the DATAxxxx folder labeled with the highest number. The highest number indicates the most recent data download.
11. Open the log file. Log files open in Microsoft[®] Excel by default as long as the program is installed. However, they can also be opened in any text editor or Microsoft[®] Word.

NOTE: All USB logs are saved in Unicode (UFT-16) format. If opening the log file in Microsoft Word, select Unicode encoding.

USB Logs

NOTE: The ADM can read/write to FAT (File Allocation Table) storage devices. NTFS, used by 32 GB or greater storage devices, is not supported.

During operation, the ADM stores system and performance related information to memory in the form of log files. The ADM maintains six log files:

- Event Log
- Pump X Log
- Cycles Log

Follow the **Download Procedure**, page 48, to retrieve log files.

Each time a USB flash drive is inserted into the ADM USB port, a new folder named DATAxxxx is created. The number at the end of the folder name increases each time a USB flash drive is inserted and data is downloaded or uploaded.

Event Log

The event log file name is 1-EVENT.CSV and is stored in the DATAxxxx folder.

The event log maintains a record of the last 1,000 events and errors. Each event record contains:

- Date of event code
- Time of event code
- Event code
- Event Type
- Event Description

Event codes include both error codes (alarms, deviations, and advisories) and record only events.

PumpX Log

The pump log file name is X-PUMPX.csv and is stored in the DATAxxx folder. The first X is the log number and the second X is the pump number.

There will be a pump log for every pump installed on the system. Each log maintains seven days worth of run data.

The pump log records the pressure and flow operating points of the pumps at 15 second intervals while the pump is enabled. The parameters recorded in this log are listed below.

- Target Outlet Pressure (bar)
- Actual Outlet Pressure (bar)
- Actual Inlet Pressure (bar)
- Target Flow Rate (cc/min)
- Actual Flow Rate (cc/min)

Cycles Log

The cycles log file name is 8-CYCLES.csv and is stored in the DATAxxx folder.

The cycles log records driver and pump cycle information for each pump. The parameters recorded in this log are listed below.

- Pump ID
- Driver Lifetime Cycles
- Driver Maintenance Cycles
- Pump Maintenance Cycles
- Platen Maintenance Cycles
- Driver Cycles in 10% increments of Max Output Thrust

HeatX log

The pump log file name is X-HEATX.csv and is stored in the DATAxxxx folder. The first X is the log number and the second X is the heat pump number.

There will be a heat log for every pump that has heat installed on the system. Each log maintains around two days worth of run data.

The pump log record the zones one at a time, in 20 seconds intervals while the heat is active. The parameters record in this log are listed below.

- Zone ID
- State
- Setpoint Temperature (deg C)
- Actual Temperature (deg C)
- Current (A)
- Duty cycles or PDM (%)

System Configuration Settings

The system configuration settings file name is SETTINGS.TXT and is stored in the DOWNLOAD folder.

A system configuration settings file automatically downloads each time a USB flash drive is inserted into the ADM. Use this file to back up system settings for future recovery or to easily replicate settings across multiple systems. Refer to the **Upload Procedure** on page 50 for instructions on how to use this file.

Custom Language File

The custom language file name is DISPTXT.TXT and is stored in the DOWNLOAD folder.

A custom language file automatically downloads each time a USB flash drive is inserted into the ADM. If desired, use this file to create a user-defined set of custom language strings to be displayed within the ADM.

The system is able to display the following Unicode characters. For characters outside of this set, the system will display the Unicode replacement character, which appears as a white question mark inside of a black diamond.

- U+0020 - U+007E (Basic Latin)
- U+00A1 - U+00FF (Latin-1 Supplement)
- U+0100 - U+017F (Latin Extended-A)
- U+0386 - U+03CE (Greek)
- U+0400 - U+045F (Cyrillic)

Create Custom Language Strings

The custom language file is a tab-delimited text file that contains two columns. The first column consists of a list of strings in the language selected at the time of download. The second column can be used to enter the custom language strings. If a custom language was previously installed, this column contains the custom strings. Otherwise the second column is blank.

Modify the second column of the custom language file as needed and then follow the **Upload Procedure** on page 50 to install the file.

The format of the custom language file is critical. The following rules must be followed in order for the installation process to succeed.

- Define a custom string for each row in the second column.

NOTE: If the custom language file is used, you must define a custom string for each entry in the DISPTXT.TXT file. Blank second-column fields will be displayed blank on the ADM.
- The file name must be DISPTXT.TXT.
- The file format must be a tab-delimited text file using Unicode (UTF-16) character representation.
- The file must contain only two columns, with columns separated by a single tab character.
- Do not add or remove rows to the file.
- Do not change the order of the rows.

Upload Procedure

Use this procedure to install a system configuration file and/or a custom language file.

1. If necessary, follow the **Download Procedure** to automatically generate the proper folder structure on the USB flash drive.
2. Insert USB flash drive into USB port of computer.
3. The USB flash drive window automatically opens. If it does not, open USB flash drive from within Windows Explorer.
4. Open GRACO folder.
5. Open the system folder. If working with more than one system, there will be more than one folder within the GRACO folder. Each folder is labeled with the corresponding serial number of the ADM (the serial number is on the back of the module).
6. If installing the system configuration settings file, place SETTINGS.TXT file into the UPLOAD folder.
7. If installing the custom language file, place DISPTXT.TXT file into the UPLOAD folder.
8. Remove USB flash drive from the computer.
9. Install USB flash drive into the ADM USB port.
10. The menu bar and USB indicator lights indicate that the USB is downloading files. Wait for USB activity to complete.
11. Remove USB flash drive from USB port.

NOTE: If the custom language file was installed, you can select the new language from the Language drop-down menu in **Advanced Setup Screen 1** on page 35.


Communications Gateway Module (CGM)

Connection Details

Fieldbus

Connect cables to fieldbus per fieldbus standards.

PROFINET



The Ethernet interface operates at 100M bit, full duplex, as required by PROFINET. The Ethernet interface is auto-polarity sensing and auto-crossover capable.

Network Status (NS)

State	Description	Comments
Off	Off-line	<ul style="list-style-type: none"> No power No connection with IO Controller
Green	On-line, (RUN)	<ul style="list-style-type: none"> Connection with IO Controller established IO Controller with RUN state
Flashing Green	On-line, (STOP)	<ul style="list-style-type: none"> Connection with IO Controller established IO Controller in STOP state


Module Status (MS)

State	Description	Comments
Off	Not initialized	No power or module in "SETUP" or "NW_INIT" state
Green	Normal operation	Diagnostic event(s) present
Flashing Green	Initialized, diagnostic event(s) present	Used by engineering tools to identify node on network
Red	Exception error	Module in state "EXCEPTION"
Red (1 flash)	Configuration error	Expected Identification differs from Real Identification
Red (2 flashes)	IP Address not set	Set IP address via system monitor or DNS server
Red (3 flashes)	Station Name not set	Set Station Name via system monitor
Red (4 flashes)	Major Internal Error	Cycle system power; replace module

Link/Activity (Link)

State	Description
Off	No Link, no communication present
Green	Link established, no communication present
Green, flashing	Link established, communication present

EtherNet/IP



The Ethernet interface operates at 100Mbit, full duplex, as required by PROFINET. The Ethernet interface is auto-polarity sensing and auto-crossover capable.

Network Status (NS)

State	Description
Off	No power or no IP address
Green	On-line, one or more connections established (CIP Class 1 or 3)
Flashing Green	On-line, no connections established
Red	Duplicate IP address, FATAL error
Flashing Red	One or more connections timed out (CIP Class 1 or 3)


Module Status (MS)

State	Description
Off	No power
Green	Controlled by a Scanner in Run state
Flashing Green	Not configured, or Scanner in Idle state
Red	Major fault (EXCEPTION-state, FATAL error etc.)
Flashing Red	Recoverable fault(s)

LINK/Activity (Link)

State	Description
Off	No link, no activity
Green	Link established
Flashing Green	Activity

DeviceNet



Network Status (NS)

State	Description
Off	Not online / No power
Green	On-line, one or more connections are established
Flashing Green (1 Hz)	On-line, no connections established
Red	Critical link failure
Flashing Red (1 Hz)	One or more connections timed-out
Alternating Red/Green	Self test


Module Status (MS)

State	Description
Off	No power or not initialized
Green	Initialized
Flashing Green (1 Hz)	Missing or incomplete configuration, device needs commissioning
Red	Unrecoverable Fault(s)
Flashing Red (1 Hz)	Recoverable Fault(s)
Alternating Red/Green	Self test

DeviceNet Connector (DC)

Pin	Signal	Description
1	V-	Negative bus supply voltage
2	CAN_L	CAN low bus line
3	SHIELD	Cable shield
4	CAN_H	CAN high bus line
5	V+	Positive bus supply voltage

PROFIBUS



TI11816A

Operation Mode (OP)

State	Description
Off	Not online / No power
Green	On-line, data exchange
Flashing Green	On-line, clear
Flashing Red (1 flash)	Parameterization error
Flashing Red (2 flashes)	PROFIBUS Configuration error

Status Mode (ST)

State	Description
Off	No power or not initialized
Green	Initialized
Flashing Green	Initialized, diagnostic event(s) present
Red	Exception error

PROFIBUS Connector (DC)

Pin	Signal	Description
1	-	-
2	-	-
3	B Line	Positive RxD/TxD, RS485 level
4	RTS	Request to send
5	GND Bus	Ground (isolated)
6	+5V Bus Output	+5V termination power (isolated)
7	-	-
8	A Line	Negative RxD/TxD, RS485 level
9	-	-
Housing	Cable Shield	Internally connected to the Anybus protective earth via cable shield filters according to the PROFIBUS standard.

Overview

The Communications Gateway Module (CGM) provides a control link between the E-Flo SP system and a selected fieldbus. This provides the means for report monitoring and control by external automation systems.

NOTE: The following system network configuration files are available at help.graco.com.

- EDS file: DeviceNet or Ethernet/IP fieldbus networks
- GSDML: PROFINET fieldbus networks

NOTE: See system manual for CGM installation.

E-Flo SP and PLC Connection Setup

Verify that the PLC parameters are set up correctly, see the Gateway Map table.

NOTE: If the PLC connection parameters are not setup correctly, the connection between the E-Flo SP and PLC will not be made. The standard gateway map that is shipped with the E-Flo SP is 2008382, and supports 6 pumps with one ADM and one CGM, or 1 tandem system with automatic cross over. There is a warm melt (heated) map (2008020) that can be retrieved from this link: [HTTP://help.graco.com/en/supply](http://help.graco.com/en/supply)

systems/E-Flo-SP-Fieldbus.html. See Appendix A for detailed information involving map configuration. The heated 2008020 map only supports signal heated ram with 1 ADM and 1 CGM, or 1 heated tandem with automatic cross over.

Gateway Map Table

Gateway Map: 2008382 for 6 Booster/6Ram/1Tandem		Gateway Map: 2008020for 1 Heated ram/1Tandem	
Comm. Format	Data-SINT	Comm. Format	Data-SINT
Input Assembly Instance:	100	Input Assembly Instance:	100
Input Size:	96	Input Size:	64
Output Assembly Instance:	150	Output Assembly Instance:	150
Output Instance Size:	62	Output Instance Size:	40

Available Internal Data

Unless stated otherwise, bytes are stored in each instance in little endian order (byte order within instance: most significant... least significant).

NOTE: Automation Outputs can be watched by the corresponding Automation Inputs to verify that the E-Flo SP received the data.

Gateway Map: 2008382 for 6 Booster/6Ram/1Tandem

Output from PLC / In to Graco E-Flo SP

Signal	Data Type	BIT	BYTE	Designator
SYS - Data Exchange Command	INT	0-15	0-1	‡
P1 - System Enable Request	Boolean	0	2-5	‡
P1 - PLC Control Lockout	Boolean	1		‡
P1 - Pump Enable	Boolean	2		‡
P1 - Pressure Control Enable	Boolean	3		‡
P1 - Flow Control Enable	Boolean	4		‡
P1 - Acknowledge / clear error	Boolean	5		‡
P1 - Prime Request	Boolean	6		❖
P1 - Recirculate Request	Boolean	7		†
P1 - Depressurize Request	Boolean	8		†
P1 - Cross Over Request	Boolean	9		‡
P1 - {Reserved Bits}	Boolean	10-31		

Signal	Data Type	BIT	BYTE	Designator
P1 - Pressure Target (xx.x bar)	INT	0-15	6-7	‡
P1 - Flow Target (xxx cc/min)	INT	0-15	8-9	‡
P1- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	10-11	‡
P2 (replication of bytes 25 above)	Boolean	0-15	12-15	x
P2 - Pressure Target (xx.x bar)	INT	0-15	16-17	•
P2 - Flow Target (xxx cc/min)	INT	0-15	18-19	•
P2- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	20-21	‡
P3 (replication of bytes 2-5 above)	Boolean	0-15	22-25	x
P3 - Pressure Target (xx.x bar)	INT	0-15	26-27	x
P3 - Flow Target (xxx cc/min)	INT	0-15	28-29	x
P3- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	30-31	x
P4 (replication of bytes 2-5 above)	Boolean	0-15	32-35	x
P4 - Pressure Target (xx.x bar)	INT	0-15	36-37	x
P4 - Flow Target (xxx cc/min)	INT	0-15	38-39	x
P4- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	40-41	x
P5 (replication of bytes 2-5 above)	Boolean	0-15	42-45	x
P5 - Pressure Target (xx.x bar)	INT	0-15	46-47	x
P5 - Flow Target (xxx cc/min)	INT	0-15	48-49	x
P5- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	50-51	x
P6 (replication of bytes 2-5 above)	Boolean	0-15	52-55	x
P6 - Pressure Target (xx.x bar)	INT	0-15	56-57	x
P6 - Flow Target (xxx cc/min)	INT	0-15	58-59	x
P6- Dynamic Setpoint Mode Target (xxx%)	INT	0-15	60-61	x
‡ - Applies to the entire system.				
† - Applies to the active pump.				
❖ - Applies to the active pump if the active pump is disabled, applies to the inactive pump if the active pump is enabled.				
x - Not applicable in Tandem systems.				
• - Used for Purging on Tandem systems.				

Input to PLC/Out From Graco E-Flo SP

Signal	Data Type	BIT	BYTE	Designator
P1 - Heartbeat	Boolean	0	0-3	†
P1 - PLC Control Lockout Active	Boolean	1		†
P1 - Automation Control ready	Boolean	2		†
SYS - System is enabled	Boolean	3		‡
P1 - Pump trying to move	Boolean	4		†
P1 - Pump is actually moving	Boolean	5		†
P1 - No Active alarms	Boolean	6		†
P1 - No Active deviations	Boolean	7		†
P1 - No Active advisories	Boolean	8		†
P1 - Prime Active	Boolean	9		†
P1 - Recirculation Active	Boolean	10		†
P1 - Depressurization Active	Boolean	11		†
P1 - Drum Low	Boolean	12		†
P1 - Drum Empty	Boolean	13		†
P1 - Not Primed	Boolean	14		†
P1 - Pump 1 active (Tandem systems only)	Boolean	15		‡
P1 - Dynamic Setpoint Mode Active	Boolean	16		†
P1 - (Reserved Bits)	Boolean	17		
P1 - Data Exchange Active Command	Boolean	0-15	4-5	†
P1 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	6-7	†
P1 - Outlet Pressure (xx.x bar)	INT	0-15	8-9	†
P1 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	10-11	†
P1 - Data Exchange Value	DINT	0-31	12-15	†
P2 (replication of bytes 0-3 above)				
P2 (replication of bytes 0-3 above)	Boolean	0-15	16-19	∅
P2 - Data Exchange Active Command	Boolean	0-15	20-21	∅
P2 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	22-23	∅
P2 - Outlet Pressure (xx.x bar)	INT	0-15	24-25	∅
P2 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	26-27	∅
P2 - Data Exchange Value	DINT	0-31	28-31	∅
P3 (replication of bytes 0-3 above)				
P3 (replication of bytes 0-3 above)	Boolean	0-15	32-35	x
P3 - Data Exchange Active Command	Boolean	0-15	36-37	x
P3 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	38-39	x
P3 - Outlet Pressure (xx.x bar)	INT	0-15	40-41	x
P3 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	42-43	x
P3 - Data Exchange Value	INT	0-31	44-47	x
P4 (replication of bytes 0-3 above)				
P4 (replication of bytes 0-3 above)	Boolean	0-15	48-51	x
P4 - Data Exchange Active Command	Boolean	0-15	52-53	x
P4 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	54-55	x
P4 - Outlet Pressure (xx.x bar)	INT	0-15	56-57	x
P4 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	58-59	x

Signal	Data Type	BIT	BYTE	Designator
P4 - Data Exchange Value	DINT	0-31	60-63	x
P5 (replication of bytes 0-1 above)				
P5 - Data Exchange Active Command	Boolean	0-15	64-67	x
P5 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	70-71	x
P5 - Outlet Pressure (xx.x bar)	INT	0-15	72-73	x
P5 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	74-75	x
P5 - Data Exchange Value	DINT	0-31	76-79	x
P6 (replication of bytes 0-1 above)				
P6 - Data Exchange Active Command	Boolean	0-15	84-85	x
P6 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	86-87	x
P6 - Outlet Pressure (xx.x bar)	INT	0-15	88-89	x
P6 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	90-91	x
P6 - Data Exchange Value	DINT	0-31	92-95	x
† - Conveys the status of the active pump only. ◇ - Conveys the status of the inactive pump only. ‡ - The status of both pumps are taken into account. x - Not applicable in Tandem systems.				

Gateway Map: 2008020 for 1 Heated ram/1Tandem

Output From PLC to E-Flo SP Warm Melt

Signal	Data Type	BIT	BYTE	Designator
SYS - Pump Data Exchange Command	INT	0-15	0-1	‡
P1 -System Enable Request	Boolean	0	2-5	‡
P1 - PLC Control Lockout	Boolean	1		‡
P1 - Pump Enable	Boolean	2		‡
P1 - Pressure Control Enable	Boolean	3		‡
P1 - Flow Control Enable	Boolean	4		‡
P1 - Acknowledge / clear error	Boolean	5		‡
P1 - Prime Request	Boolean	6		❖
P1 - Recirculate Request	Boolean	7		†
P1 - Depressurize Request	Boolean	8		†
P1 - Cross Over Request	Boolean	9		‡
P1 - {Reserved Bits}	Boolean	10-31		
P1 - Pressure Target (xx.x bar)	INT	0-15	6-7	‡
P1 - Flow Target (xxx cc/min)	INT	0-15	8-9	‡
P1 - Dynamic Setpoint Mode Target (xxx%)	INT	0-15	10-11	‡
P2 - (replication of bytes 2-5 above)				
Pressure Target (xx.x bar)	INT	0-15	16-17	•
Flow Target (xxx cc/min)	INT	0-15	18-19	•
Dynamic Setpoint Mode Target (xxx%)	INT	0-15	20-21	x

Signal	Data Type	BIT	BYTE	Designator
SYS - Heat Enabled Request	Boolean	0	22-23	‡
SYS - Heat Disabled Request	Boolean	1		‡
SYS - Heat Enable PLC Control	Boolean	2		‡
SYS - Heat {Reserved Bits}	Boolean	3-15		‡
H1 - Heat On Request	Boolean	0	24-25	
H1 - Heat Off Request	Boolean	1		
H1 - Heat Setback Request	Boolean	2		†
H1 - Acknowledge / Clear Heat Errors	Boolean	3		†
H1 - {Reserved Bits}	Boolean	4-15		†
H1 - Data Exchange Command	INT	0-15	26-27	†
H1 - Data Exchanged Command Desired Value	DINT	0-31	28-31	†
H2 - (Replication of bytes 24-25 above)	Boolean	0-15	32-33	★
H2 - Data Exchange Command	INT	0-15	34-35	★
H2 - Data Exchanged Command Desired Value	DINT	0-31	36-39	★

‡ - Applies to the entire system.
 † - Applies to the active pump.
 ★ - Applies to the inactive pump.
 ❖ - Applies to the active pump if the active pump is disabled, applies to the inactive pump if the active pump is enabled.
 x - Not applicable in Tandem systems.
 • - Used for Purging on Tandem systems.

Input From E-Flo SP Warm Melt to PLC

Signal	Data Type	BIT	BYTE	Designator
P1 - Heartbeat	Boolean	0	0-3	†
P1 - PLC Control Lockout Active	Boolean	1		†
P1 - Automation Control ready	Boolean	2		†
SYS - System is enabled	Boolean	3		†
P1 - Pump trying to move	Boolean	4		†
P1 - Pump is actually moving	Boolean	5		†
P1 - No Active alarms	Boolean	6		†
P1 - No Active deviations	Boolean	7		†
P1 - No Active advisories	Boolean	8		†
P1 - Prime Active	Boolean	9		†
P1 - Recirculation Active	Boolean	10		†
P1 - Depressurization Active	Boolean	11		†
P1 - Drum Low	Boolean	12		†
P1 - Drum Empty	Boolean	13		†
P1 - Not Primed	Boolean	14		†
P1 - Pump 1 active (Tandem systems only)	Boolean	15		†
P1 - Dynamic Setpoint Mode Active	Boolean	16		†
P1 - {Reserved Bits}	Boolean	17-31	†	

Signal	Data Type	BIT	BYTE	Designator
P1 - Data Exchange Active Command	INT	0-15	4-5	†
P1 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	6-7	†
P1 - Outlet Pressure (xx.x bar)	INT	0-15	8-9	†
P1 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	10-11	†
P1 - Dynamic Setpoint Mode Value (xxx %)	INT	0-15	12-13	†
P1 - Data Exchange Value	DINT	0-31	14-17	★
P2 - (Replication of bytes 0-3)	Boolean	0-31	18-21	★
P2 - Data Exchange Active Command	INT	0-15	22-23	★
P2 - Actual Pump Flow Rate (xxx cc/min)	INT	0-15	24-25	★
P2 - Outlet Pressure (xx.x bar)	INT	0-15	26-27	★
P2 - Inlet Pressure (or filter pressure) (xx.x bar)	INT	0-15	28-29	★
P2 - Dynamic Setpoint Mode Value (xxx %)	INT	0-15	30-31	★
P2 - Data Exchange Value	DINT	0-31	32-35	★
H1 - Heartbeat	Boolean	0	36-39	†
H1 - Heat Status Enables	Boolean	1		†
H1 - PLC Lockout Active	Boolean	2		†
'H1 - Heat On	Boolean	3		†
'H1 - Heat Warming Up	Boolean	4		†
'H1 - Heat At Temperature	Boolean	5		†
H1 - Heat in Heat Soak	Boolean	6		†
H1 - Heat in Setback	Boolean	7		†
H1 - Heat Off	Boolean	8		†
H1 - No Heat Module Active Alarms	Boolean	9		†
H1 - No Heat Module Active Deviations	Boolean	10		†
H1 - No Heat Module Active Advisories	Boolean	11		†
H1 - No Heat Zone Active Alarms	Boolean	12		†
H1 - No Heat Zone Active Deviations	Boolean	13		†
H1 - No Heat Zone Active Advisories	Boolean	14		†
H1 - Heat Idle Timeout Happened	Boolean	15		†
H1 - {Reversed Bits}	Boolean	16-31	†	
H1 -Heat Soak Remaining Time (xxx sec)	INT	0-15	40-41	†
H1 - Heat Idle Remaining Time (xxx sec)	INT	0-15	42-43	†
H1 - Heat Data Exchange Command	INT	0-15	44-45	†
H1 - Heat Data Exchange Value	DINT	0-31	46-49	†
H2 - (Replication of bytes 36-39)	Boolean	0	50-53	★
H2 - Heat Soak Remaining Time (xxx sec)	INT	0-15	54-55	★
H2 - Heat Idle Remaining Time (xxx sec)	INT	0-15	56-57	★
H2 - Heat Data Exchange Command	INT	0-15	58-59	★
H2 -Heat Data Exchange Value	DINT	0-31	60-63	★

Signal	Data Type	BIT	BYTE	Designator
‡ - Applies to the entire system. † - Applies to the active pump. ★ - Applies to the inactive pump. ❖ - Applies to the active pump if the active pump is disabled, applies to the inactive pump if the active pump is enabled. x - Not applicable in Tandem systems. • - Used for Purging on Tandem systems.				

Data Exchange

NOTE: Please reference the timing diagrams on the timing of the signals to utilize the Data Exchange.

The Data Exchange is a condensed structure that is used to read a number of different variables in one data location. If multiple are needed they must be cycled through.

The Data Exchange is a method of:

1. Setting "SYS – Data Exchange Command" a 16 bit integer (byte 0-1).
2. Reading - "P1 – Data Exchange Active Command" a 16 bit integer (byte 2-3).
3. Reading - "P1 – Data Exchange Value" a 32 bit integer (byte 10-13).

Example:

How to read the cycle rate on pump 2 through the Data Exchange.

1. Set bytes 0-1 to 9 (base 10).
2. Read bytes 16-7 to ensure that it reads 9 (base 10).
3. Read bytes 24-27 to get the active cycle rate of pump 2.

E-Flo SP Data Exchange

Command Value (base 10 decimal)	Name	Units / Format
0	Active Alarms	Bitfield
1	Active Deviations	Bitfield
2	Active Advisories	Bitfield
3	Pump Position	Percent Stroke (0 = bottom, 100 = top)
4	Driver Lifetime Cycles	Cycles
5	Driver Resettable Cycles	Cycles
6	Pump Resettable Cycles	Cycles
7	Platen Resettable Cycles	Cycles
8	Remaining Drum Volume	cc's
9	Cycle Rate	1/10 CPM
10	Fluid Filter Delta	1/10 bar
11	Driver Cycles by Thrust, 0 - 9% (lifetime)	Cycles
12	Driver Cycles by Thrust, 10 - 19% (lifetime)	Cycles
13	Driver Cycles by Thrust, 20 - 29% (lifetime)	Cycles
14	Driver Cycles by Thrust, 30 - 39% (lifetime)	Cycles
15	Driver Cycles by Thrust, 40 - 49% (lifetime)	Cycles
16	Driver Cycles by Thrust, 50 - 59% (lifetime)	Cycles
17	Driver Cycles by Thrust, 60 - 69% (lifetime)	Cycles
18	Driver Cycles by Thrust, 70 - 79% (lifetime)	Cycles
19	Driver Cycles by Thrust, 80 - 89% (lifetime)	Cycles
20	Driver Cycles by Thrust, 90 - 100% (lifetime)	Cycles
21	Driver Cycles by Thrust, 0 - 9% (since last reset)	Cycles
22	Driver Cycles by Thrust, 10 - 19% (since last reset)	Cycles
23	Driver Cycles by Thrust, 20 - 29% (since last reset)	Cycles
24	Driver Cycles by Thrust, 30 - 39% (since last reset)	Cycles
25	Driver Cycles by Thrust, 40 - 49% (since last reset)	Cycles
26	Driver Cycles by Thrust, 50 - 59% (since last reset)	Cycles
27	Driver Cycles by Thrust, 60 - 69% (since last reset)	Cycles
28	Driver Cycles by Thrust, 70 - 79% (since last reset)	Cycles
29	Driver Cycles by Thrust, 80 - 89% (since last reset)	Cycles
30	Driver Cycles by Thrust, 90 - 100% (since last reset)	Cycles
31	Pressure Target	1/10 bar
32	Flow Target	cc/min
33	Dynamic Setpoint Mode Target	Percentage

Heat Data Exchange

E-Flo SP Heat Data Exchange

Command Value (Hexadecimal)	Name	Units / Format
0x0000	AMZ Main Module Alarms	Bitfield
0x0001	AMZ Main Module Deviations	Bitfield
0x0002	AMZ Main Module Advisories	Bitfield
0x0003	AMZ Expansion Active Module Alarms	Bitfield
0x0004	AMZ Expansion Active Module Deviations	Bitfield
0x0005	AMZ Expansion Active Module Advisories	Bitfield
0x0006	I/O Daughter Board Active Module Alarms	Bitfield
0x0007	I/O Daughter Board Active Module Deviations	Bitfield
0x0008	I/O Daughter Board Active Module Advisories	Bitfield
0x0009	Drum/Platen Size	Enum Number: 0:20 Liters 1:200 liters
0x000A	Heat Inactive Timeout	xx Minutes
0x000B	AMZ Line Voltage, Leg #1	xxx.x Volts
0x000C	AMZ Line Voltage, Leg #2	xxx.x Volts
0x000D	AMZ Line Voltage, Leg #3	xxx.x Volts
0x000E	AMZ Expansion Line Voltage, Leg #1	xxx.x Volts
0x000F	AMZ Expansion Line Voltage, Leg #2	xxx.x Volts
0x0010	AMZ Expansion Line Voltage, Leg #3	xxx.x Volts
Transition to Zones		
0xZ00	AMZ Active Zone #Z Alarms	Bitfield
0xZ01	AMZ Active Zone #Z Deviations	Bitfield
0xZ02	AMZ Active Zone #Z Advisorie	Bitfield
0xZ03	Zone #Z Heat State	Bit Number: 0: Heat Zone 1: Heat Zone On 2. Heat Zone Warming up 3. Heat Zone At Temperature 4. Heat Zone is Heat Soaking 5. Heat Zone is in Setback 6. Heat Zone has a Deviation 7. Heat Zone has an Alarm
0xZ05	Zone #Z Actual Temperature	xx.x deg C
0xZ06	Zone #Z Actual Current Usage	xx.xxx A
0xZ07	Zone #Z Soak Time Remaining	xxx %
0xZ08	Zone #Z Setpoint Temperature	xx seconds
0xZ09	Zone #Z Setback Temperature	xx deg C
0xZ0A	Zone #Z Heat Soak Time	xx deg C
0xZ0B	Zone #Z Heat Enabled/ Installed State	xx minutes
0xZ0C	Zone #Z Other Tandem Heat Enabled/Installed State	Boolean

Command Value (Hexadecimal)	Name	Units / Format
0xZ0D	Zone #Z Type	Boolean
0xZ0E	Zone #Z High Temperature Alarm Offset	Enum Number: 0: Hose 1: Valve 2: Manifold 3: PGM 4: Flowmeter 5: Press Regulator 6: Other 7: Pump 8: Platen
0xZ0F	Zone #Z High Temperature Deviation Offset	xx deg C
0xZ10	Zone #Z Low Temperature Alarm Offset	xx deg C
0xZ11	Zone #Z Low Temperature Deviation Offset	xx deg C
0xZ12	Zone #Z Heat Rate Options	Enum Number: 0: Normal Rate 1: Slow Rate

NOTES:

- The (Z) in the command value corresponds to the zone you are wanting to read/write. See Zone Z identification table to cross reference the number needed to identify the data exchange element for the specific zone.
- If an invalid command is requested, a invalid value will be return to the Automation Outputs Data Exchange Elements

Zone Z Identification Table

Zone Z's hex Number (corresponds to the Z location)	Actual Zone Number
0x01	Zone 1
0x02	Zone 2
0x03	Zone 3
0x04	Zone 4
0x05	Zone 5
0x06	Zone 6
0x07	Zone 7
0x08	Zone 8
0x09	Zone 9
0x0A	Zone 10
0x0B	Zone 11
0x0C	Zone 12
0x0D	Zone 13
0x0E	Zone 14
0x0F	Zone 15
0x10	Zone 16
0x11	Zone 17


Timing Diagrams

NOTES:

It is recommended to introduce a 50 ms delay between each automation signal


Automation Control Ready” in the following diagrams represents the following:

- System is enabled
- No active alarms
- ADM is in “Remote Mode”




Flow Mode

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)




NOTES:

* Can be enabled at once. Disabling any will stop the pump.


**If Dynamic Setpoint Percentage is enabled, value needs to be sent in order for the machine to know what percentage to run at when the dynamic setpoint mode is active

Pressure Flow Combined

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)




NOTES:

* Can be enabled at once. Disabling any will stop the pump. (Must have pressure and/or flow enabled to run.)


**If Dynamic Setpoint Percentage is enabled, value needs to be sent in order for the machine to know what percentage to run at when the dynamic setpoint mode is active

Prime

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)




NOTES:
* Can be enabled at once.
† Both must be enabled.

Recirculate


To utilize the recirculate feature:

- Must have a ram or tandem system
- Fluid Solenoid kit must be installed and enabled on the ADM setup screen
- ADM is in the remote mode

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)



NOTES:


* Can be enabled at once. Pump enable must be last.

Depressurization


To utilize the recirculate feature:

- Must have a ram or tandem system
- Fluid Solenoid kit must be installed and enabled on the ADM setup screen
- ADM is in the remote mode
- Pump crossover, request, prime request or recirculation cannot be active

Automation Inputs (E-Flo SP Outputs)




Automation Outputs (E-Flo SP Inputs)



System Enable Request

Automation Inputs (E-Flo SP Outputs)




Automation Outputs (E-Flo SP Inputs)



ACK-Clear Error

Automation Inputs (E-Flo SP Outputs)




Automation Outputs (E-Flo SP Inputs)



Crossover

- To utilize the crossover feature:
- Must have a tandem system
 - ADM is in the remote mode
 - Prime request , recirculation request, and depressurization request cannot be active

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)




NOTES:


Once the crossover occurs and the other pump becomes the active pump, drop the crossover request immediately.

Data Exchange

Automation Inputs (E-Flo SP Outputs)




Automation Outputs (E-Flo SP Inputs)




Power Reset

Automation Inputs (E-Flo SP Outputs)



Automation Outputs (E-Flo SP Inputs)




NOTES:

* The valve will remain in it's current state when shut down. A change in state at 1 Hz should be used to detect power.


** Once an offline is detected all automation outputs should be cleared to (0) so that when the system comes back online, the PLC can initiate the corresponding variables needed to restart the pumps.

Heat Overall CGM

Automation Inputs (E-Flo SP Warm Melt Outputs)



Automation Outputs (E-Flo SP Warm Melt Inputs)




NOTES:

* "System Disable Request" and "Module Data Exchange Command" will be accepted without the "PLC Lockout/Control" set high. Any other automation output instance needs to have the "PLC Lockout/Control" set high for the automation output instance to be accepted by the Eflo SP warm melt controller.

Heat Module Ack-Clear Error

Automation Inputs (E-Flo SP Warm Melt Outputs)



Automation Outputs (E-Flo SP Warm Melt Inputs)



NOTES:


*If errors are not successfully resolved/fixd the bit will reminder high, once the system has successfully seen that the error has been resolved, the bit will go low.

Process can be repeated for deviations and advisories.

- Only need to check if the expansion module is installed.

Heat Zone Ack-Clear Error

Automation Inputs (E-Flo SP Warm Melt Outputs)



Automation Outputs (E-Flo SP Warm Melt Inputs)




NOTES:


- + Each zone has to be scanned for errors before send the Acknowledge/clear errors bit.
- * If errors are not successfully resolved/fixd the bit will reminder high, once the system has successfully seen that the error has been resolved, the bit will go low.
- Process can be repeated for deviations and advisories.

CGM Heat Data Exchange

Automation Inputs (E-Flo SP Warm Melt Outputs)



Automation Outputs (E-Flo SP Warm Melt Inputs)



Error Code Handling

As indicated in the Available Internal Data section, and the Ack-Clear Internal Data timing diagram, any pump (P1 - P6) error condition (Alarm, Deviation or Advisory) is reported to the controlling PLC using the Data Exchange Interface. As an example, if the PLC wants to know if an active deviation exists for Pump 2, the PLC needs to write a 1 to the PLC output bytes 0 and 1. Then read the P2 - Data Exchange Value (PLC input bytes 24-27) after the P2 - Data Exchange Active Command value equals 1 (requested command). If the value read by the Data Exchange Value equals 0, there are no active deviations for that pump location.

The following actions should be taken if a pump reports a non-zero value.

1. The PLC requested if an alarm condition existed for pump 3, by sending a 0 to PLC output bytes 0 and 1, then reading the P3 - Data exchange Value (PLC input bytes 38-41) after the P3 - Data Exchange Active Command (PLC input bytes 30-31) reported a 0.
2. The P3 pump reports a 514 decimal (0 x 0202 hexadecimal, or base 16) on the P3 - Data Exchange Value location 38-41 (Input bytes 38-41).
3. As indicated in the **Active Alarm Descriptions** table on page 77, the 514 reported indicates a V4M_ and a A4D condition ($512 + 2 = 514$) exists for the P3 pump.
4. To acknowledge and clear the alarm condition, the PLC will need to implement the items outlined in the Ack - Clear Error timing diagram, by activating the Acknowledge / Clear Errors bit for P3 pump (PLC output byte 15, bit 5).
5. The pop-up window for the error conditions will be cleared. If both conditions are removed, the No Active Alarms bit from the P3 pump (E-flo output byte 28 bit 6) will be set back to high and the P3 - Data Exchange Value from the P3 pump will be set to 0. If only the A4D_ condition is cleared, the No Active Alarms bit will remain low, and the data exchange value will change from 514 to 2.

Active Alarm Descriptions

Data Exchange Command Value = 0

Data Exchange Values Bit Assignments	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit Code on ADM	Exchange Value Symbol	Error Description
0	1	1	V1M_	3MCP_ALARM_UNDE R_VOLTAGE	Supplied bus voltage is below minimum acceptable limits
1	2	2	V4M_	3MCP_ALARM_OVER _VOLTAGE	Supplied bus voltage is above maximum acceptable limits
2	4	4	T4M_	3MCP_ALARM_MOT OR_TEMPERATURE	Temperature of driver motor is too hot
3	8	8	T4C_	3MCP_ALARM_BOA RD_TEMPERATURE	Temperature of the Control PCB is too hot
4	16	10	WBD_	3MCP_ALARM_ENC ODER	Encoder or hall sensor not communicating with driver logic
5	32	20	WMN_	3MCP_ALARM_VERS ION_MISMATCH	Communication is lost between the 2 micro-controllers in the MCM
6	64	40	CCN_	3MCP_ALARM_IPC_ COMMUNICATION	Problem with the MCM hardware
7	128	80	A4N_	3MCP_ALARM_BOA RD_HARDWARE	Motor current exceeds maximum allowable limit
8	256	100	WMC_	3MCP_ALARM_BOA RD_EXCEPTION	MCM Module reset due to exception in the software
9	512	200	A4D_	3MCP_ALARM_SW_ CURRENT_ERROR	Motor current exceeds maximum allowable limit
10	1024	400	DD4_	3MCP_ALARM_PUM P_DIVING	Pump diving detected
11	2048	800	P4C_	3MCP_ALARM_PRES SURE_HIGH	Measure outlet pressure greater than desired amount plus tolerance

Data Exchange Values Bit Assignments	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit Code on ADM	Exchange Value Symbol	Error Description
12	4096	1000	P1C_	3MCP_ALARM_PRES SURE_LOW	Measured outlet pressure less than desired amount minus tolerance
13	8192	2000	F4D_	3MCP_ALARM_FLOW_HIGH	Measure flow greater than desired flow rate plus tolerance
14	16384	4000	F1D_	3MCP_ALARM_FLOW_LOW	Measured flow less than desired flow rate minus tolerance
15	32768	8000	P6D_	3MCP_ALARM_PRES SURE_OUTLET_XDR	Outlet pressure transducer fault or not connected
16	65536	10000	DKC_	3MCP_ALARM_CROSSOVER	Crossover error in tandem system
17	131072	20000	L1C_	3MCP_ALARM_DRUM_EMPTY	Drum is empty
18	262144	40000	DB1_	3MCP_ALARM_NOT_PRIMED	Pump has not been primed since last drum empty
19	524288	80000	CCG_	3MCP_ALARM_FIELD BUS	Not communication with Gateway/Fieldbus module
20	1048576	100000	CAC_	3MCP_ALARM_COMM_ADM	No communication between ADM module and MCM/Pump
21	2097152	200000	CAC_	3MCP_ALARM_COMM_HEAT_NOT_READ Y	Heat module is not up to or the heat is not turned on

Active Deviation Descriptions

Data Exchange Command Value = 1

Data Exchange Values Bit Assignments	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code on ADM	Exchange Value Symbol	Error Description
0	1	1	T2D_	3MCP_DEVIATION_LOW_TEMPERATURE	Motor temperature thermistor disconnected
1	2	2	T3D_	3MCP_DEVIATION_OVER_TEMPERATURE	Current supplied to motor reduced to lower electronics temperature
2	4	4	WSC_	3MCP_DEVIATION_ENCODER_CALIBRATION	Encoder calibration information not found
3	8	8	DD3_	3MCP_DEVIATION_PUMP_DIVING	Pump diving detected
4	16	10	P3C_	3MCP_DEVIATION_PRESSURE_HIGH	Measure outlet pressure greater than desired amount plus tolerance
5	32	20	P2C_	3MCP_DEVIATION_PRESSURE_LOW	Measure outlet pressure less than desired amount minus tolerance
6	64	40	F3D_	3MCP_DEVIATION_FLOW_HIGH	Measured flow greater than desired flow rate plus tolerance
7	128	80	F2D_	3MCP_DEVIATION_FLOW_LOW	Measured flow less than desired flow rate minus tolerance
8	265	100	P6D_	3MCP_DEVIATION_PRESSURE_OUTLET_XDR	Outlet pressure transducer not connected
9	512	200	L2C_	3MCP_DEVIATION_DRUM_LOW	Drum material is low
10	1024	400	DB2_	3MCP_DEVIATION_NOT_PRIMED	Pump has not been primed since last empty

Active Advisories Descriptions

Data Exchange Command Value = 2

Data Exchange Values Bit Assignments	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code on ADM	Exchange Value Symbol	Error Description
0	1	1	MBD_	3MCP_ADVISORY_DRIVER_MAINTENANCE	Maintenance due for driver (MCM)
1	2	2	MAD_	3MCP_ADVISORY_PUMP_MAINTENANCE	Maintenance due for pump
2	4	4	MLC_	3MCP_ADVISORY_REBUILD_PLATEN_SEALS	Maintenance due for platen seals
3	8	8	MG2_	3MCP_ADVISORY_FILTER_PRESSURE_DROP_LOW	Low pressure drop detected, replace fluid filter
4	16	10	MG3_	3MCP_ADVISORY_FILTER_PRESSURE_DROP_HIGH	High filter pressure detected, blockage detected

AMZ MLZP Board Active Module Alarms

Heat - Data Exchange Main Module Command Value = 0x0 or Heat - Data Exchange Expansion Module Command Value = 0x3.

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
0	1	1	V6H_	Wiring Error H_	The wiring is invalidated from what the AMZ is expecting
1	2	2	V4H_	High Voltage H_	The incoming power is above maximum acceptable limit

AMZ MLZP Board Active Module Deviation

Heat - Data Exchange Main Module Command Value = 0x1 or Heat - Data Exchange Expansion Module Command Value = 0x4

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
0	1	1	V2H_	Low Voltage H_	The incoming power is below minimum acceptable limit

AMZ MLZP Board Active Module Advisories

Heat - Data Exchange Main Module Command Value = 0x2 or Heat - Data Exchange Expansion Module Command Value = 0x5

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
Table Contents Pending Future Development					

I/O Daughter Board Active Module Alarms

Heat - Data Exchange Command Value = 0x4.

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
0	1	1	TA1_	Heat Zone Offline Z1 H_	The heat zone is offline
1	2	2	TA2_	Heat Zone Offline Z2 H_	The heat zone is offline
2	4	4	TA3_	Heat Zone Offline Z3 H_	The heat zone is offline
3	8	8	TA4_	Heat Zone Offline Z4 H_	The heat zone is offline
4	16	10	TA5_	Heat Zone Offline Z5 H_	The heat zone is offline
5	32	20	TA6_	Heat Zone Offline Z6 H_	The heat zone is offline
6	64	40	TA7_	Heat Zone Offline Z7 H_	The heat zone is offline

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
7	128	80	TA8_	Heat Zone Offline Z8 H_	The heat zone is offline
8	256	100	TA9_	Heat Zone Offline Z9 H_	The heat zone is offline
9	512	200	TAA_	Heat Zone Offline Z10 H_	The heat zone is offline
10	1024	400	TAB_	Heat Zone Offline Z11 H_	The heat zone is offline
11	2048	800	TAC_	Heat Zone Offline Z12 H_	The heat zone is offline
12	4096	1000	TAD_	Heat Zone Offline Z13 H_	The heat zone is offline
13	8192	2000	TAE_	Heat Zone Offline Z14 H_	The heat zone is offline
14	16384	4000	TAF_	Heat Zone Offline Z15 H_	The heat zone is offline
15	32678	8000	TAG_	Heat Zone Offline Z16 H_	The heat zone is offline
16	65536	10000	TAH_	Heat Zone Offline Z17 H_	The heat zone is offline
17	131072	20000	CCH_	Fieldbus Comm. Error H_	Communication lost between AMZ DB and Gateway
18	262144	40000	CBV_	ADM Comm. Error H_	Communication lost between AMZ DB and ADM

I/O Daughter Board Active Module Deviation

Heat - Data Exchange Command Value = 0x5

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
Table Contents Pending Future Development					

I/O Daughter Board Active Module Advisories

Heat - Data Exchange Command Value = 0x6

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
Table Contents Pending Future Development					

AMZ Active Zone #Z Alarms

Heat - Data Exchange Command Value = 0xZ00

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
0	1	1	T4_	High Temperature H_Z_	The zone temperature has exceeded the setpoint
1	2	2	T4_	High Temperature H_Z_	The zone temperature has exceeded the setpoint
2	4	4	T1_	Low Temperature H_Z_	Temperature of the zone is below the setpoint
3	8	8	T8_	No Temperature Rise H_Z_	Temperature of the zone is below the setpoint
4	16	10	T9_	Over Temperature Switch H_Z_	The zone temperature has not changed
5	32	20	A4_	High Current H_Z_	The zones switch has an over temperature reading
6	64	40	A1_	Low Current H_Z_	Heater current exceeds maximum allowed value
7	128	80	A8_	No Current H_Z_	Power is not getting to heating element
8	256	100	A7_	Unexpected Current H_Z_	Heat current has an unexpected current flow
9	512	200	T6_	Sensor Error H_Z_	The zone has no reading from RTD

AMZ Active Zone #Z Deviation

Heat - Data Exchange Command Value = 0xZ01

Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
Table Contents Pending Future Development					

I/O Daughter Board Active Module Advisories


Heat - Data Exchange Command Value = 0x6


Data Exchange Values Bit Assignment	Resultant Value from Bit Assignment (Base 10)	Resultant Value from Bit Assignment (Base 16)	4 Digit code	Exchange Description	Error Description
0	1	1	T3_	High Temperature H_Z_	The zone temperature has exceeded the setpoint
1	2	2	T3_	High Temperature H_Z_	The zone temperature has exceeded the setpoint
2	4	4	T2_	Low Temperature H_Z_	Temperature of the zone is below the setpoint
4	16	10	A3_	High Current H_Z_	Heater current exceeds maximum allowed valuet
5	32	20	A2_	Low Current H_Z_	Heater current is below the minimum allowed value

Setup

Gateway Screens

The Gateway screens are used to configure the fieldbus. These screens are shown only if a CGM is correctly installed in your system. See your system manual for proper installation.

1. With the system on and enabled, press  to access the Setup screens.
2. Press the left arrow key twice to navigate to the main Gateway screen.



PROFIBUS Fieldbus Screens

These screens are shown only if a PROFIBUS Fieldbus CGM is installed.


Screen 1

This screen enables the user to set the device address, install date, location tag, function tag, and description.



Screen 2

This screen displays the hardware revision, system serial number, and data map identification information.



PROFINET Fieldbus Screens

These screens are shown only if a PROFINET Fieldbus CGM is installed.

Screen 1

This screen enables the user to set the IP Address, DHCP settings, subnet mask, gateway, and DNS information.

02/08/19 12:12 | System | Fieldbus | Advanced

Active | No Active Errors

PROFINET

IP Address: 192|168|000|001

DHCP: No

Subnet Mask: 255|255|255|000

Gateway: 000|000|000|000

DNS 1: 000|000|000|000

DNS 2: 000|000|000|000

Screen 2

This screen enables the user to set the station name, install date, location tag, function tag, and description.

02/08/19 12:12 | System | Fieldbus | Advanced

Active | No Active Errors

PROFINET

Station Name: E-Flo SP

Install Date: 2019-02-07 08:00

Location Tag: CELL 1

Function Tag: E-Flo SP

Description: SUPPLY PUMP

Screen 3

This screen displays the hardware revision, system serial number, and data map identification information.

02/08/19 12:13 | System | Fieldbus | Advanced

Active | No Active Errors

PROFINET

Hardware Revision: 0001

System Serial #: 06201222

Map ID: 00002

Map Name: E-Flo SP

Map Revision: 001.001


Map Date: 11/20/18

EtherNet/IP Fieldbus Screens

These screens are shown only if an EtherNet/IP Fieldbus CGM is installed.


Screen 1

This screen enables the user to set the IP address, DHCP settings, subnet mask, gateway, and DNS information.



Screen 2

This screen displays the hardware revision, system serial number, and data map identification information.



DeviceNet Fieldbus Screen

This screen is shown only if a DeviceNet Fieldbus CGM is installed.

This screen enables the user to set the device address and baud rate, as well as view the hardware revision, system serial number, and data map identification information.




I/O Integration

Connector	Pin	Input/Output	Description
1	-	Communications and 24 Vdc Power	GCA CAN port. Connection to ADM or CGM
2	-	Communications and 24 Vdc Power	GCA CAN port. Connection to ADM or CGM
3	1	24Vdc Digital Output: - 24V is ON - 0V is OFF	24 V power for Level sensor(s)
	2	24Vdc Digital Input: -> 4V is ON -< 1V is OFF	Empty Level Sensor Input: When the sensor detects an empty drum, the input pin will be OFF.
	3	Ground / Return	Ground / Return
	4	24Vdc Digital Input: -> 4V is ON -< 1V is OFF	Low Level Sensor Input: When the sensor detects a low drum, the input pin will be OFF.
	5	Not Used	-----
Booster and Ram System without Fluid Solenoids Installed:			
4	1	0-10 V Analog In	Pressure Command: Analog reading is proportional to the outlet pressure target. A reading of 0V sets outlet pressure to 0. A reading of 10V sets the outlet pressure to the maximum determined by the volume of the pump lower.
	2	0-10 V Analog In	Flow Command: Analog reading is proportional to the outlet flow rate. A reading of 0V sets the flow rate to 0. A reading of 10V sets the flow rate to the maximum determined by the volume of the pump lower and the maximum cycle rate.
	3	Ground / Return	Ground / Return
	4	+5 Vdc Supply	Power
	5	24Vdc Digital Input: -> 4V is ON -< 1V is OFF	System Enable: When the digital input is ON, the system is active, and when the digital input is OFF, the system is inactive.
	6	24Vdc Digital Input: -> 4V is ON -< 1V is OFF	Pressure Mode Enable: When the digital input is ON, pressure mode is enabled, and when the digital input is OFF, pressure mode is disabled.
	7	24Vdc Digital Input: -> 4V is ON -< 1V is OFF	Flow Mode Enable: When the digital input is ON, flow mode is enabled, and when the digital input is OFF, flow mode is disabled. Or: Dynamic Setpoint Mode: When the dynamic setpoint is enabled on Pump Setting 6 - Drum Settings, this pin will be used to control the setpoint that the system is running at. The dynamic setpoint mode is an inverted signal so that when the digital input is OFF the system will run at percentage of the setpoint and when the digital input is ON, it will run at the normal setpoint.
	8	24 Vdc Digital Output: -24V is ON -0V is OFF	Ready / Fault Detected: When the digital output is ON, the pump is ready for operation, and when the digital output is OFF, the pump is in an error state.
Tandem and Ram System with Fluid Solenoids Installed:			
4	1	Not Used	-----
	2	Not Used	-----
	3	Ground / Return	Ground / Return
	4	Not Used	-----
	5	Not Used	-----
	6	Not Used	-----
	7	24 Vdc Digital Output: -24V is ON -0V is OFF	Solenoid Enable: When the digital output is ON, the fluid solenoid is enabled, and when the digital output is OFF, fluid solenoid is disabled.
	8	Not Used	-----

5	-	Analog Differential Input	Outlet Pressure Transducer Port
6	-	Analog Differential Input	Inlet Pressure Transducer Port or either fluid filter pressure transducers in tandem systems.

NOTE: See **Connector Identification** on page 89.

Connector Identification



Appendix A - Obsolete E-Flo SP Maps

E-Flo SP and PLC Connection Setup

Verify that the PLC parameters are set up correctly, see the Gateway Map table.

NOTE: If the PLC connection parameters are not setup correctly, the connection between the E-Flo SP and PLC will not be made. The standard gateway map is 17X095, and supports 6 pumps with one ADM and one CGM, or 1 tandem system with automatic cross over. There is a smaller map (17Z463) that can be purchased separately. It is for hardware that only supports less than 512bits (64bytes). The smaller 17Z463 map only supports 3 pumps with 1 ADM and 1 CGM, or 1 tandem with automatic cross over.

Gateway Map: 17X095 for 6 Booster/6Ram/1Tandem		Gateway Map: 17Z463 for 3Booster/3Ram/1Tandem	
Comm. Format	Data-SINT	Comm. Format	Data-SINT
Input Assembly Instance:	100	Input Assembly Instance:	100
Input Size:	84	Input Size:	42
Output Assembly Instance:	150	Output Assembly Instance:	150
Output Instance Size:	38	Output Instance Size:	20

NOTE: for Data Exchange element data, error code bit data, and timing diagrams, refer to the **Communications Gateway Module (CGM)** page 51.

Output from PLC / In to Graco E-Flo SP

Signal	Data Type	BIT	BYTE	Designator	Map Compatibility
SYS - Data Exchange Command	Integer	0-15	0-1	†	6X,3X
P1 - System Enable Request	Boolean	0	2	‡	6X,3X
P1 - PLC Control Lockout	Boolean	1		‡	6X,3X
P1 - Pump Enable	Boolean	2		‡	6X,3X
P1 - Pressure Control Enable	Boolean	3		‡	6X,3X
P1 - Flow Control Enable	Boolean	4		‡	6X,3X
P1 - Acknowledge / clear error	Boolean	5		‡	6X,3X
P1 - Prime Request	Boolean	6		❖	6X,3X
P1 - Recirculate Request	Boolean	7		†	6X,3X
P1 - Depressurize Request	Boolean	0	3	†	6X,3X
P1 - Cross Over Request	Boolean	1		‡	6X,3X
P1 - {Reserved Bits}	Boolean	2-7			6X,3X
P1 - Pressure Target (xx.x bar)	Integer	0-15	4-5	‡	6X,3X
P1 - Flow Target (xxx cc/min)	Integer	0-15	6-7	‡	6X,3X
P2 (replication of bytes 2-3 above)	Boolean	0-15	8-9	x	6X,3X
P2 - Pressure Target (xx.x bar)	Integer	0-15	10-11	•	6X,3X
P2 - Flow Target (xxx cc/min)	Integer	0-15	12-13	•	6X,3X
P3 (replication of bytes 2-3 above)	Boolean	0-15	14-15	x	6X,3X
P3 - Pressure Target (xx.x bar)	Integer	0-15	16-17	x	6X,3X
P3 - Flow Target (xxx cc/min)	Integer	0-15	18-19	x	6X,3X
P4 (replication of bytes 2-3 above)	Boolean	0-15	20-21	x	6X
P4 - Pressure Target (xx.x bar)	Integer	0-15	22-23	x	6X
P4 - Flow Target (xxx cc/min)	Integer	0-15	24-25	x	6X
P5 (replication of bytes 2-3 above)	Boolean	0-15	26-27	x	6X
P5 - Pressure Target (xx.x bar)	Integer	0-15	28-29	x	6X
P5 - Flow Target (xxx cc/min)	Integer	0-15	30-31	x	6X
P6 (replication of bytes 2-3 above)	Boolean	0-15	32-33	x	6X
P6 - Pressure Target (xx.x bar)	Integer	0-15	34-35	x	6X
P6 - Flow Target (xxx cc/min)	Integer	0-15	36-37	x	6X
‡ - Applies to the entire system.					
† - Applies to the active pump.					
❖ - Applies to the active pump if the active pump is disabled, applies to the inactive pump if the active pump is enabled.					
x - Not applicable in Tandem systems.					
• - Used for Purging on Tandem systems.					
3X - Map 17Z463 support for 3 pumps and Tandem.					
6X - Map 17X095 support for 6 pumps and Tandem.					

Input to PLC/Out from Graco E-Flo SP

Signal	Data Type	BIT	BYTE	Designator	Map Compatibility
P1 - Heartbeat	Boolean	0	0	†	6X,3X
P1 - PLC Control Lockout Active	Boolean	1		†	6X,3X
P1 - Automation Control ready	Boolean	2		†	6X,3X
SYS - System is enabled	Boolean	3		†	6X,3X
P1 - Pump trying to move	Boolean	4		†	6X,3X
P1 - Pump is actually moving	Boolean	5		†	6X,3X
P1 - No Active alarms	Boolean	6		†	6X,3X
P1 - No Active deviations	Boolean	7		†	6X,3X
P1 - No Active advisories	Boolean	0	1	†	6X,3X
P1 - Prime Active	Boolean	1		†	6X,3X
P1 - Recirculation Active	Boolean	2		†	6X,3X
P1 - Depressurization Active	Boolean	3		†	6X,3X
P1 - Drum Low	Boolean	4		†	6X,3X
P1 - Drum Empty	Boolean	5		†	6X,3X
P1 - Not Primed	Boolean	6		†	6X,3X
P1 - Pump 1 active (Tandem systems only)	Boolean	7		‡	6X,3X
P1 - Data Exchange Active Command	Boolean	0-15	2-3	†	6X,3X
P1 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	4-5	†	6X,3X
P1 - Outlet Pressure (xx.x bar)	Integer	0-15	6-7	†	6X,3X
P1 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	8-9	†	6X,3X
P1 - Data Exchange Value	Integer	0-31	10-13	†	6X,3X
<hr/>					
P2 (replication of bytes 0-1 above)	Boolean	0-15	14-15	∅	6X,3X
P2 - Data Exchange Active Command	Boolean	0-15	16-17	∅	6X,3X
P2 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	18-19	∅	6X,3X
P2 - Outlet Pressure (xx.x bar)	Integer	0-15	20-21	∅	6X,3X
P2 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	22-23	∅	6X,3X
P2 - Data Exchange Value	Integer	0-31	24-27	∅	6X,3X
<hr/>					
P3 (replication of bytes 0-1 above)	Boolean	0-15	28-29	x	6X,3X
P3 - Data Exchange Active Command	Boolean	0-15	30-31	x	6X,3X
P3 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	32-33	x	6X,3X
P3 - Outlet Pressure (xx.x bar)	Integer	0-15	34-35	x	6X,3X
P3 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	36-37	x	6X,3X
P3 - Data Exchange Value	Integer	0-31	38-41	x	6X,3X
<hr/>					
P4 (replication of bytes 0-1 above)	Boolean	0-15	42-43	x	6X
P4 - Data Exchange Active Command	Boolean	0-15	44-45	x	6X
P4 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	46-47	x	6X
P4 - Outlet Pressure (xx.x bar)	Integer	0-15	48-49	x	6X
P4 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	50-51	x	6X
P4 - Data Exchange Value	Integer	0-31	52-55	x	6X

Signal	Data Type	BIT	BYTE	Designator	Map Compatibility
P5 (replication of bytes 0-1 above)	Boolean	0-15	56-57	x	6X
P5 - Data Exchange Active Command	Boolean	0-15	58-59	x	6X
P5 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	60-61	x	6X
P5 - Outlet Pressure (xx.x bar)	Integer	0-15	62-63	x	6X
P5 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	64-65	x	6X
P5 - Data Exchange Value	Integer	0-31	66-69	x	6X
P6 (replication of bytes 0-1 above)	Boolean	0-15	70-71	x	6X
P6 - Data Exchange Active Command	Boolean	0-15	72-73	x	6X
P6 - Actual Pump Flow Rate (xxx cc/min)	Integer	0-15	74-75	x	6X
P6 - Outlet Pressure (xx.x bar)	Integer	0-15	76-77	x	6X
P6 - Inlet Pressure (or filter pressure) (xx.x bar)	Integer	0-15	78-79	x	6X
P6 - Data Exchange Value	Integer	0-31	80-83	x	6X
† - Conveys the status of the active pump only. ◇ - Conveys the status of the inactive pump only. ‡ - The status of both pumps are taken into account. x - Not applicable in Tandem systems. 3X - Map 17Z463 support for 3 pumps and Tandem. 6X - Map 17X095 support for 6 pumps and Tandem.					

California Proposition 65

CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm – www.P65warnings.ca.gov.

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

Sealant and Adhesive Dispensing Equipment

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor, go to www.graco.com, or call to identify the nearest distributor.

If calling from the USA: 1-800-746-1334

If calling from outside the USA: 0-1-330-966-3000

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A6724

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2018, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision D, November 2024